



PRIUS *c*
2 0 1 6



QUICK REFERENCE GUIDE

2016 Prius c

This *Quick Reference Guide* is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The *Quick Reference Guide* is not intended as a substitute for the *Owner's Manual* located in your vehicle's glove box. We strongly encourage you to review the *Owner's Manual* and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor Sales, U.S.A., Inc. wish you many years of satisfied driving in your new Prius c.

A word about safe vehicle operations

This *Quick Reference Guide* is not a full description of Prius c operations. Every Prius c owner should review the *Owner's Manual* that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the *Owner's Manual*. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this *Quick Reference Guide* is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

INDEX

OVERVIEW

Engine maintenance	9
Fuel tank door release and cap	8
Hood release	8
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
Keyless entry¹	6
Light control-Instrument cluster	9
Smart Key system^{1,2}	7

FEATURES/OPERATIONS

Audio	18
Auto lock/unlock¹	17
Automatic air conditioning/heating	16
Bluetooth® Device Pairing Section	36-45
Clock	22
Cruise control	20
Drive mode	11
Hill-start Assist Control (HAC)	23
Hybrid Synergy Drive System	10
Hybrid transmission	11
Lights & turn signals	15
Moon roof	17
Multi-Information Display (MID) ²	21
Parking brake	20
Power outlet-12V DC	18
Seat adjustments-Front	12
Seat-Folding down rear seat	13
Seat heaters	16
Seats-Head restraints	12
Steering wheel switches	19
Telephone controls (Bluetooth®)	22
Tilt and telescopic steering wheel	21
USB/AUX port	19
Windows-Power	13
Windshield wipers & washers	14

TOYOTA SAFETY SENSE

Auto High Beams (AHB)	30
Lane Departure Alert (LDA)	27-29
Pre-Collision System (PCS)	25-26
Quick overview-	
Toyota Safety Sense C	24
Sensors	24

SAFETY AND EMERGENCY FEATURES

Doors-Child safety locks	32
Door locks	32
Floor mat installation	34
Seat belts	31
Spare tire & tools	32
Star Safety System™	33-34
Tire Pressure Monitoring (warning) System	31



¹ Visit your Toyota dealer for information on customizing this feature.

² Programmable by customer. Refer to the Owner's Manual for instructions and more information.


OVERVIEW

Instrument panel

Steering wheel controls



- 1 Steering wheel audio controls
- 2 Steering wheel climate controls
- 3 Multi-Information Display “DISP” button
- 4 “TRIP” button
- 5 Cruise control¹
- 6 Ignition switch (standard key)¹
- 7 Telephone controls
- 8 Voice command button^{2,3}
- 9 Headlight/turn signal and fog light¹ controls
- 10 Wiper and washer controls
- 11 Power button (Smart Key)¹
- 12 Emergency flasher button
- 13 Instrument cluster
- 14 Air conditioning/heating controls
- 15 Outside heated rearview mirror¹/rear window defogger button
- 16 Front window defogger button
- 17 Audio system² or audio/navigation system²
- 18 USB/AUX port
- 19 12V DC power outlet




- 20 Seat heater controls¹
- 21 VSC OFF switch
- 22 “EV MODE” drive switch
- 23 “ECO MODE” drive switch
- 24 Shift lever
- 25 Tilt and telescopic steering lock release lever
- 26 Tire Pressure Monitoring (warning) System reset
- 27 Hood lock release lever
- 28 Fuel tank door opener
- 29 Lane Departure Alert (LDA) switch¹
- 30 Pre-Collision System (PCS) switch¹
- 31 Instrument cluster light control dial
- 32 Power rearview mirror controls
- 33 Automatic High Beam (AHB) switch¹

¹ If equipped

² For more information, refer to “Navigation System Owner’s Manual” and “2016 Entune™ Audio Quick Reference Guide.”

Instrument cluster



- ❶ Speedometer
- ❷ Transmission shift position indicator
- ❸ Fuel gauge
- ❹ Multi-Information Display
- Service indicators and reminders

Indicator symbols

For details, refer to “Indicators and warning lights,” Section 2, *2016 Owner’s Manual*.

-  BRAKE Brake system warning¹
-  Brake system warning light (yellow indicator)¹
-  Driver seat belt reminder (alarm will sound if speed is over 12 mph)
-  Charging system warning¹
-  Malfunction/Check Engine indicator¹
-  Airbag SRS warning¹
-  Master warning¹
-  Low Tire Pressure Warning¹
-  Electric power steering system warning¹
-  Immobilizer system indicator²
-   Headlight low/high beam indicator
-  Turn signal indicator

¹ If indicator does not turn off within a few seconds of starting Hybrid System, there may be a malfunction. Have vehicle inspected by your Toyota dealer.

	READY indicator
	EV Drive Mode indicator
	Eco Mode indicator
	EV drive indicator
	Front fog light indicator
	Slip indicator/Hill-start Assist Control indicator ¹
	SET Cruise control ² /cruise control “SET” indicator ² indicator
	ABS Anti-lock Brake System warning ¹
	SRS airbag on-off indicator ¹
	Low fuel level warning
	Pre-Collision System (PCS) warning ²
	PARK Parking brake warning
	Automatic High Beam (AHB) indicator ²
	Lane Departure Alert (LDA) indicator ²
	VSC OFF indicator ¹
	P Shift position indicator
	Arrow direction indicates fuel tank door position

² If equipped.


Keyless entry

Locking operation

Type A



Type B




Push 

Unlocking operation

Type A



Type B



Push ONCE: Driver door
TWICE: All doors



NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.


Panic button



Push and hold 


Smart Key system (if equipped)

Start function




Power (without starting Hybrid System)


Without depressing the brake pedal, pressing the “POWER” switch will change the operation mode in succession from:



Unlocking operation*




Locking operation*



* Front door handles only.




Back door lock/unlock



* Driver door unlocking function can be programmed to unlock driver door only, or all doors. Grasping passenger door handle will unlock all doors.



NOTE: Doors may also be locked/unlocked using remote.

Fuel tank door release and cap




NOTE: Tighten until one click is heard. If the cap is not tightened enough, Check Engine “” indicator may illuminate.


Hood release



Light control-Instrument cluster



Engine maintenance



- ① Engine oil filler cap
- ② Engine coolant reservoir
- ③ Engine oil level dipstick
- ④ Windshield washer fluid tank

NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the “Warranty Maintenance Guide.”

Maintenance reset light instructions can be found in “Maintenance Requirements Chapter” in Owner’s Manual.

FEATURES/OPERATIONS

Hybrid Synergy Drive System


The Hybrid Synergy Drive System utilizes a computer-controlled gasoline engine and electric motor to provide the most efficient combination of power for the vehicle. To conserve energy, when the brakes are applied the braking force generates electricity which is then sent to the traction battery. In addition, the engine shuts off when the vehicle is stopped. The benefits are better fuel economy, reduced vehicle emissions and improved performance.

NOTE: Fuel consumption and energy information of the Hybrid System are shown on the multi-information display or the Display Audio System.

Tips for improved fuel economy


- Ensure tire pressures are maintained at levels specified in the *Owner's Manual*.
- When possible, link trips to reduce engine cold starts.
- Avoid driving at speeds that are higher than necessary, especially on the highway.
- When possible, avoid sudden stops to maximize regenerative braking energy.
- Minimize use of the Air Conditioning.

Starting the Hybrid System



- (1) Put the selector lever in "P."
- (2) **Vehicles with Smart Key system:**
Depress the brake pedal, and press the "POWER" switch briefly and firmly.
Vehicles without Smart Key system:
Depress the brake pedal, and turn the key to the "START" position.
- (3) The "READY" light will blink. After a few seconds, when the light remains steady and a beep sounds, you may begin driving.

Hybrid transmission




P	Park ¹
R	Reverse
N	Neutral
D	Drive
B	Engine brake ²

¹ The “POWER”/ignition switch must be “ON” and the brake pedal depressed to shift from Park.

² The engine brake is the equivalent of downshifting. Shift to “B” when engine braking is desired (e.g. downhill driving, coasting to a stop).

Drive mode


ECO MODE



Eco Mode helps achieve low fuel consumption during trips that involve frequent accelerating and braking.

Refer to the *Owner’s Manual* for more details.


EV MODE




EV Drive Mode allows the electric motor (traction motor), powered by the hybrid battery (traction battery), to be used to drive the vehicle under certain driving conditions.

Seats-Head restraints

Front (adjustable type)/Rear center



Rear outboard




Seat adjustments-Front




- 1 Seat position (forward/backward)
- 2 Height crank (driver side; if equipped)
- 3 Seatback angle

Seat-Folding down rear seat

Split rear seats




Non-split rear seat




Windows-Power

Driver side



Window lock switch




Automatic operation (driver side only) Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.

Window lock switch Deactivates all passenger windows. Driver's window remains operable.


Windshield wipers & washers

Front

Type A




Type B




* Intermittent windshield wiper frequency adjustment Rotate to increase/ decrease wipe frequency. (if equipped)

Rear (if equipped)

Type A



Type B





* The wipers will automatically operate a couple of times after the washer squirts.

Lights & turn signals

Headlights

Type A

Type B




Daytime Running Light system (DRL) Automatically turns on the headlights at a reduced intensity.

Front fog lights (if equipped)


Type A

Type B




☞ Front fog lights come on only when the headlights are on low beam.

Turn signals




Automatic air conditioning/heating



- 1 Automatic climate control ON
Adjusting the temperature setting will cause the airflow vents, air intake and fan to adjust automatically.
- 2 Temperature setting display
- 3 Fan speed display
- 4 Airflow mode display
- 5 Windshield defogger
- 6 Outside heated rearview mirror (if equipped)/Rear window defogger
- 7 Recirculate cabin air (outside air when OFF)
- 8 Airflow vent
In “” mode, use outside air (“” indicator OFF) to reduce window fogging.
- 9 Fan speed control
- 10 Climate control OFF
- 11 Air Conditioning ON/OFF
- 12 Temperature selector dial




Seat heaters (if equipped)



Moon roof (if equipped)


Sliding operation

Push once to open to recommended position; again to open completely.



Recommended open position to minimize wind noise.

Tilting operation



Push once to open; moon roof will automatically stop at the recommended position. Push again to open completely.

Auto lock/unlock

Automatic door locks can be programmed to operate in two different modes, or turned OFF.

- Doors lock when shifting from Park.
- Doors lock when the vehicle speed is approximately 12 mph or higher.
- Doors unlock when shifting into Park.

Vehicles without Smart Key system

- Doors unlock when the ignition switch is set from "ON" to "ACC" or "LOCK" and driver's door is opened.


Vehicles with Smart Key system

- Doors unlock when the "POWER" switch is set to OFF and driver's door is opened.


Refer to the *Owner's Manual* for more details.

Audio

Type 1 - Entune™ Audio




Type 3 - Entune™ Premium Audio with Integrated Navigation and App Suite




Refer to the “Navigation System Owner’s Manual” and “2016 Entune™ Audio Quick Reference Guide.”

Power outlet - 12V DC



The “POWER”/ignition switch must be set at the “ACC” or “ON” position for use.

USB/AUX port




USB port

By connecting a USB-compatible portable audio device or USB memory to the USB port, you can listen to music from the portable audio device or USB memory through the vehicle's speaker system.

AUX port

By inserting a mini plug into the AUX port, you can listen to music from a portable audio device through the vehicle's speaker system while in AUX mode.

Steering wheel switches



① “MODE”


Push to change audio source, mute or pause the current operation. To mute or pause the current operation, press and hold. To cancel the mute or pause, press and hold again.

“V Λ”


② Use to search within the selected audio medium (radio, CD, etc.).

Cruise control (if equipped)

Turning system ON/OFF




Functions




¹ The set speed may also be cancelled by depressing the brake pedal.
² The set speed may be resumed once vehicle speed exceeds 25 mph.

Parking brake



Tilt and telescopic steering wheel



Hold wheel, push lever down, set angle and length, and return lever.

NOTE: Do not attempt to adjust while the vehicle is in motion.

Multi-Information Display (MID)



Push “DISP” to scroll through the following information screens:

- | | |
|------------------------------------|---|
| (1) Energy Monitor ¹ | (6) ECO Savings Record ¹ |
| (2) Drive Information ¹ | (7) Lane Departure Alert (LDA) ² |
| (3) ECO Score | (8) Past Record ¹ |
| (4) 5min Consumption ¹ | (9) Settings & Screen Off |
| (5) ECO Savings | |


¹ Factory default is OFF. To activate, access settings through “Settings & Screen Off.”

² If equipped.

After reaching the desired menu screen (1-7), wait for a moment and the details screen will appear. However, to display the details of “Settings & Screen Off” (8), push and hold the “DISP” button while on that menu screen.

With display showing ODO, press trip button to toggle km/h or MPH speed values.

Clock



Refer to the *Owner's Manual* for details on adjusting time.


Telephone controls (Bluetooth®)

<p>Microphone (Type A, with moon roof)</p> A line drawing of a car's interior showing the center console. A callout box highlights a microphone located on the console.	<p>Microphone (Type B, without moon roof)</p> A line drawing of a car's interior showing the center console. A callout box highlights a microphone located on the console.
<p>Audio unit</p> A line drawing of the car's audio unit. A callout box highlights the 'BT' icon on the screen.	<p>Steering wheel telephone switches</p> A line drawing of the steering wheel. Callouts point to a 'Volume' knob with '+' and '-' buttons, a 'MODE' button, and two buttons labeled 'End call' and 'Start call'.

Bluetooth® technology allows dialing or receipt of calls without taking hands from the steering wheel or using a cable to connect the telephone and the system.

Refer to “Bluetooth® Device Pairing Section,” in this guide, for more information about phone connections and compatibility.

Hill-start Assist Control (HAC)



HAC helps prevent rolling backwards on an incline. To engage, push further down on brake pedal while at a complete stop until a beep sounds and slip indicator illuminates. HAC holds for approximately two seconds after releasing brake pedal. Refer to the *Owner's Manual* for more details.

Quick overview-Toyota Safety Sense C (if equipped)

Toyota Safety Sense (TSS) C is a set of active safety technologies designed to help prevent or mitigate collisions across a wide range of traffic situations. TSS C is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe and comfortable driving experience.

Refer to the *Owner's Manual* for more details to understand these functions and complete safety precautions before attempting to use any of TOYOTA SAFETY SENSE C functions.




Pre-Collision System (PCS)

Provides collision avoidance or damage mitigation support in speed ranges where rear end collisions are likely to occur.



Lane Departure Alert (LDA)

Provides notification regarding the risk of unintended lane departure.




Auto High Beams (AHB)


Vehicle detects lights of leading or opposing vehicles and automatically changes between high and low beam headlight settings.

Sensors

Two types of sensors, located behind the front windshield, detect information necessary to operate the drive assist systems. The single-lens camera in front of the inside rear view mirror recognizes certain shapes and visible white or yellow lane markings.



Pre-Collision System (PCS)



The Pre-Collision System uses a laser sensor and camera sensor to help detect vehicles in front of your vehicle. If the system determines that the possibility of a frontal collision with a vehicle is high, the system warns the driver to take evasive action while the potential brake pressure is increased to help the driver avoid collision or reduce the impact to the vehicle and its occupants.

Note: PCS is enabled each time the engine switch is turned to Ignition On. The system can be disabled/enabled and the warning timing of the system can be changed.

Pre-collision warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.


Pre-collision brake assist

When the system determines that the possibility of a frontal collision is high, the system applies greater braking force in relation to how strongly the brake pedal is depressed.

Pre-collision braking

When the system determines that the possibility of a frontal collision is high, the system warns the driver. If the system determines that the possibility of a collision is extremely high, the brakes are automatically applied to help avoid the collision or reduce the collision speed.


Changing the pre-collision warning timing



Each time the Pre-Collision System switch is pressed, the response to the warning distance changes as follows:

- ① Far
- ② Middle (default)
- ③ Near

Disabling the Pre-Collision System (PCS)



To disable the system

Press the PCS switch for 3 seconds or more.


The PCS warning light will turn on and a message will be displayed on the Multi-Information Display (MID).

To enable the system

Press the PCS switch again.


The system is enabled each time the engine switch is turned to IGNITION ON mode.

Lane Departure Alert (LDA)



The Lane Departure Alert system recognizes visible white or yellow lane markers via a front sensor. The system alerts the driver with a warning buzzer sound and message in the Multi-Information Display (MID) when it detects the vehicle deviating from or swaying multiple times within its lane.

Turning on the LDA system



Press the LDA switch to turn the LDA system on. Depress again to turn it off.


Note: The system will continue in the last state it was in (ON or OFF) when the engine is started again.

Functions



Lane Departure Alert (LDA) indicator flashes orange when operating

- ① LDA function display
- ② Lane



The LDA function displays when the Multi-Information Display (MID) is switched to the driving assist system information screen.

- (1) The system displays solid white lines on the LDA indicator when visible lane markers on the road are detected. A side flashes orange to alert the driver when the vehicle deviates from its lane.
- (2) The system displays outlines on the LDA indicator when lane markers on the road are not detected or the function is temporarily cancelled.

Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, LDA may not function on the side(s) where white/yellow lines are not detectable.

Adjusting Lane Departure Alert (LDA) sensitivity




The driver can adjust the sensitivity of the LDA (warning) function from the Multi-Information Display (MID) customization screen.

High - Warns before the front tire crosses the lane marker.

Standard - Warns when the front tire crosses the lane marker.

Auto High Beams (AHB)



The AHB uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns high beam on or off as necessary.

Activating the Automatic High Beam (AHB) system

- (1) With the engine switch in IGNITION ON mode and headlight switch turned to “ON” position, push lever away from you.
- (2) Depress the Automatic High Beam “AUTO” switch.

The AHB indicator will come on when the headlights are turned on automatically to indicate that the system is active.

Note: Pull the lever back toward you to turn the AHB system off.

The AHB indicator will turn off and the high beam indicator turns on.

Conditions where Automatic High Beams will turn ON/OFF automatically

When all of these conditions are met, high beams will be automatically turned on (after approximately 1 second):


- Vehicle speed is above approximately 25 mph (40 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.

If any of these conditions occur, high beams will be automatically turned off:

- Vehicle speed drops below approximately 19 mph (30 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

SAFETY AND EMERGENCY FEATURES


Seat belts



NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic locking retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the *Owner's Manual*.

Tire Pressure Monitoring (warning) System



System reset initialization

1. Push and hold “SET” button until the indicator blinks three times.
2. Wait a few minutes to allow initialization to complete.

After adjusting tire pressures, or after tires have been rotated or replaced, turn the “POWER”/ignition switch “ON” and press and hold the “SET” button until indicator blinks three times. Let the vehicle sit for a few minutes to allow initialization to complete.


Refer to the load label on the door jamb or the *Owner's Manual* for tire inflation specifications.

If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota dealer.

NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.


SAFETY AND EMERGENCY FEATURES

Door locks



Doors-Child safety locks


Rear door



Moving the lever to the lock position will allow the door to be opened only from the outside.

Spare tire & tools


Tool location



¹ For detailed directions on removing the jack from under the driver's seat, refer to the *Owner's Manual*.

² Jack handle, wheel nut wrench and towing eyelet

Removing the spare tire



Refer to the *Owner's Manual* for tire changing and jack positioning procedures.

Star Safety System™

All new Toyota vehicles come standard with the Star Safety System™, which combines Vehicle Stability Control (VSC), Traction Control (TRAC), Anti-lock Braking System (ABS), Electronic Brake-force Distribution (EBD), Brake Assist (BA) and Smart Stop Technology (SST).

Vehicle Stability Control (VSC)

VSC helps prevent loss of traction during cornering by reducing Hybrid System output and applying brake force to selected wheels.

Toyota's VSC monitors steering angle and the direction your vehicle is traveling. When it senses that the front or rear wheels begin to lose traction, VSC reduces Hybrid System output and applies braking to selected wheels. This helps restore traction and vehicle control.

Traction Control (TRAC)

VSC helps prevent loss of traction during cornering by reducing Hybrid System output, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).

Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits Hybrid System output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Anti-Lock Brake System (ABS)

ABS helps prevent brakes from locking up by “pulsing” brake pressure to each wheel. This limits brake lockup and helps provide directional control for the current road conditions.

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by “pulsing” each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

Electronic Brake Force Distribution (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. Abrupt stops can cause a vehicle to tilt forward, reducing the braking power of the rear wheels. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

Brake Assist (BA)

Brake Assist is designed to detect sudden or “panic” braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

SAFETY AND EMERGENCY FEATURES

Smart Stop Technology (SST)


Smart Stop Technology automatically reduces driving torque when the accelerator and brake pedals are pressed simultaneously under certain conditions.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



BLUETOOTH® DEVICE PAIRING SECTION

To begin the Bluetooth® Pairing process, press the HOME button on the faceplate of your Toyota Vehicle Entune™ Multimedia Head Unit.¹

Bluetooth® Pairing for Android® phone and Entune™ touch screen system


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Android mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.²

Initiate Bluetooth® on your Android®



STEP 1

From your APPS SCREEN, select SETTINGS.



STEP 2

Select CONNECTIONS and select BLUETOOTH.



STEP 3

Ensure BLUETOOTH is ON.



STEP 4

Select YOUR PHONE DEVICE to make it discoverable.

Phone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your Android device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

¹ To determine which head unit is installed in your vehicle, refer to the Audio section in this guide.

² Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

BLUETOOTH® DEVICE PAIRING

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.




STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP** BUTTON on the Home Screen.




STEP 7

Select **BLUETOOTH**.
Image shown is a sample image, features may vary.



STEP 8

Select **ADD**, to add your phone device.



STEP 9

Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit



STEP 12

Using your smartphone, you will need to allow Entune access to your messaging and contacts.

It is recommended to check the "Don't ask again" box, so as not to have to press OK every time the phone makes a Bluetooth connection with your Toyota



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

Bluetooth® Pairing for iPhone® and Entune™ touch screen system


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all iPhone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

Initiate Bluetooth® on your iPhone®



STEP 1

From the HOME SCREEN, select SETTINGS.



STEP 2

Select BLUETOOTH.



STEP 3

Ensure BLUETOOTH is ON.



STEP 4

Your iPhone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.




STEP 6

Select **SETUP** BUTTON on the Home Screen.



STEP 7

Select **BLUETOOTH**.
Image shown is a sample image, features may vary.



STEP 8

Select **ADD**, to add your phone device.



STEP 9

Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.

BLUETOOTH® DEVICE PAIRING



STEP 12

Using your smartphone, you may need to allow Entune access to your messaging and contacts.

Only current iPhone text messages can be viewed on the head unit. iPhone does not allow text message reply.



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures


This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

Bluetooth® Pairing for Windows Phone® and Entune™ touch screen system


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Windows Phone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

Initiate Bluetooth® on your Windows Phone®



STEP 1

From your APP LIST, select **SETTINGS**.



STEP 2

Select **BLUETOOTH**.



STEP 3

Ensure **BLUETOOTH** is **ON**.



STEP 4

Phone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

BLUETOOTH® DEVICE PAIRING

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.




STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP** BUTTON on the Home Screen.




STEP 7

Select **BLUETOOTH**.
Image shown is a sample image, features may vary.



STEP 8

Select **ADD**, to add your phone device.



STEP 9

Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit



STEP 12

Using your smartphone, you may need to allow Entune access to your contacts.



STEP 13

A confirmation will appear that your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

- This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.
1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
 2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
 3. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.



CUSTOMER EXPERIENCE CENTER
1-800-331-4331

