


RAV4
2 0 1 9



QUICK REFERENCE GUIDE

2019

RAV4

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new RAV4.

A word about safe vehicle operations

This Quick Reference Guide is not a full description of RAV4 operations. Every RAV4 owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

OVERVIEW

Engine maintenance	11
Fuel tank door release & cap	10
Hood release	10
Indicator symbols	6-7
Instrument cluster	5
Instrument panel	2-4
Instrument panel light control	11
Keyless (and remote) entry ¹	8-9
Smart Key system ¹	9

FEATURES & OPERATIONS

Air conditioning/heating	19
Audio	23
Auto lock/unlock ¹	12
Automatic transmission	12
Bird's Eye View Camera with Perimeter Scan function	28
Blind Spot Monitor with Rear Cross Traffic Alert (BSM w/RCTA)	29
Clock	20
Cup holders	26
Door locks	14
Door-Power Liftgate	18
Downhill assist control system	28
Driving mode select	32-33
Electric parking brake	13
Garage door opener (Homelink®) ³	35
Intuitive Parking Assist	30
Lights ^{1,2} & turn signals ¹	16-17
Moonroof	20
Multi-Information Display (MID) ²	25
Multi-terrain select	34
Panoramic moonroof	21
Parking Support Brake (PKSB) functions	30
Power outlets-12V DC	26
Power outlets- 120V AC	26
Qi wireless charger	27
Rear view monitor system	29
Seat adjustments-Front	15
Seat adjustments-Rear	15
Seat heaters/ventilators	22
Seats-Head restraints	15

FEATURES & OPERATIONS (continued)

Steering lock release	14
Steering wheel-Heater	22
Steering wheel switches & telephone controls (Bluetooth®)	24
Stop & Start system	31
Tilt & telescopic steering wheel	14
USB charg-ports	27
USB media/AUX Port	23
Vehicle Stability Control (VSC)/TRAC and Trailer sway control OFF switch	33
Windows-Power	17
Windshield wipers & washers	17

TOYOTA SAFETY SENSE™ (TSS)

Automatic High Beams (AHB)	51
Full-Speed Range Dynamic Radar Cruise Control (DRCC)	48-50
Lane Departure Alert with Steering Assist (LDA w/SA)	40-43
Lane Tracing Assist (LTA)	44-47
Pre-Collision System with Pedestrian Detection (PCS w/PD)	37-39
Quick overview-	
Toyota Safety Sense™ 2.0 (TSS)	36
Road Sign Assist (RSA)	52
Sensors	37

SAFETY & EMERGENCY FEATURES

Floor mat installation	57
Rear door child safety locks	53
Safety Connect®	55
Seat belts	53
Seat belts-Shoulder belt anchor	53
Spare tire & tools	54
Star Safety System™	56-57
Tire Pressure Monitoring (warning) System (TPMS)	55

BLUETOOTH® DEVICE PAIRING SECTION

58-60


¹ Visit your Toyota dealer for information on customizing this feature.

² Programmable by customer. Refer to the Owner's Manual for instructions and more information.


³ HomeLink® is a registered trademark of Genex Corporation.

OVERVIEW

Instrument panel




Steering wheel controls



¹ If equipped.


² For details, refer to the “Navigation and Multimedia System Owner’s Manual” or visit www.toyota.com/entune for additional audio/multimedia resources.



OVERVIEW

Instrument panel (continued)

CENTER PANEL AREA




¹ If equipped.


² For details, refer to the "Navigation and Multimedia System Owner's Manual" or visit www.toyota.com/entune for additional audio/multimedia resources.

Instrument cluster


4.2-inch display



7-inch display (Analog speedometer)



7-inch display (Digital speedometer)



○ Service indicators and reminders

OVERVIEW

Indicator symbols

For details, refer to "Indicators and warning lights," Section 2-1, 2019 Owner's Manual.

	Airbag ON/OFF indicator ¹		Downhill assist control system indicator ^{1,2,4}
	Airbag SRS warning ¹		Driver's and front passenger's seat belt reminder (alarm will sound if speed is over 12 mph)
	Anti-lock Brake System (ABS) warning ¹		SET Full-Speed Range Dynamic Radar Cruise Control (DRCC) indicator/DRCC SET indicator
	Automatic High Beam (AHB) indicator		ECO ECO drive mode indicator
	Blind Spot Monitor (BSM) warning ⁴		ECO Eco driving indicator ^{1,4}
	BSM outside rear view mirror indicators ^{1,4}		Electric power steering system warning ¹ [Red/yellow]
	HOLD Brake hold operating indicator ^{1,2}		Fuel tank door position
	HOLD Brake hold standby indicator ¹		Fog light indicator ⁴
	Brake Override System/Drive-Start Control/PKSB ⁴ warning		 Headlight low/high beam indicators
	BRAKE Brake system warning ¹		High coolant temperature warning
	Brake system warning ¹ [Yellow]		P OFF Intuitive parking assist OFF indicator ^{2,4}
	 Charging system warning ¹		
	SET Constant speed cruise control indicator/Constant speed cruise control SET indicator		

	Lane Tracing Assist (LTA)/ Lane Departure Alert (LDA) indicator [Orange]		Security indicator
	Low engine oil pressure warning		Slip indicator ^{1,3}
	Low fuel level warning		Smart Key system indicator ⁴
	Low outside temperature indicator		SNOW Snow mode indicator ⁴
	Low Tire Pressure Warning ¹		SPORT SPORT mode indicator
	Malfunction/Check Engine indicator ¹		Stop & Start cancel indicator ^{1,2,4}
	Mud & sand mode indicator ⁴		Stop & Start indicator ^{1,4}
	Parking brake indicator ³		Turn signal indicator
	PKSB OFF indicator ^{1,2,4}		Vehicle Stability Control (VSC) OFF indicator ¹
	Pre-Collision System (PCS) warning ^{1,2}		
	RCTA OFF indicator ^{1,2,4}		
	Rear passenger's seat belt reminder		
	Rock & dirt mode indicator ⁴		

¹ If the indicator does not turn off within a few seconds of starting the engine, there may be a malfunction. Have the vehicle inspected by your Toyota dealer.

² If the indicator flashes, there may be a malfunction. Refer to the Owner's Manual.


³ If the indicator flashes, it indicates that the system is operating.

⁴ If equipped.

OVERVIEW

Keyless (and remote) entry


UNLOCKING OPERATION



Push
ONCE: Driver door
TWICE: All doors


Carry Smart Key remote

Front door unlock*



NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.


LOCKING OPERATION



Push


Carry Smart Key remote

All-door lock



POWER LIFTGATE LOCK/UNLOCK (IF EQUIPPED)


Smart Key



Push and hold

Carry Smart Key remote

All-door unlock and lock




* Driver door unlocking function can be programmed to unlock driver door only, or all doors. Grasping passenger door handle will unlock all doors.

NOTE: Doors may also be locked/unlocked using remote.

PANIC BUTTON

Smart Key




HOLD
HOLD
 Push and hold



Smart Key system


START FUNCTION



NOTE: The Smart Key must be carried to enable the start function. With gear shift lever in Park and the brake pedal depressed, push the “ENGINE START STOP” switch.

POWER (WITHOUT STARTING ENGINE)




Without depressing the brake pedal, pressing the “ENGINE START STOP” switch will change the operation mode in succession from:



OVERVIEW




Fuel tank door release & cap

Driver seat




NOTE: Tighten until one click is heard. If the cap is not locked or tightened, Check Engine "CHECK" indicator may illuminate.


Hood release



Instrument panel light control



Engine maintenance



NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the “Warranty & Maintenance Guide.”

FEATURES & OPERATIONS

Auto lock/unlock

Automatic door locks can be programmed to operate in different modes, or turned OFF.

Shift position linked door locking/unlocking function

- Doors lock when shifting from Park.
- Doors unlock when shifting into Park.

Speed linked door locking function


- Doors lock when the vehicle speed goes above approximately 12 mph.

Driver's door linked door unlocking function

- Doors unlock when driver's door is opened.

Refer to the Owner's Manual for more details.

Automatic transmission



* The "ENGINE START STOP" switch/ignition switch must be "ON" and the brake pedal depressed to shift from Park.

"S" (SEQUENTIAL) MODE

Shift the shift lever to "S" position from "D" position.


- + : Upshift (push and release)
- : Downshift (pull and release)

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the "D" position.


Electric parking brake

PARKING BRAKE

Automatic mode



Manual mode



Automatic (shift lever operation)


To turn automatic mode ON, while vehicle is stopped, pull and hold switch until a buzzer sounds and "EPB Shift Interlock Function Activated" displays in Multi-Information Display (MID). While depressing brake, shifting into P position will automatically set the brake and turn the parking brake indicator and parking brake light on. To release brake, depress brake and shift out of P. The indicator light turns off.

To turn automatic mode OFF, push and hold parking brake switch until "EPB Shift Interlock Function Deactivated" displays on the MID.

Manual

While vehicle is stopped and brake pedal is depressed, pull to set parking brake and turn the parking brake indicator and parking brake light on. To release, press the brake pedal and push switch. The indicator light turns off.

BRAKE HOLD




The brake hold system keeps the brake applied when the shift lever is in D, S or N with the system on and the brake pedal has been depressed to stop the vehicle. The system releases the brake when the accelerator pedal is depressed with the shift lever in D or S to allow smooth start off.


Refer to the *Owner's Manual* for limitations and more details.

Tilt & telescopic steering wheel

Lock release lever



Angle




Hold wheel, push lever down, set angle and length, and return lever.

NOTE: Do not attempt to adjust while the vehicle is in motion.

Steering lock release


Smart Key



When the steering lock cannot be released, "Push Engine Switch while Turning Steering Wheel in Either Direction" will be displayed on the multi-information display.

Press the engine switch shortly and firmly while turning the steering wheel left and right.


Without Smart Key



When starting the engine, the engine switch may seem stuck in OFF. To free it, turn the key while turning the steering wheel slightly left and right.


When starting the engine, the engine switch may seem stuck in OFF. To free it, turn the key while turning the steering wheel slightly left and right.

Door locks




Seats-Head restraints

Front seats



Lock release button

Rear seats



Lock release button



Rear outboard seat

Head restraints cannot be adjusted.

Seat adjustments-Front


MANUAL SEAT

POWER SEAT (DRIVER'S SIDE)




Seat adjustments-Rear

Adjustment



Folding




FEATURES & OPERATIONS



Lights & turn signals

HEADLIGHTS

Type A



Type B



Daytime Running Light system (DRL) Automatically turns on under certain conditions to make vehicle more visible to other drivers. Not for use at night.


Automatic light cut off system Automatically turns lights off after a 30 second delay, or lock switch on remote is pushed after locking.

Automatic High Beam (AHB) system Automatically switches between high and low beams as appropriate for enhanced vision at night.

Refer to Toyota Safety Sense™ (TSS) in this guide or the Owner's Manual for more details on the Automatic High Beam feature.

* Operating conditions must be met. Refer to Owner's Manual for details.


TURN SIGNALS



¹ The right hand signals will flash three times.

² The left hand signals will flash three times.

FOG LIGHTS (IF EQUIPPED)




Front fog lights come on only when the headlights are on low beam.

Windshield wipers & washers

FRONT

Intermittent

Adjust frequency*



Pull to wash and wipe

Single wipe

Off


Interval wipe

Slow

Fast

Rain-sensing (if equipped)

Adjust frequency*



Pull to wash and wipe

Single wipe

Off

Interval wipe


Slow

Fast

***Intermittent windshield wiper frequency adjustment** Rotate to increase/decrease wipe frequency.


* **Rain-sensing windshield wiper** Rotate to increase/decrease sensor sensitivity.

REAR




Windows-Power

Driver side



Window lock switch




All window auto up/down Push the switch completely down or pull it completely up and release to fully open or close. To stop window partway, lightly push the switch in the opposite direction.

Window lock switch Deactivates all passenger windows. Driver's window remains operable.

FEATURES & OPERATIONS

Door-Power Liftgate (if equipped)


Instrument panel




Open: Push and hold
Close: Push and hold again

Power Liftgate (back door)



(open only)



(close only)



Hands-Free, Foot-Activated Power Liftgate (if equipped)



To automatically open/close Power Liftgate Quickly swipe your foot near the lower center part of the rear bumper for within 1 second to trigger sensor. To operate, make sure that the touchless sensor operation is enabled and that you are carrying the remote.

NOTE: If battery is disconnected, the power back door needs to be reinitialized.

PROGRAMMABLE POWER LIFTGATE

1. When the liftgate reaches the desired height, push the rear liftgate close-button (on the door jam of the liftgate) once. Press and hold the button until the buzzer sounds (4 times).
2. To reset the height, with the liftgate open and not moving, press and hold the rear liftgate close-button until it buzzer sounds 4 times, and continue to hold until it buzzes again -then let go. Push the same button to close the liftgate. When you next open the liftgate it will open to the maximum height.
3. To set the height using the Multi-Information Display, press " or " meter control switches and select " from the MID. Press " or " and select  and then press ". Select Opening Adjustment, then press ". Select desired position (5 height options to choose from,) then press ".

For more details, refer to the Owner's Manual.

Air conditioning/heating

AUTOMATIC AIR CONDITIONING (IF EQUIPPED)

Automatic climate control ON - Adjusting the temperature setting will cause the airflow vents, air intake and fan to adjust automatically.

Synchronizes driver, front passenger and rear temperature settings


Temperature selector (driver side)

Windshield defogger

ECO mode

Rear Air Flow mode

Temperature selector settings (front passenger side)



Climate control OFF

Outside mirror (if equipped)/ Rear window defogger

Fan speed

Air conditioning ON/OFF

Recirculate cabin air (outside air when OFF)

Airflow vent

In " " or " " mode, use outside air (" " indicator OFF) to reduce window fogging.




MANUAL AIR CONDITIONING (IF EQUIPPED)

Fan speed

Outside mirror (if equipped)/ Rear window defogger

MAX A/C switch

Temperature selector settings



Climate control OFF

Windshield defogger

Air conditioning ON/OFF

Recirculate cabin air (outside air when OFF)

Airflow vent

In " " or " " mode, use outside air (" " indicator OFF) to reduce window fogging.




Refer to the Owner's Manual for more information.

FEATURES & OPERATIONS

Moonroof (if equipped)

SLIDING OPERATION


Push once to open partway; again to open completely.



Recommended driving position to minimize wind noise.

TILTING OPERATION

Push once to open completely.



Lightly press either side of the moonroof switch while opening/tilting is in progress, the moonroof stops partway.

Clock

To find your system, refer to the Audio section of this guide.

FOR ENTUNE™ 3.0 AUDIO

- 1) Push "APPS" button next to the screen, then select "SETUP" next to the screen. The system displays the Setup screen.
- 2) Select "General" to access General settings screen.
- 3) Select "Clock" to access settings.

FOR ENTUNE™ 3.0 AUDIO PLUS AND ENTUNE™ 3.0 PREMIUM (JBL®) AUDIO WITH INTEGRATED NAVIGATION AND APP SUITE


- 1) Push "MENU" button next to the screen, then select "Setup" on the touch screen.
- 2) Select "General" on the touch screen. The system displays the "General Settings" screen.
- 3) Then select "Clock" to access settings.

Refer to the Owner's Manual or the Navigation and Multimedia System Owner's Manual for more information.

Panoramic moonroof (if equipped)

SLIDING OPERATION

Open and closing the electronic sunshade




Open - Slide and hold the  switch backward. The electronic sunshade will open fully automatically.*


Close - Slide and hold the  switch forward. The electronic sunshade will close fully automatically.*

*** Note: Quickly slide and release the switch in either direction to stop the electronic sunshade partway.**

Open and closing the panoramic moonroof



Open - Slide and hold the  switch backward. The panoramic moonroof and electronic sunshade will open automatically.*




Close - Slide and hold the  switch forward. The panoramic moonroof will fully close automatically.

*** Note: Quickly slide and release the switch in either direction to stop the panoramic moonroof partway.**

TILTING OPERATION

Tilting the panoramic moonroof up and down



Tilt-up - Press the center of the  switch to tilt the panoramic moonroof up. When the panoramic moonroof is tilted up, the electronic sunshade opens to the half-open position.

Tilt-down - Press and hold the  switch to tilt down. The panoramic moonroof can be tilted down only when it is in the tilt-up position.


Note: The panoramic moonroof can be opened from the tilt-up position. Also, lightly pressing the  switch again stops the panoramic moonroof partway.

FEATURES & OPERATIONS


Seat heaters/ventilators (if equipped)

SEAT HEATERS (IF EQUIPPED)

Front




Rear



SEAT VENTILATORS (IF EQUIPPED)

Driver's seat

Passenger's seat



Level indicators


Yellow - seat heater on

Green - seat ventilator on

The engine switch must be in the "ON" mode.

Refer to the Owner's Manual for more details.

Steering wheel-heater (if equipped)




Engine switch must be in the "ON" position or MID must display the "IGNITION ON."

Audio

ENTUNE™ 3.0 AUDIO

ENTUNE™ 3.0 AUDIO PLUS

ENTUNE™ 3.0 PREMIUM (JBL®) AUDIO WITH INTEGRATED NAVIGATION




Refer to the "Navigation and Multimedia System Owner's Manual" or visit www.toyota.com/entune for additional audio/multimedia resources.

NOTE: Concentrating on the road should always be your first priority while driving. Do not use the Entune™ 3.0 system if it will distract you.

Visually match your vehicle's Entune™ 3.0 audio system to one featured in this guide for the most accurate information.

USB media/AUX port



USB media port


By connecting a USB-compatible portable audio device or USB memory stick into the USB media port, you can listen to music through the vehicle's speaker system.

AUX port


By inserting an AUX cable into the AUX port, you can listen to music from a portable audio device through the vehicle's speaker system while in AUX mode.

FEATURES & OPERATIONS

Steering wheel switches & telephone controls (Bluetooth®)



Microphone



Bluetooth® technology allows dialing or receipt of calls without removing your hands from the steering wheel or using a cable to connect the compatible telephone and the system.

* Push and hold to access Mobile Assistant. When a compatible smartphone is Bluetooth® connected push and hold the Voice Command switch 2-3 seconds to access Siri® Eyes Free.


Refer to the Owner's Manual and Navigation and Multimedia System Owner's Manual for more details.

NOTE: Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.

Multi-Information Display (MID)


4.2-inch display

Driving support system information display area




7-inch display

Driving support system information display area



Information display area

Information display area



Push MID control switches to view or change information in the following:


-  Driving information
-  Driving support system information
-  Audio system-linked display
-  Vehicle information
-  Settings display
-  Warning display

Refer to the Owner's Manual for more information.


FEATURES & OPERATIONS

Power outlets-12V DC


Front



Rear (if equipped)




Luggage compartment (if equipped)



The engine switch must be in the "ACC" or "ON" position to be used.


Power outlets-120V AC (if equipped)




The engine switch must be in the "ON" position to be used.

Cup holders

Front




Rear




USB charge-ports (if equipped)

Front




Rear




The engine switch must be set at "ACCESSORY" or "ON" position for use.

Qi Wireless charger (if equipped)




(1)



When the engine is turned off, the last state (ON/OFF) of the charger is memorized.

(2)




Place device nearest the center of charging area for best results. Moving device may result in stopping or restarting the charging process.

A mobile device can be charged wirelessly on the tray. (1) Press the wireless charger power switch and the green operation indicator light turns on. (2) Place a mobile device on the tray as shown in the illustration. An amber indicator illuminates while charging is in progress. When charging is complete, the indicator illuminates green. Some phones, cases or cover type wireless chargers may not cause the green indicator to illuminate even though it is fully charged.

Refer to the Owner's Manual for more details on this system before attempting to use it.


FEATURES & OPERATIONS

Bird's Eye View Camera with Perimeter Scan Function (if equipped)



Moving view

Body color setting switch




Rotation pause switch

Display mode change switch

See through view

Body color setting switch



Rotation pause switch

Display mode change switch

The Bird's Eye View Camera with Perimeter Scan function assists the driver in viewing the surroundings, when operating at low speeds or parking, by combining front, side and rear cameras and displaying an overhead image on the screen.

To view or turn OFF the screen, press the camera switch when the shift lever is in the "P" position. It will display two angles, the Moving view and the See Through view.

For limitations and more details, refer to section 4-5 in the Owner's Manual.

Downhill assist control system (if equipped)




With the downhill assist control system, the vehicle is able to descend a steep hill, maintaining a constant low speed of about 15 mph (25 km/h) without brake pedal operation.

Press the "DAC" button to activate the system. The downhill assist control system indicator will flash to as the system gradually ceases operation.

Refer to the Owner's Manual for more limitations and details.

Blind Spot Monitor with Rear Cross Traffic Alert (BSM w/RCTA) (if equipped)



The Blind Spot Monitor is a system that has two functions:


- The Blind Spot Monitor function (assists the driver in making the decision when to change lanes)
- The Rear Cross Traffic Alert function (assists the driver when backing up)

The system is designed to use radar sensors to detect vehicles traveling in the Rav4's blind spot. If a vehicle is detected, the driver will be alerted via the outside rear view side mirror indicators.

Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

Rear view monitor system

Refer to the Owner's Manual for more information.




The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is located above the license plate.

To adjust the image on the rear view monitor screen, press the "MENU" button and select "Display" on the "Setup" screen. Select "Camera" to adjust the screen contrast and brightness.

Refer to the Owner's Manual for limitations and more details on this system.

FEATURES & OPERATIONS

Intuitive Parking Assist (if equipped)



If the sensors detect an obstacle, the buzzer and MID or navigation system display informs the driver of the approximate position and distance of the obstacle by illuminating continuously (far) or blinking (near). Depending on your Entune™ 3.0 Audio system, you can adjust settings.

To turn system ON/OFF:

- 1) Press "**◀** / **▶**" or "**▲** / **▼**" and "**OK**" of the meter control switches and select "**⚙**" from the Multi-Information Display (MID).
- 2) Select **P** and press "**OK**". The system displays **P** when the the system is operational.

Refer to the Owner's Manual for more details.

Parking Support Brake (PKSB) function (if equipped)

The Parking Support Brake system consists of the following functions that operate when driving at a low speed or backing up, such as when parking. When the system determines that the possibility of a collision with a detected object is high, a warning operates to urge the driver to take evasive action. If the system determines that the possibility of a collision with a detected object is extremely high, the brakes are automatically applied to help avoid the collision or help reduce the impact of the collision.

CHANGE SETTINGS


Use "**◀** / **▶**" or "**▲** / **▼**" and "**OK**" of the meter control switches to select "**⚙**" and **🚗** in the Multi-Information Display (MID) to change settings. The system will continue in the last state it was in (ON or OFF) when the engine is started again.

Refer to all of the section Parking Support Brake functions (static objects and rear-crossing vehicles) in the Owner's Manual for more details.

Stop & Start system (if equipped)

The Stop & Start system stops and starts the engine according to brake pedal or shift lever operation when the vehicle is stopped, such as at a stoplight, intersection, etc., in order to improve fuel economy and reduce noise pollution caused by the engine idling.

STOP & START SYSTEM OPERATION



Stopping the engine

While driving with the D shift position selected, depress the brake pedal and stop the vehicle. The engine will stop automatically.

When the engine stops, the Stop & Start indicator will illuminate.

Restarting the engine


Release the brake pedal. The engine will start automatically.

When the engine starts, the Stop & Start indicator will turn off.

DISABLING THE STOP & START SYSTEM

Press the Stop & Start cancel switch to disable the Stop & Start system.

The Stop & Start cancel indicator will illuminate. Pressing the switch again will enable the Stop & Start system and the Stop & Start cancel indicator will turn off.




Refer to the Owner's Manual for limitations and more details on this system.


FEATURES & OPERATIONS

Driving mode select

FF VEHICLES/DYNAMIC TORQUE CONTROL AWD VEHICLES



DYNAMIC TORQUE VECTORING AWD VEHICLES



Normal mode

Use for normal driving.

ECO drive mode

Use Eco drive mode to help achieve low fuel consumption during trips that involve frequent accelerating.

SPORT mode


Use Sport mode when increased acceleration response and precise handling is desired, for example, when driving on mountain roads.

Refer to the Owner's Manual for limitations and more details on this system.


SNOW MODE (IF EQUIPPED)

Snow mode can be selected to suit the conditions when driving on slippery road surfaces, such as on snow.

Dynamic Torque Control AWD vehicles



Dynamic Torque Vectoring AWD vehicles



Refer to the Owner's Manual for limitations and more details on this system.

Vehicle Stability Control (VSC)/ TRAC and Trailer sway control OFF switch



The VSC OFF switch can be used to help free a stuck vehicle in surroundings like mud, dirt or snow. While the vehicle is stopped, press switch to disable the TRAC system.


To disable both VSC and TRAC systems, press and hold the switch for at least 3 seconds.

Refer to the Owner's Manual for more limitations and details.


FEATURES & OPERATIONS

Multi-terrain Select (AWD vehicles)

DYNAMIC TORQUE CONTROL AWD VEHICLES



DYNAMIC TORQUE VECTORING AWD VEHICLES



Multi-terrain Select is a system that helps drivability in off-road situations. When driving over muddy, sandy or rough road surfaces, the system selects a suitable driving mode to switch AWD, brake and drive force control to perform control suitable for the road condition.


MUD & SAND - Muddy roads, sandy roads, muddy road or dirty conditions.

ROCK & DIRT - Very bumpy road conditions, such as unpaved forest roads.


Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

Garage door opener (HomeLink®)* (if equipped)

Vehicles with auto anti-glare inside rear view mirror



Vehicles with Digital Rearview mirror



Garage door openers manufactured under license from HomeLink®* can be programmed to operate garage doors, estate gates, security lighting, etc.

Refer to "Garage door opener," Section 6-4 in the Owner's Manual, for more details.

For programming assistance, contact HomeLink® at 1-800-355-3515, or visit <http://www.homelink.com>.

* HomeLink® is a registered trademark of Gentex Corporation.

Quick overview-Toyota Safety Sense™ 2.0

Toyota Safety Sense™ (TSS) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the Owner's Manual for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to <http://www.toyota.com/safety-sense>



Pre-Collision System with Pedestrian Detection (PCS w/PD)

PCS w/PD is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system detects a potential collision with a preceding vehicle is likely to occur.

The advanced millimeter-wave radar sensor system is designed to work with the camera sensor to help recognize a preceding pedestrian or bicyclist, and provide an alert, mitigation and/or avoidance support in certain conditions.



Lane Departure Alert with Steering Assist (LDA w/SA)

LDA w/SA is designed to provide notification when the system detects an unintended lane departure.

The Steering Assist function is designed to provide small corrective steering inputs to the steering wheel for a short period of time to help keep the vehicle in its lane.

The Sway Warning function is designed to detect vehicle swaying (based on the vehicle location and steering wheel operation) and alert the driver with an audio and visual alert, urging them to take a break.



Lane Tracing Assist (LTA)

LTA contains all the features of LDA described above and additionally is designed to help keep the vehicle in the center of a lane by assisting the driver in steering control when using Full-Speed Range DRCC.



Full-Speed Range Dynamic Radar Cruise Control (DRCC)

DRCC is designed to help maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed. Full-Speed Range DRCC is the same as regular DRCC except the available speed range is extended down to 0 MPH.



Automatic High Beams (AHB)

AHB is designed to detect the headlights of oncoming vehicles and the tail lights of preceding vehicles and switch between high beams and low beams as appropriate.




Road Sign Assist (RSA)


RSA is designed to recognize specific road signs using the forward facing camera to provide information to the driver via the display.

Sensors

TSS combines an in-vehicle camera mounted in front of the inside rear view mirror and a radar mounted in the front grill. These sensors support the driver assist systems.



Pre-Collision System with Pedestrian Detection (PCS w/PD)



The Pre-Collision System uses a radar sensor and camera sensor to help detect a vehicle or pedestrian or bicyclist in front of your vehicle.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the Pre-Collision System yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle may not be detected by the radar and camera sensors, preventing the system from operating or engaging properly.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system may not operate properly.

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist

If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.

PRE-COLLISION SYSTEM (CONTINUED)


Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.

Refer to the Toyota Owner's Manual for additional information on PCS operation, settings adjustments, limitations, and precautions before attempting to use it.

PCS PEDESTRIAN DETECTION


Under certain conditions, the PCS system included with the TSS package may also help to detect a pedestrian in front of your vehicle using the in-vehicle camera and lasers. The in-vehicle camera of PCS detects a potential pedestrian or bicyclist based on size, profile, and motion of the detected pedestrian or bicyclist. However, a pedestrian or bicyclist may not be detected depending on the conditions, including the surrounding brightness and the motion, posture, size, and angle of the potential detected pedestrian or bicyclist, preventing the system from operating or engaging.



As part of the Pre-Collision System, this function is also designed to first provide an alert and then automatic braking if needed.

Refer to the Toyota Owner's Manual for additional limitations and information.

CHANGING PRE-COLLISION ALERT TIMING




Each time the PCS switch is pressed, the response to the PCS alert timing changes.

- (1) Press “< >” switches and select “⚙️” from the Multi-Information Display (MID).
- (2) Press “⏴ ⏵” switches and select “🚗” from the MID and then press “OK”. The setting screen is displayed.
- (3) Press “OK” each time to change the setting. Each time it is pressed, the response to the PCS alert timing changes as shown above. You can press “⏴” to go back to the menu.

Note: PCS is enabled each time the engine switch is turned to Ignition On. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same).

DISABLING PRE-COLLISION SYSTEM (PCS)




- (1) Press “< >” switches and select “⚙️” from the Multi-Information Display (MID).
- (2) Press “⏴ ⏵” and “OK” switches to change the setting.
- (3) Press “⏴” to go back to the menu.

Note: The system is enabled each time the power switch is turned to ON mode.

Refer to the Toyota Owner's Manual for additional information on PCS operation, settings adjustments, limitations, and precautions before attempting to use it.

Lane Departure Alert with Steering Assist (LDA w/SA)




LDA in TSS uses an in-vehicle camera designed to detect visible white and yellow lane markers or road edge in front of the vehicle and the vehicle's position on the road. If the system determines that the vehicle is starting to unintentionally deviate from its lane, the system alerts the driver with an audio and visual alert. When the alerts occur, the driver must check the surrounding road situation and carefully operate the steering wheel to move the vehicle back to the center part of their lane.

LDA is designed to function at speeds of approximately 32 mph (50 km/h) or higher on relatively straight roadways.

In addition to the alert function, LDA w/SA also features a steering assist function. When enabled, if the system determines that the vehicle is on a path to unintentionally depart from its lane, the system may provide small corrective steering inputs to the steering wheel for a short period of time to help keep the vehicle in its lane.

If the vehicle repeatedly deviates from the lane, the vehicle drifts within the lane due to inattention, or the driver abruptly operates the steering wheel after an inattentive period, when enabled, the vehicle sway warning function alerts the driver with an audio and visual alert, urging them to take a break.

TURNING THE LDA SYSTEM ON/OFF




Press the LDA switch to turn the LDA system on. Depress again to turn it off.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.

Refer to the Toyota Owner's Manual for additional information on LDA operation, settings adjustments, limitations, and precautions before attempting to use it.

LDA function display



Lane Departure Alert (LDA) indicator flashes orange when operating.



(1)



(2)

The LDA function  displays when the Multi-Information Display (MID) is switched to the driving assist system information screen.

(1) The system displays solid white lines on the LDA indicator when visible lane markers on the road are detected. A side flashes orange to alert the driver when the vehicle deviates from its lane.

(2) The system displays outlines on the LDA indicator when lane markers on the road are not detected or the function is temporarily cancelled.

Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, LDA may not function on the side(s) where white/yellow lines are not detectable.

Refer to the Toyota Owner's Manual for additional information on LDA operation, settings adjustments, limitations, and precautions before attempting to use it.

TOYOTA SAFETY SENSE™

DISABLING STEERING ASSIST

- (1) Press " 
" switches and select "" from the Multi-Information Display (MID).- (2) Press " 
" switches and select the "Steering Assist" setting function and then press "".- (3) Press "
" each time to change the setting.- (4) Press "
" to go back to the menu.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.

ADJUSTING LDA ALERT SENSITIVITY


The driver can adjust the sensitivity of the LDA (warning) function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.

Normal - Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press " 
" switches and select "" from the Multi-Information Display (MID).- (2) Press " 
" switches and select the "Sensitivity" setting function and then press "".- (3) Press "
" each time to change the setting.- (4) Press "
" to go back to the menu.

SWAY WARNING SYSTEM



Continuous lane deviations from swaying.



Gentle swaying from driver's inattentiveness.



Acute steering wheel operation after the number of operations decrease due to driver's inattentiveness.

SWS is a function of LDA and is designed to detect swaying based on the vehicle location in the lane and the driver's steering wheel operation. To help prevent swaying, the system alerts the driver using a buzzer sound and a warning displays in the MID.

DISABLING LDA SWAY WARNING ALERT


- (1) Press “ ” switches and select “” from the Multi-Information Display (MID).
- (2) Press “ ” switches and select the “Sway Warning” setting function and then press “”.
- (3) Press “” each time to change the setting.
- (4) Press “” to go back to the menu.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.

ADJUSTING SWAY ALERT SENSITIVITY


- (1) Press “ ” switches and select “” from the Multi-Information Display (MID).
- (2) Press “ ” switches and select the “Sway Sensitivity” setting function and then press “”.
- (3) Press “” each time to change the setting.
- (4) Press “” to go back to the menu.

Lane Tracing Assist (LTA)



The LTA system is comprised of the lane departure alert function, the steering assist function, the lane centering function, and the vehicle sway warning function. The in-vehicle camera detects the visible white and yellow lane markers in front of the vehicle and the vehicle's position on the road. If the vehicle starts to unintentionally deviate from its lane when the LTA system is on, the lane departure alert function alerts the driver with an audio and visual alert. When the steering assist function is enabled, if the system determines that the vehicle is on a path to unintentionally depart from its lane, the system may provide small corrective steering inputs to the steering wheel for a short period of time to help keep the vehicle in its lane. Additionally, when enabled, the lane centering function will automatically provide assistance to help keep the vehicle in the center of the lane when Full-Speed DRCC is set. If the vehicle repeatedly deviates from the lane, the vehicle drifts within the lane due to inattention, or the driver abruptly operates the steering wheel after an inattentive period, when enabled, the vehicle sway warning function alerts the driver with an audio and visual alert, urging them to take a break.

TURNING THE LTA SYSTEM ON/OFF




Press the LTA switch to turn the LTA system on. Depress again to turn it off.

Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.

Refer to the Toyota Owner's Manual for additional information on LTA operation, settings adjustments, limitations, and precautions before attempting to use it.

LTA function display



Lane Tracing Assist (LTA) indicator flashes orange when operating.



(1)



(2)

The LTA function  displays when the Multi-Information Display (MID) is switched to the driving assist system information screen.

(1) The system displays solid white lines on the LTA indicator when visible lane markers on the road are detected. A side flashes orange to alert the driver when the vehicle deviates from its lane.

(2) The system displays outlines on the LTA indicator when lane markers on the road are not detected or the function is temporarily cancelled.

Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, LTA may not function on the side(s) where white/yellow lines are not detectable.

Refer to the Toyota Owner's Manual for additional information on LTA operation, settings adjustments, limitations, and precautions before attempting to use it.

DISABLING STEERING ASSIST

- (1) Press " 
" switches and select "" from the Multi-Information Display (MID).- (2) Press " 
" switches and select the "Steering Assist" setting function and then press ".- (3) Press "
" each time to change the setting.- (4) Press "
" to go back to the menu.

Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.

ADJUSTING LTA ALERT SENSITIVITY


The driver can adjust the sensitivity of the LTA (warning) function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.

Normal - Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press " 
" switches and select "" from the Multi-Information Display (MID).- (2) Press " 
" switches and select the "Sensitivity" setting function and then press ".- (3) Press "
" each time to change the setting.- (4) Press "
" to go back to the menu.

LANE CENTERING



The lane centering function is linked with Full-Speed Range Dynamic Radar Cruise Control (DRCC) and provides the required assistance by operating the steering wheel to keep the vehicle in its current lane.

When dynamic radar cruise control with full-speed range is not operating, the lane centering function does not operate.


DISABLING LANE CENTERING FUNCTION

- (1) Press “< >” switches and select “⚙️” from the Multi-Information Display (MID).
- (2) Press “↓ ↑” switches and select the “Lane center” setting function and then press “OK.”
- (3) Press “OK” each time to change the setting.
- (4) Press “↩️” to go back to the menu.

Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.


Full-Speed Range Dynamic Radar Cruise Control (DRCC)

DRCC helps maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed. This mode is always selected first when the cruise control button is depressed. Constant speed cruise control mode is also available. Full-Speed Range DRCC is designed to function at speeds between 0 to approximately 110 MPH and is intended for highway use.



TURNING SYSTEM ON/OFF

(1)




Push once: On
Push twice: Off


Refer to page 50 for switching to Constant Speed (Cruise) Control Mode.

ADJUSTING SET SPEED

(2)



(3)




Vehicle will cruise at a set speed, decelerate to maintain selected distance from a slower vehicle traveling in front and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.

- (1) Push “” to turn DRCC system ON.
- (2) Use the steering wheel controls to increase speed by pushing “+RES” or decrease the speed by pushing “-SET”. Push and hold to make a large adjustment or push each time to make fine adjustments (1 mph [1.6 km/h] or 1 km/h [0.6 mph] increments).
- (3) Push “Cancel” to cancel the adjusting speed operation.


¹ The set speed may be resumed once vehicle speed exceeds 25 mph.

² The set speed may also be cancelled by depressing the brake pedal.



This mode employs a radar sensor to detect the presence of a preceding vehicle up to approximately 328 ft (100 m) ahead, determines the current vehicle-to-vehicle following distance and operates to maintain a preset following distance from the vehicle ahead. These distances vary based on vehicle speed.

Note: Vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Constant speed cruising when there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

(2) Deceleration cruising and follow-up cruising when a preceding vehicle driving slower than the set speed appears

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes (the brake lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.


ADJUSTING DISTANCE (CONTINUED)

(3) Acceleration when there are no longer any preceding vehicles driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Note: When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.


SWITCHING TO CONSTANT SPEED (CRUISE) CONTROL MODE



If you are already using DRCC "  ", push ON-OFF button to turn the system off first, then push and hold ON-OFF button for at least 1.5 seconds to switch.

Note: When the engine is turned off, it will automatically default to DRCC.


SETTING CONSTANT SPEED (CRUISE) CONTROL



To adjust speed or cancel, see steps (2) and (3) of ADJUSTING SET SPEED on page 48.

Refer to the Toyota Owner's Manual for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)



AHB is a safety system designed to help drivers see more of what's ahead at nighttime without and reduce glare for oncoming drivers. AHB uses an in-vehicle camera to help detect the headlights of oncoming vehicles and tail lights of preceding vehicles, then automatically switches between high and low beams as appropriate to provide the most light possible and enhance forward visibility. By using high beams more frequently, the system may allow earlier detection of pedestrians and obstacles.

Refer to the *Toyota Owner's Manual* for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

ACTIVATING THE AHB SYSTEM

- (1) Press the “” switch.
- (2) Push lever away from you with the headlight switch is in the “” or “AUTO” position.

The AHB indicator will come on when the headlights are turned on automatically to indicate that the system is active.

Note: Pull the lever back toward you or press the AHB switch to turn the AHB system off.

The AHB indicator will turn off. To turn switch to “” position and the manual high beam indicator “” turns on.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY

When all of these conditions are met, high beams will be automatically turned on (after approximately 1 second):

- Vehicle speed is above approximately 21 mph (34 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- There are few streetlights on the road ahead.


If any of these conditions occur, high beams will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.


Road Sign Assist (RSA)

Road Sign Assist is designed to help ensure drivers are kept informed. The RSA system recognizes specific road signs using a forward-facing intelligent camera to provide information to the driver via a Multi-information Display (MID). If the system judges that the vehicle is being driven over the speed limit, or performing actions prohibited by other support types of road signs. It alerts the driver using a warning display and may sound a warning buzzer.

RSA DISPLAY



When the driving support system information is selected, a maximum of 3 signs can be displayed.



When a tab other than the driving support system information is selected, only a recognized speed limit sign or do not enter sign (when notification is necessary) will be displayed.

SUPPORTED TYPES OF ROAD SIGNS



Speed limit



Stop



Do Not Enter



Yield


SETTING RSA

- (1) Press "**◀ ▶**" switches and select "**⚙**" from the Multi-Information Display (MID).
- (2) Press "**▼ ▲**" switches and select the "Road Sign Assist ON/OFF" setting function and then press "**OK**."
- (3) Press "**OK**" each time to change the setting.
- (4) Press "**↩**" to go back to the menu.

Note: If the engine switch was last turned off while a speed limit sign was displayed on the multi-information display, the same sign displays again when the engine switch is turned to ON.

Refer to the Toyota Owner's Manual for additional information on RSA operation, settings adjustments, limitations, and precautions before attempting to use it.

Seat belts




Keep as low on hips as possible

NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic locking retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the Owner's Manual.


Rear door child safety locks



Moving the lever downward will allow the door to be opened only from the outside.

Seat belts-Shoulder belt anchor


Push up or squeeze lock release to lower



SAFETY & EMERGENCY FEATURES


Spare tire & tools

TOOL LOCATION




REMOVING THE SPARE TIRE

(1)



(2)



- (1) Pull up the tab to raise the deck board and move it toward you to remove, then Place the deck board through the groove and move forward.
- (2) After remove the jack holder, loosen the center fastener that secures the spare tire.

Refer to the Owner's Manual for tire changing and jack positioning procedures.

Tire Pressure Monitoring (warning) System (TPMS)

The tire pressure warning system can be selected on “” of the multi-information display (MID).

System rest initialization

- (1) Select “Vehicles Setting” and then push “”.
- (2) Select “TPWS” and then push “”.
- (3) Select “Set Pressure” then push and hold “” until the message displays on MID and the warning light blinks three times.




The image may differ from the image that is actually displayed on the MID.

Refer to the load label on the door jamb or the Owner's Manual for tire inflation specifications.

If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota dealer.

NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.

Safety Connect[®] (if equipped)



Safety Connect[®] is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect[®] is supported by Toyota's designated response center, which operates 24 hours per day, 7 days per week.

Services for subscribers include:

- Automatic collision notification
- Stolen vehicle location
- Emergency assistance (“SOS” button)
- Enhanced roadside assistance

Contact your dealer for more information about Safety Connect.

For details, refer to the “Owner's Manual” or visit www.toyota.com/safety-connect.

SAFETY & EMERGENCY FEATURES

Star Safety System™

Your vehicle comes standard with the Star Safety System™, which combines Anti-lock Braking System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Vehicle Stability Control (VSC) and Traction Control (TRAC).

Refer to the Owner's Manual for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by "pulsing" each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or "panic" braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

ENHANCED VEHICLE STABILITY CONTROL (VSC)

Enhanced Vehicle Stability Control provides cooperative control of the ABS, TRAC, VSC and EPS.

Enhanced VSC helps to maintain directional stability when loss of traction occurs during a turn.

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).



Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



BLUETOOTH® DEVICE PAIRING SECTION

Do not attempt the Bluetooth® Pairing process while driving.

To begin the Bluetooth® Pairing process, press the HOME button on the faceplate of your multimedia system.

Bluetooth® Pairing for your phone

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy. All you have to do is setup the phone and multimedia system to form a connection.¹




Entune™ 3.0 Audio/Entune™ 3.0 Audio Plus/ Entune™ 3.0 Premium Audio

STEP 1 Press [MENU] on the faceplate, then select "Setup" on display screen.



iPhone bluetooth Menu



Android bluetooth Menu



STEP 3 Select "Bluetooth", then select "Add New Device" on display screen.

STEP 2 Ensure Bluetooth is turned on for your device.



STEP 4 Select "Device Name".



STEP 5 Check the display on your smart phone. Does the PIN XXXX match the PIN displayed? If it does select "Pair".

¹ Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

Bluetooth® Pairing for your phone (cont.)




STEP 6 "Connecting" displays while device is forming the connection to your multimedia system.



STEP 7 Enable Notifications (text message). While pairing your device message will display: **"You may need to allow message access on your phone"**.

Note: You may also select "Skip" on display screen to skip enabling notifications. If skipped proceed to **Step 8**.



STEP 8 Turn on "Show Notifications" for iPhone or "ON" for Android.



STEP 9 A confirmation will appear once your phone has been paired and connected.



www.toyota.com/owners

CUSTOMER EXPERIENCE CENTER

1-800-331-4331



Printed in U.S.A. 11/18
18-MKG-12465



00505QRG19RAV4