

QUICK REFERENCE GUIDE



2022

2022

SEQUOIA

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new Sequoia.

A word about safe vehicle operations

This Quick Reference Guide is not a full description of Sequoia operations. Every Sequoia owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

OVERVIEW

Engine maintenance	11
Fuel tank door release & cap	10
Hood release	10
Indicator symbols	6-7
Instrument cluster	5
Instrument panel	2-4
Instrument panel light control	11
<i>Keyless entry</i> ^{1,2}	8-9
<i>Smart Key system</i> ^{1,2}	9

FEATURES & OPERATIONS

Air conditioning/heating	24-25
Audio	26
<i>Auto lock/unlock</i> ^{1,2}	12
Automatic transmission	12
AVS (Adaptive Variable Suspension System)	31
<i>Blind Spot Monitor with Rear Cross Traffic Alert (BSM w/RCTA)</i> ^{1,2}	33
Clock	29
Cup holders	15
Door locks	16
<i>Driving position memory</i> ¹	23
Electronically modulated air suspension	32
Four-wheel drive system	13
<i>Garage door opener (HomeLink®)</i> ³	30
Heated/ventilated seats	25
Intuitive parking assist	34
<i>Lights</i> ^{1,2} & <i>turn signals</i>	20
<i>Moonroof</i> ¹	23
<i>Multi-Information Display (MID)</i> ^{1,2}	29
Parking brake	15
<i>Power back door</i> ¹	22
<i>Power back door window</i> ¹	22
Power outlets-12V DC	28
Power outlets-120V AC	27
<i>Power windows</i> ¹	21
Rear seat entertainment system	28
Rear view monitor system	34
Seat adjustments-Front	16

FEATURES & OPERATIONS (continued)

Seat adjustments-Rear	17
Seats-Folding 2nd row seats	18
Seats-Folding 3rd row seats	19
Seats-Head restraints	18
Steering lock release	14
Steering wheel switches & telephone controls (Bluetooth®)	27
Tilt & telescopic steering wheel	14
TOW/HAUL switch	30
USB charge ports	26
USB media port	26
Vehicle Stability Control (VSC)/TRAC/Trailer sway control OFF switch	31
<i>Windshield wipers & washers</i> ¹	21

TOYOTA SAFETY SENSE™ P (TSS-P)

Automatic High Beams (AHB)	46
Dynamic Radar	
Cruise Control (DRCC)	43-45
Lane Departure Alert (LDA)	39-42
Pre-Collision System with Pedestrian Detection (PCS w/PD)	36-38
Quick overview-	
Toyota Safety Sense™ P (TSS-P)	35
Sensors	35

SAFETY & EMERGENCY FEATURES

Floor mat installation	51
Rear door child safety locks	48
Safety Connect®	48
Seat belts	47
Seat belts-Shoulder belt anchor	49
Spare tire & tools	49
Star Safety System™	50-51
Tire Pressure Monitoring (warning) System (TPMS)	47

BLUETOOTH® DEVICE PAIRING SECTION


	52-54
--	-------

¹ Visit your Toyota dealer for information on customizing this feature.


² Programmable by customer. Refer to the Owner's Manual for instructions and more information.

³ HomeLink® is a registered trademark of Gentex Corporation.

Instrument panel




Steering wheel controls



¹ If equipped


² For details, refer to the "Navigation and Multimedia System Owner's Manual" or visit www.toyota.com/audio-multimedia for additional resources.



OVERVIEW

Instrument panel (continued)


CENTER PANEL AREA



¹ If equipped

² For details, refer to the "Navigation and Multimedia System Owner's Manual" or visit www.toyota.com/audio-multimedia for additional resources.

Instrument cluster



○ Service indicators and warning lights

OVERVIEW

Indicator symbols

For details, refer to "Warning lights and indicators," Section 2, 2022 Owner's Manual.

- | | |
|--|---|
|  | AIR BAG ON/OFF indicator ¹ |
|  | Airbag SRS warning ¹ |
| ABS | Anti-lock Brake System (ABS) warning ¹ |
| AUTO LSD | AUTO LSD (Limited Slip Differential) indicator ^{1,4} |
|  | Automatic High Beams (AHB) indicator |
| BSM | Blind Spot Monitor (BSM) indicator |
|  | BSM outside rear view mirror indicators |
| RCTA | BSM w/Rear Cross Traffic Alert (RCTA) indicator |
| BRAKE | Brake system warning ¹ |
|  | Center differential lock indicator ⁴ |
|  | Charging system warning ¹ |
|  | Constant speed cruise control/
Dynamic Radar Cruise Control (DRCC) indicator |
| SET | Constant speed cruise control/Dynamic Radar Cruise Control SET indicator |
|  | Driver's and/or front passenger's seat belt reminder ¹ (alarm will sound when the vehicle is on) |
|  | Front fog light indicator |
|  | Fuel tank door position |
|  | Headlight low/
high beam indicator |
| 4 HI | High/Low speed four-wheel drive indicator ⁴ |
| 4 LO | |



Lane Departure Alert (LDA) indicator
[green/yellow³ indicator]



Low fuel level warning



Low outside temperature indicator



Low tire pressure warning¹



Malfunction/
Check Engine indicator¹



Master warning^{1,2}



Parking brake indicator



Pre-Collision System (PCS)
warning¹



Power steering warning¹



Security indicator



Slip indicator^{1,3}



TOW/HAUL indicator



TRAC OFF (Traction Control OFF)
indicator¹



Turn signal indicator



Vehicle Stability Control
(VSC) OFF indicator¹

¹ If the indicator does not turn off within a few seconds of starting the vehicle, there may be a malfunction. Have the vehicle inspected by your Toyota dealer.

² If the indicator flashes, there may be a malfunction. Refer to the Owner's Manual.

³ If the indicator flashes, it indicates that the system is operating.

⁴ If equipped.

OVERVIEW

Keyless entry

UNLOCKING OPERATION




Push

ONCE: Driver door
TWICE: All doors

Carry Smart
Key remote

Driver door unlock*

Grasp



NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

LOCKING OPERATION



Push

Carry Smart
Key remote

All-door lock

Touch



POWER BACK DOOR OPERATION (IF EQUIPPED)



HOLD




Push and hold

POWER BACK DOOR LOCK/UNLOCK



Carry Smart
Key remote



* Driver door unlocking function can be programmed to unlock driver door only, or all doors. Grasping passenger door handle will unlock all doors.

Please refer to the Owner's Manual for more details on how to program the doors.


NOTE: Doors may also be locked/unlocked using the mechanical key.

PANIC BUTTON



Smart Key system


START FUNCTION



NOTE: The Smart Key must be carried to enable the start function. With the shift lever in Park and the brake pedal depressed, push the power button.


POWER (WITHOUT STARTING VEHICLE)

Without depressing the brake pedal, pressing the power button will change the operation mode in succession from:




OVERVIEW

Fuel tank door release & cap



NOTE: To close, tighten until one click is heard. If the cap is not locked or tightened enough, the Check Engine indicator "CHECK" may illuminate.


Hood release




Instrument panel light control

Change brightness level

Short press: 1 step change
Long press: continues change




Engine maintenance



NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the "Warranty & Maintenance Guide."

FEATURES & OPERATIONS

Automatic transmission



* The vehicle must be on and the brake pedal depressed to shift from Park.

"S" (SEQUENTIAL) MODE

Shift the shift lever to "S" position from "D" position.

- + : Upshift (push and release)
- : Downshift (pull and release)

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the "D" position.

Auto lock/unlock

Automatic door locks can be programmed to operate in different modes, or turned OFF.

DEFAULT SETTING

Shift position linked door locking/unlocking function

- Doors lock when shifting from Park.
- Doors unlock when shifting into Park.

CUSTOMIZED SETTING

Speed linked door locking function

- Doors lock when the vehicle speed goes above approximately 12 mph (20 km/h) or higher.


Driver's door linked door unlocking function

- Doors unlock when driver's door is opened within 10 seconds after turning the vehicle to ACC or OFF.

Refer to the Owner's Manual for more details.

Four-wheel drive system (if equipped)

FOUR-WHEEL DRIVE CONTROL SWITCH



2WD

High speed (2WD)

Turn to "2WD" from "4H" with speed below 62 mph (100 km/h).

4H

High speed (4WD)

-Turn to "4H" from "2WD" with speed below 62 mph (100 km/h).

-Shift to "N" position when stopped, then push and turn to "4H" from "4L."

4L


Low speed (4WD)

Shift to "N" position when stopped, then turn to "4L" from "4H."

For best fuel economy and performance under normal driving conditions, keep in "2WD" position.

Refer to the Owner's Manual for more details.

CENTER DIFFERENTIAL LOCK/UNLOCK SWITCH




Lock the center differential if the wheels get stuck in a ditch or when driving on a slippery or bumpy surface.

Refer to the Owner's Manual for more details on this system before attempting to use it.

FEATURES & OPERATIONS


Tilt & telescopic steering wheel

MANUAL



Hold the steering wheel, push the lever down, set angle and length and return the lever.

POWER




Toggle the control switch to set angle and length.

NOTE: Do not attempt to adjust while the vehicle is in motion.

Power easy access system (if equipped): The steering wheel moves in accordance with power button mode and the driver's seat belt condition.

Steering lock release




A message will be displayed on the Multi-Information Display (MID). Check that the shift lever is in P. Press the power button while turning the steering wheel left and right.


Cup holders

FRONT

Front console




Back of the front console




REAR

Rear side trim




Rear console box (if equipped)



Parking brake


PARK



Set: Depress
Release: Depress again


FEATURES & OPERATIONS

Door locks




Seat adjustments-Front

POWER SEAT




MANUAL SEAT




Seat adjustments-Rear

SECOND ROW

Separate seat




Bench seat




THIRD ROW

Manual seat



Power seat




Refer to the Owner's Manual for more details.


FEATURES & OPERATIONS

Seats-Head restraints


Front and second row



Third row (center)




Third row (outside)




Seats-Folding 2nd row seats

(1)



Lower the head restraints.


(2)



Stow the seat belt buckles.


Separated seat

(3)




Fold down the seatback.

Bench seat




Fold down the seatback.

(4)




Fold out the board (if equipped) from the seatback.


Seats-Folding 3rd row seats




Release the center seat belt tab.



Stow the center seat belt tab.



Lower the head restraint.




Stow the seat belt buckles.




Fold the head restraint.

(6) From rear door side

Manual seat




Power seat




Press and hold to fold down fully and buzzer sound.

From back door side

Manual seat



Power seat




Press and hold to fold down fully and buzzer sound.

FEATURES & OPERATIONS

Lights & turn signals

HEADLIGHTS



Daytime Running Light system (DRL) Automatically turns on under certain conditions to make vehicle more visible to other drivers. Not for use at night.

Automatic light cut off system


- Headlights are on: The lights will turn off automatically 30 seconds after the vehicle is turned from ON to ACC or OFF and a door is opened and closed. (If the lock switch on the Smart Key remote is pushed after all doors are closed, the lights will turn off immediately.)
- Only the tail lights are on: The tail lights will turn off automatically if the vehicle is turned from ON to ACC or OFF and the driver's door is opened.

Automatic High Beams (AHB) system Automatically switches between high and low beams as appropriate to enhance vision at night.

Refer to *Toyota Safety Sense™ P (TSS-P)* in this guide or the *Owner's Manual* for more details on the Automatic High Beams feature.



* Operating conditions must be met. Refer to the *Owner's Manual* for details.

FRONT FOG LIGHTS



Front fog lights come on when the parking lights are on or the headlights are on in low beam.

TURN SIGNALS




* Move lever partway and release. The signals will flash three times.



Windshield wipers & washers

FRONT

Type A




Type B




* **Intermittent windshield wiper frequency adjustment** Rotate to increase/decrease wiper frequency.

REAR

Type A




Type B




* The wiper will automatically operate a couple of times after the washer squirts.

Power windows



Window lock switch




Automatic operation (front windows only) Push the switch completely down or pull it completely up and release to fully open or close. To stop window partway, lightly push the switch in the opposite direction.

Window lock switch Deactivates all passenger windows and back window. Driver's window remains operable.

FEATURES & OPERATIONS


Power back door window

OPERATING FROM INSIDE



Automatic operation Push the switch completely in or pull it completely out and release to fully open or close. To stop window partway, lightly push the switch in the opposite direction.


OPERATING FROM OUTSIDE



Push and hold


Power back door (if equipped)

Instrument panel



Open: Push and hold
Close: Push and hold again

Back door (close only)




The power back door can be opened when the vehicle is on and the shift lever is in P/the vehicle is in "ACCESSORY" or "OFF".

NOTE: If battery is disconnected, the power back door needs to be reinitialized. Refer to the Owner's Manual for more details.

Moonroof


SLIDING OPERATION

Push once to open partway.
Push again to open completely.



TILTING OPERATION

Push once to open completely.




Lightly press either side of the moonroof switch while opening/tilting is in progress, the moonroof stops partway.


Driving position memory (if equipped)

DRIVER'S SEAT

To save



To recall



- (1) Adjust driver's seat, steering wheel, and outside rear view mirrors.
- (2) Push "SET" and "1" or "2" buttons to save until buzzer sounds.

- (1) Press "1" or "2" to recall until buzzer sounds.


You can save up to two driving positions to memory and recall it with the touch of a button. Make sure shift lever is in "P" position and power button is in the "ON" position.

Refer to the Owner's Manual for more details on this system.

Air conditioning/heating

FRONT

Display



Control panel


Automatic climate control ON:

Adjusting the temperature setting will cause the airflow mode, air intake and fan to adjust automatically to the set temperature.


"SYNC" button

Indicator ON: Synchronized temperature settings for driver, front passenger and rear seats.

Indicator OFF: Separate temperature settings for driver, front passenger and rear seats.





REAR





Heated/ventilated seats (if equipped)

FRONT SEAT

Heated and Ventilated (if equipped)




Heated only (if equipped)





SECOND SEAT (WITH CONSOLE BOX)

High heat setting



Low heat setting




Push lightly in the opposite direction to turn off.

The vehicle must be on for use.

FEATURES & OPERATIONS


Audio



Refer to the "Navigation and Multimedia System Owner's Manual" or visit www.toyota.com/audio-multimedia for additional resources.


NOTE: Always use safe driving practices and follow all traffic rules.

USB charge ports



The vehicle must be in the "ACCESSORY" or "IGNITION ON" mode for use.

USB media port



Connecting a compatible device and cable into the USB media port will support charging and music playback through the audio multimedia system.

Steering wheel switches & telephone controls (Bluetooth®)

" ^ v "

Use to search within the selected audio feature.

Volume controls

Voice command switch


"MODE/HOLD"

Push to change audio mode. Push and hold to mute or pause the audio.

Start call

End call

Microphone




Bluetooth® technology allows dialing or receipt of calls without removing your hands from the steering wheel.

Refer to the Bluetooth® device pairing in this guide or the Navigation and Multimedia System Owner's Manual for additional user instructions.

NOTE: Always use safe driving practices and follow all traffic rules.

Power outlets-120V AC (if equipped)




The vehicle must be on for use.


FEATURES & OPERATIONS

Power outlets-12V DC


Instrument panel




Inside of the center console box



Back of the center console box (if equipped)



Luggage compartment




The vehicle must be in the "ACCESSORY" or "IGNITION ON" mode for use.

Rear seat entertainment system (if equipped)

Front audio/visual system

DVD player



DVD screen

Remote control


A/V input port

12V AC power outlet

Headphone volume controls and headphone jacks

Refer to the Navigation and Multimedia System Owner's Manual for more details.

Multi-Information Display (MID)




Press meter control switches to change and select information in the following:

-  Drive information
-  Navigation system-linked display (if equipped)
-  Audio system-linked display
-  Vehicle information
-  Warning message display
-  Settings display

Refer to the *Owner's Manual* for more details.

Clock




- 1) Push "**MENU**" button next to the screen.
- 2) Select "**Setup**" or "**General**" in the touchscreen to access the general setting screen.
- 3) Select "**Clock.**"
- 4) Select the desired items to be set.

Refer to the *"Navigation and Multimedia System Owner's Manual"* for more details.

* Available only on Premium Audio

FEATURES & OPERATIONS

Garage door opener (HomeLink®)*



Garage door openers manufactured under license from HomeLink®* can be programmed to operate garage doors, estate gates, security lighting, etc.


Refer to the Owner's Manual for more details.

For programming assistance, contact HomeLink® at 1-800-355-3515, or visit <http://www.homelink.com/toyota>.



* HomeLink® is a registered trademark of Gentex Corporation.


TOW/HAUL switch



"TOW/HAUL" mode can be used when carrying or towing heavy loads. As fuel economy is reduced while in "TOW/HAUL" mode, deactivating when driving without a load is recommended.

Refer to the Owner's Manual for more details on this system before attempting to use it.

Vehicle Stability Control (VSC)/TRAC / Trailer Sway Control OFF switch




The VSC OFF switch can be used to help free a stuck vehicle in surroundings like mud, dirt or snow. While the vehicle is stopped, press switch to disable the TRAC system.

To disable VSC/TRAC/Trailer Sway Control systems, press and hold the switch for at least 3 seconds.

Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

AVS (Adaptive Variable Suspension System) (If equipped)



AVS controls the suspension according to the road and driving conditions. Selecting an optimum driving mode allows good vehicle posture and steering wheel operation.

Sport mode: For winding mountain road driving or high speed driving.

Normal mode: For ordinary driving.

Comfort mode: For driving on a bumpy road.


Refer to the Owner's Manual for limitations and more details on this system.

FEATURES & OPERATIONS


Electronically modulated air suspension (If equipped)

The electronically modulated air suspension allows the driver to control the vehicle's height in order to adjust for driving conditions. Select the desired height with the height control switch.

HEIGHT CONTROL SWITCH



SELECTING VEHICLE HEIGHT



Vehicle height can be adjusted only when the engine is running. The selected height mode will be shown on the electronically modulated air suspension display. The selected mode will flash while the height mode is being changed.


“N” mode (normal mode): For ordinary driving.

“HI” mode (high mode): For driving on bumpy roads 1.2 in. (30 mm) higher than the normal height.

“LO” mode (low mode): For the ease of egress/ingress and loading luggage. -1.2 in. (30 mm) lower than the normal height

Refer to the Owner's Manual for limitations and more details on this system.

Blind Spot Monitor with Rear Cross Traffic Alert (BSM w/RCTA)



The Blind Spot Monitor is a system that has two functions:

- The Blind Spot Monitor function (assists the driver in making the decision when changing lanes)
- The Rear Cross Traffic Alert function (assists the driver when backing up)

The system is designed to use radar sensors to detect vehicles traveling in the Sequoia's blind spot. If a vehicle is detected, the driver will be alerted via the outside rear view side mirror indicators.

Rear Cross Traffic Alert function:

While in reverse, when a vehicle approaching from the right or left rear of the Sequoia is detected, the outside rear view mirror indicators will flash and a buzzer will sound.


SYSTEM ON/OFF

- (1) Press " " switches and select " " from the Multi-Information Display (MID).
- (2) Press " " switches and select "BSM" or "RCTA" then press " ." The setting screen is displayed.
- (3) Press " " switches and select the "On/Off" setting function and then press " ."
- (4) Press " " to go back to the previous screen. Also, use " " to switch menu or display the top screen.

Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

FEATURES & OPERATIONS

Intuitive parking assist




The parking assist sonar system operates when the vehicle approaches an obstacle. The distance from your vehicle to nearby obstacles when parallel parking or maneuvering into a garage is measured by sensors and communicated via the Multi-Information Display (MID) and a buzzer.

When the sensor detects an obstacle, the direction and the approximate distance to the obstacle are displayed on the MID by illuminating continuously (near) or blinking (far), and beeping sounds will switch from intermittent to continuous as you approach and get closer to a detected obstacle. When the sensors detect two or more obstacles, the audible alerts will respond to the nearest zone.

Always check the surrounding area when using this system.

Refer to the Owner's Manual for limitations and more details.

Rear view monitor system



The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is located above the license plate.


To adjust the image on the rear view monitor screen, press the "MENU" button and select "Display." Select "Camera" to adjust the screen contrast and brightness.

Refer to the Owner's Manual for limitations and more details on this system.

Quick overview-Toyota Safety Sense™ P (TSS-P)

Toyota Safety Sense™ P (TSS-P) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS-P is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the Owner's Manual for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to www.toyota.com/safety-sense.



Pre-Collision System with Pedestrian Detection (PCS w/PD)

PCS w/PD is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system detects a potential collision with a preceding vehicle is likely to occur.

The advanced grille-mounted radar system is designed to work with the forward-facing camera to help recognize a preceding pedestrian, and provide an alert, mitigation and/or avoidance support in certain conditions.



Lane Departure Alert (LDA)

LDA is designed to provide notification when the system detects an unintended lane departure.



Dynamic Radar Cruise Control (DRCC)

DRCC is designed to help maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed.




Automatic High Beams (AHB)


AHB is designed to detect the headlights of oncoming vehicles and the tail lights of preceding vehicles and switch between high beams and low beams as appropriate.

Sensors

TSS-P combines a forward-facing camera mounted in front of the inside rear view mirror and a grille-mounted radar mounted in the front grille. These sensors support the driver assist systems.



Pre-Collision System with Pedestrian Detection (PCS w/PD)



The Pre-Collision System with Pedestrian Detection (PCS w/PD) is designed to help detect a vehicle or a pedestrian in certain situations. Using a combination of a camera and radar, PCS w/ PD can provide an audio/visual alert to warn you of a possible collision under certain circumstances. If you don't react, the system is designed to automatically brake.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the pre-collision system yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle or pedestrian may not be detected by the radar and camera sensors, preventing the system from operating or engaging properly.

See toyota.com/safety-sense for more information.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist

If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.

Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.


Suspension Control

When the system determines that the possibility of a frontal collision is high, the Adaptive Variable Suspension System will control the damping force of the shock absorbers to help maintain an appropriate vehicle posture.

Refer to the Toyota Owner's Manual for additional information on PCS w/PD operation, settings adjustments, limitations, and precautions before attempting to use it.

PCS PEDESTRIAN DETECTION


Under certain conditions, the PCS system included with the TSS-P package may also help to detect a pedestrian in front of your vehicle using the forward-facing camera and front grille-mounted radar. The forward-facing camera of PCS detects a potential pedestrian based on size, profile, and motion of the detected pedestrian. However, a pedestrian may not be detected depending on the conditions, including the surrounding brightness and the motion, posture, size, and angle of the potential detected pedestrian, preventing the system from operating or engaging.



As part of the Pre-Collision System, this function is also designed to first provide an alert and then automatic braking if needed.

Refer to the Toyota Owner's Manual for additional limitations and information.


CHANGING PCS ALERT TIMING



- (1) Press "◀▶" switches and select "⚙️" from the Multi-Information Display (MID).
- (2) Press "⏪⏩" switches and select "Meter Settings" and then press "⬢".
- (3) Press "⏪⏩" switches and select "PCS" and then press "⬢". The setting screen is displayed.
- (4) Then select "PCS Sensitivity" and press "⬢" to select the desired setting. Each time it is pressed, the response to the PCS warning timing changes as shown above.
- (5) Press "⏪" to go back to the previous screen. Also, use "⏪⏩" to switch menu or display the top screen.

Note: PCS is enabled each time the vehicle is turned on. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same.)

DISABLING PRE-COLLISION SYSTEM (PCS)




- (1) Press "◀▶" switches and select "⚙️" from the Multi-Information Display (MID).
- (2) Press "⏪⏩" switches and select "Meter Settings" and then press "⬢".
- (3) Press "⏪⏩" switches and select "PCS" and then press "⬢". The setting screen is displayed.
- (4) Then select "PCS" and press "⬢" to select the desired setting (on/off).
- (5) Press "⏪" to go back to the previous screen. Also, use "⏪⏩" to switch menu or display the top screen.

Note: The system is enabled each time the vehicle is turned on.

Refer to the Toyota Owner's Manual for additional information on PCS w/PD operation, settings adjustments, limitations, and precautions before attempting to use it.

Lane Departure Alert (LDA)



By detecting visible white/yellow lane markings at speeds above 32 mph, Lane Departure Alert (LDA) is designed to issue an audio/visual alert if an inadvertent lane departure is detected.

See toyota.com/safety-sense for more information.


Refer to the *Toyota Owner's Manual* for a list of additional situations in which the system operation may be limited.

TURNING THE LDA SYSTEM ON/OFF



Press the LDA switch to turn the LDA system on. Depress again to turn it off.

Note: The system will continue in the last state it was in (ON or OFF) when the vehicle is started again.



Lane Departure Alert (LDA) indicator flashes orange when operating.



The LDA function  displays when the Multi-Information Display (MID) is switched to the driving assist system information screen.

- (1) The system displays solid white lines on the LDA indicator when visible lane markers on the road are detected. A side flashes orange to alert the driver when the vehicle deviates from its lane.
- (2) The system displays outlines on the LDA indicator when lane markers on the road are not detected or the function is temporarily canceled.

Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, LDA may not function on the side(s) where white/yellow lines are not detectable.

ADJUSTING LDA ALERT SENSITIVITY

The driver can adjust the sensitivity of the LDA (warning) function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.

Standard - Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press "" switches and select "" from the Multi-Information Display (MID).
- (2) Press "" switches and select "Meter Settings" and then press ".
- (3) Press "" switches and select "LDA" and then press ".
 The setting screen is displayed.- (4) Then select "LDA Sensitivity" and press "" to select the desired setting.
- (5) Press "" to go back to the previous screen. Also, use "" to switch menu or display the top screen.

SWAY WARNING SYSTEM



Continuous lane deviations from swaying.



Gentle swaying from driver's inattentiveness.



Acute steering wheel operation after the number of operations decrease due to driver's inattentiveness.

SWS is a function of LDA and is designed to detect swaying based on the vehicle location in the lane and the driver's steering wheel operation. To help prevent swaying, the system alerts the driver using a buzzer sound and a warning display on the MID.

DISABLING LDA SWAY WARNING SYSTEM

- (1) Press "◀▶" switches and select "⚙️" from the Multi-Information Display (MID).
- (2) Press "⏴⏵" switches and select "Meter Settings" and then press "⏹️."
- (3) Press "⏴⏵" switches and select "LDA" and then press "⏹️." The setting screen is displayed.
- (4) Then select "Sway Warning" and press "⏹️" to select the desired setting.
- (5) Press "🏠" to go back to the previous screen. Also, use "⏴⏵" to switch menu or display the top screen.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.

ADJUSTING SWAY ALERT SENSITIVITY

- (1) Press "◀▶" switches and select "⚙️" from the Multi-Information Display (MID).
- (2) Press "⏴⏵" switches and select "Meter Settings" and then press "⏹️."
- (3) Press "⏴⏵" switches and select "LDA" and then press "⏹️." The setting screen is displayed.
- (4) Then select "Sway Warning Sensitivity" and press "⏹️" to select the desired setting.
- (5) Press "🏠" to go back to the previous screen. Also, use "⏴⏵" to switch menu or display the top screen.


Refer to the Toyota Owner's Manual for additional information on LDA operation, settings adjustments, limitations, and precautions before attempting to use it.

Dynamic Radar Cruise Control (DRCC)

Intended for highway use, Dynamic Radar Cruise Control (DRCC) lets you drive at a preset speed. DRCC is designed to function at speeds of 25-110 mph and uses vehicle-to-vehicle distance control, helping maintain a preset distance from the vehicle ahead of you.


See toyota.com/safety-sense for more information.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.



TURNING SYSTEM ON/OFF

(1)



Push once: On
Push twice: Off

Refer to page 45 for switching to Constant Speed (Cruise) Control Mode.



ADJUSTING SET SPEED

(2)

Resume²

(3)

Increase speed



Vehicle will cruise at a set speed, decelerate to maintain a selected distance from a slower vehicle traveling in front and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.

(1) Push the ON-OFF button. The "RADAR READY" and "  " indicator will come on.


(2) Push the lever down to set speed, push it up to resume and pull it or depress brake to cancel.

(3) Push up to increase the set speed, push down to decrease (1 mph [1.6 km/h] or 1 km/h [0.6 mph] increments.)

¹ The speed control may also be canceled by depressing the brake pedal.


² The speed control may be resumed once vehicle speed exceeds 25 mph.

ADJUSTING DISTANCE



This mode employs a radar sensor to detect the presence of a preceding vehicle up to approximately 328 ft (100 m) ahead, determines the current vehicle-to-vehicle following distance and operates to maintain a preset following distance from the vehicle ahead. These distances vary based on vehicle speed.

Note: Vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Constant speed cruising when there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control switch.

(2) Deceleration cruising and follow-up cruising when a preceding vehicle driving slower than the set speed appears

When a slower vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system may apply the brakes (the brake lights will come on at this time.) The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.


ADJUSTING DISTANCE (CONTINUED)

(3) Acceleration when there are no longer any preceding vehicles driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Note: When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.

SWITCHING TO CONSTANT SPEED (CRUISE) CONTROL MODE



1.5 seconds

If you are already using DRCC "  ", push ON-OFF button to turn the system off first, then push and hold ON-OFF button for at least 1.5 seconds to switch.

Note: When the engine is turned off, it will automatically default to DRCC.

SETTING CONSTANT SPEED (CRUISE) CONTROL




Set

To adjust speed or cancel, see steps (2) and (3) of ADJUSTING SET SPEED on page 43.

Refer to the Toyota Owner's Manual for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)



The Automatic High Beams (AHB) safety system is designed to help you see more clearly at night. At speeds above 25 mph, AHB can detect the headlights of oncoming vehicles and taillights of preceding vehicles, then automatically toggles between high and low beams accordingly.

See toyota.com/safety-sense for more information.

Refer to the Toyota Owner's Manual for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

ACTIVATING THE AHB SYSTEM

- (1) Push the lever away from you with the headlight switch is in the "AUTO" position.
- (2) Press the "AUTO" switch.

The AHB indicator will come on when the headlights are turned on automatically to indicate that the system is active.

Note: Pull the lever back toward you or press the AHB switch to turn the AHB system off.

The AHB indicator will turn off and "☀️" or "🚫" will turn on. To activate the system again, push the lever away from you or press the "AUTO" switch.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY

When all of the following conditions are met, the high beams will be automatically turned on (after approximately 1 second):


- Vehicle speed is above approximately 21 mph (34 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- There are few street lights on the road ahead.

If any of the following conditions occur, the high beams will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

SAFETY & EMERGENCY FEATURES

Tire Pressure Monitoring (warning) System (TPMS)



System reset initialization

1. Push and hold “” SET” button until the indicator blinks three times.
2. Wait a few minutes to allow initialization to complete.



After adjusting tire pressures, or after tires have been rotated or replaced, turn the ignition switch to “ON” and press and hold the “” SET” button until indicator blinks three times. Let the vehicle sit for a few minutes to allow initialization to complete.

If the tire pressure indicator flashes for 1 minute and then remains on, take the vehicle to your local Toyota dealer.

Refer to the load label on the door jamb or the Owner's Manual for tire inflation specifications.

NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.

Seat belts




NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic locking retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the Owner's Manual.

SAFETY & EMERGENCY FEATURES


Rear door child safety locks

Rear door



Moving the lever downward will allow the door to be opened only from the outside.

Safety Connect®



Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is staffed with live agents at the Toyota response center, which operates 24 hours per day, 7 days per week.


Services for subscribers include:

- Automatic collision notification
- Stolen vehicle locator
- Emergency assistance ("SOS" button)
- Enhanced roadside assistance

For limitations and additional information, refer to the "Owner's Manual" or visit www.toyota.com/connected-services.


Seat belts-Shoulder belt anchor

Push up, or squeeze
lock release to lower





Spare tire & tools


TOOL LOCATION



REMOVING THE SPARE TIRE

- 

Assemble the jack handle.
- 

Remove the cover.
- 

Insert the jack handle extension into the lowering screw and turn it counterclockwise. Lower the spare tire completely to the ground.

Refer to the Owner's Manual for tire changing and jack positioning procedures.

SAFETY & EMERGENCY FEATURES

Star Safety System™

Your vehicle comes standard with the Star Safety System™, which combines Anti-lock Braking System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Traction Control (TRAC) and Vehicle Stability Control (VSC).

Refer to the Owner's Manual for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota's Anti-lock Brake System detects which wheels are locking up and limits wheel lockup by "pulsing" each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or "panic" braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

VEHICLE STABILITY CONTROL (VSC)

VSC helps prevent loss of traction during cornering by reducing engine power and applying brake force to selected wheels.

Toyota's VSC monitors steering angle and the direction your vehicle is traveling. When it senses that the front or rear wheels begin to lose traction, VSC reduces engine power and applies braking to selected wheels. This helps restore traction and vehicle control.

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).


Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Only use one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



BLUETOOTH® DEVICE PAIRING SECTION

Do not attempt the Bluetooth® Pairing process while driving.

To begin the Bluetooth® Pairing process, press the HOME button.

Bluetooth® Pairing for your phone

Pairing your phone is the first step in connecting with your Toyota. This pairing process is quick and easy. All you have to do is setup the phone and multimedia system to form a connection.




Audio / Audio Plus / Premium Audio

STEP 1 Press [MENU], then select "Setup" on display screen.



iPhone bluetooth Menu



Android bluetooth Menu¹



STEP 3 Select "Bluetooth," then select "Add New Device" on display screen.

STEP 2 Ensure Bluetooth is turned on for your phone.



STEP 4 Select "Phone Name."



STEP 5 Check the display on your phone. Does the PIN XXXX match the PIN displayed? If it does, select "Pair."

¹ Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

Bluetooth® Pairing for your phone (cont.)




STEP 6 "Connecting" displays while phone is forming the connection to the multimedia system.



STEP 7 Enable Notifications (text message.) While pairing your phone, a message will be displayed: **"You may need to allow message access on your phone."**

Note: You may also select "Skip" on display screen to skip enabling notifications. If skipped, proceed to **Step 8**.



STEP 8 Turn on "Show Notifications" for iPhone or "ON" for Android.



STEP 9 A confirmation will appear once your phone has been paired and connected.

NOTES

NOTES



SEQUOIA

Quick Reference Guide 2022



00505QRG22SEQ



Printed in U.S.A. 6/21
21-MKG-15672

toyota.com