

QUICK REFERENCE GUIDE



C-HR

2022

2022

C-HR

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new C-HR.

A word about safe vehicle operations

This Quick Reference Guide is not a full description of C-HR operations. Every C-HR owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

OVERVIEW

Engine maintenance	9
Fuel tank door release & cap	8
Hood release	8
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
Instrument panel light control	9
Keyless entry ^{1,2}	6
Smart Key system ^{1,2}	7

FEATURES & OPERATIONS

Air conditioning/heating ^{1,2}	18
Audio	20
Auxiliary storage	17
Blind Spot Monitor (BSM) ² and Rear Cross Traffic Alert (RCTA) ²	22
Clock	19
Continuously variable transmission	10
Cup holders	17
Door locks	16
Driving mode select	10
Electric parking brake	11
Front seats-Adjustments	14
Heated seats	19
Lights ¹ & turn signals ¹	12-13
Multi-Information Display (MID) ²	15
Power outlet-12V DC	20
Power windows ¹	17
Rear seats-Folding	14
Rear view monitor system	23
Seats-Head restraints	14
Steering lock release	16
Steering wheel switches & telephone controls (Bluetooth®)	21
Tilt & telescopic steering wheel	16
USB media port	21
Vehicle Stability Control (VSC)/TRAC OFF switch	23
Windshield wipers & washers	13

TOYOTA SAFETY SENSE™ 2.5 (TSS 2.5)

Automatic High Beams (AHB)	37
Full-Speed Range Dynamic Radar	
Cruise Control (DRCC)	34-36
Lane Tracing Assist (LTA) System	28-33
Pre-Collision System with Pedestrian Detection (PCS w/PD)	25-27
Quick overview-Toyota Safety Sense™ 2.5 (TSS 2.5)	24
Road Sign Assist (RSA)	38
Sensors	25

SAFETY & EMERGENCY FEATURES

Floor mat installation	44
Rear door child safety locks	39
Safety Connect®	41
Seat belts	39
Seat belts-Shoulder belt anchor	39
Spare tire & tools	42
Star Safety System™	43-44
Tire Pressure Monitoring (warning) System (TPMS)	40



BLUETOOTH® DEVICE PAIRING SECTION

46-48

¹ Visit your Toyota dealer for information on customizing this feature.


² Programmable by customer. Refer to the Owner's Manual for instructions and more information.

Instrument panel




¹ If equipped.

² For details, refer to the “Multimedia Owner’s Manual” or visit www.toyota.com/audio-multimedia for additional resources.



Instrument cluster



Indicator symbols

For details, refer to “Warning lights and indicators,” Section 2, 2022 Owner’s Manual.

	“AIRBAG ON/OFF” indicator ¹		Brake system warning [red] ¹
	AIRBAG SRS warning ¹		Brake system warning [yellow] ¹
	ABS (Anti-lock Brake System) warning ¹		Charging system warning
	AHB (Automatic High Beams) indicator		Constant speed cruise control/ Full-Speed Range Dynamic Radar Cruise Control (DRCC) indicator
	BSM (Blind Spot Monitor) OFF indicator ^{1,4}		Constant speed cruise control/ Full-Speed Range DRCC SET indicator
	BSM outside rear view mirror indicators ^{1,4}		Driver’s and front passenger’s seat belt reminder (alarm will sound when the vehicle is on)
	Brake hold operating indicator ^{1,2,3}		ECO MODE indicator
	Brake hold standby indicator ¹		Eco Driving Indicator
	Brake Override System/ Drive-Start Control		Electric power steering system warning [red/yellow] ¹

	Front fog light indicator ⁴
	Fuel tank door position
	Headlight low/high beam indicators
	High engine coolant temperature warning
	LTA (Lane Tracing Assist) indicator [white/green/orange ³]
	Low engine oil pressure warning
	Low fuel level warning
	Low outside temperature indicator
	Low tire pressure warning ¹
	Malfunction/Check Engine indicator ¹
	Parking brake indicator ²
	PCS (Pre-Collision System) warning ^{1,2}
	“RCTA (Rear Cross Traffic Alert) OFF” indicator ^{2,4}
	Rear passengers' seat belt reminder
	Security indicator
	Slip indicator ^{1,3}
	Smart Key system ⁴
	SPORT mode indicator
	Turn signal indicator
	VSC (Vehicle Stability Control) OFF indicator ¹

¹ If the indicator does not turn off within a few seconds of starting the engine, there may be a malfunction. Have the vehicle inspected by your Toyota dealer.

² If the indicator flashes, there may be a malfunction. Refer to the Owner's Manual.

³ If the indicator flashes, it indicates that the system is operating.

⁴ If equipped.

OVERVIEW

Keyless entry

UNLOCKING OPERATION




Push

ONCE: Driver door
TWICE: All doors

Carry Smart
Key remote

Driver door unlock*

Grasp



NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

LOCKING OPERATION



Push

Carry Smart
Key remote

All-door lock

Touch



PANIC BUTTON



HOLD



Push and hold



BACK DOOR LOCKING/UNLOCKING



Carry Smart
Key remote




* Driver door unlocking function can be programmed to unlock driver door only, or all doors. In some models, grasping front passenger door handle will unlock all doors.

Please refer to the Owner's Manual for more details on how to program the doors.

NOTE: Doors may also be locked/unlocked using the mechanical key.

Smart Key system (if equipped)


START FUNCTION






NOTE: The Smart Key must be carried to enable the start function. With the shift lever in Park and the brake pedal depressed, push the power button.

POWER (WITHOUT STARTING VEHICLE)

Without depressing the brake pedal, pressing the power button will change the operation mode in succession from:






Fuel tank door release & cap




NOTE: Tighten until one click is heard. If the cap is not locked or tightened enough, the Check Engine indicator  may illuminate.


Hood release



Instrument panel light control




Engine maintenance



NOTE: Regularly scheduled maintenance at your Toyota dealer, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the *“Warranty & Maintenance Guide.”*

Continuously variable transmission



* The vehicle must be on and the brake pedal depressed to shift from Park.

7-SPEED SPORT SEQUENTIAL SHIFTMATIC MODE (M POSITION)

Shift the shift lever to "M" position from "D" position.

- + : Upshifting (push and release)
- : Downshifting (pull and release)

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the "D" position.

Refer to the Owner's Manual for more details.

Driving mode select

Use the the steering wheel MID control switches to operate the MID.

"**NORMAL**" - Suitable for city driving.

"**SPORT**" - Suitable for roads with many curves needing improved driving response.

"**ECO**" - Suitable for improved fuel economy and energy saving controlled air/heating.


- (1) Press MID control switches "<>" and select  from the Multi-information display (MID).
- (2) Press  switches and select "Drive Mode."
- (3) Select a driving mode.

The "SPORT" and "ECO" indicators display on the Multi-Information Display (MID).


Electric parking brake

PARKING BRAKE

Automatic mode



Manual mode



Automatic mode

To turn automatic mode ON, while vehicle is stopped, pull and hold the switch until “EPB Shift Interlock Function Activated” displays on the Multi-Information Display (MID). While depressing the brake pedal, shifting into P position will automatically set the brake and turn the parking brake indicator and parking brake lamp on. To release brake, depress the brake pedal and shift out of P. The indicator and the lamp will turn off.


To turn automatic mode OFF, press and hold the parking brake switch until “EPB Shift Interlock Function Deactivated” displays on the MID.

Manual mode

While the vehicle is stopped and the brake pedal is depressed, pull the switch to set the parking brake and turn the parking brake indicator and parking brake lamp on. To release, press the brake pedal and press the switch. The indicator and the lamp will turn off.

Refer to the Owner's Manual for limitations and more details.

BRAKE HOLD




The brake hold system keeps the brake applied when the shift lever is in any position other than P or R while the system is on and the brake pedal has been depressed to stop the vehicle (yellow indicator light.) The system releases the brake when the accelerator pedal is depressed with the shift lever in any position other than P, R or N to allow smooth start off (green indicator light.)

Refer to the Owner's Manual for limitations and more details.

FEATURES & OPERATIONS

Lights & turn signals

HEADLIGHTS



Daytime Running Light system (DRL) Automatically turns on under certain conditions to make vehicle more visible to other drivers. Not for use at night.

Automatic light cut off system

- Headlights are on: The lights will turn off automatically 30 seconds after the vehicle is turned from ON to ACC or Lock**/ON to ACCESSORY or OFF*** and a door is opened and closed. (If the lock switch on the Smart Key remote is pressed after all doors are closed, the lights will turn off immediately.)
- Only the taillights are on: The taillights will turn off automatically if the vehicle is turned from ON to ACC or LOCK**/ON to ACCESSORY or OFF*** and the driver's door is opened.

Automatic High Beams (AHB) system Automatically switches between high and low beams as appropriate to enhance vision at night.


Refer to *Toyota Safety Sense™ 2.5 (TSS 2.5)* in this guide or the *Owner's Manual* for more details on the Automatic High Beams feature.

* Operating conditions must be met. Refer to the Owner's Manual for details.

** Vehicle equipped without a Smart Key system.



*** Vehicle equipped with a Smart Key system.

FRONT FOG LIGHTS (IF EQUIPPED)



Front fog lights come on only when the headlights are on.


TURN SIGNALS



* Move the lever partway and release. The signal will flash three times.


Windshield wipers & washers

WITH INTERMITTENT WIPER



* **Intermittent windshield wiper frequency adjustment**
Rotate to increase/decrease wiper frequency.

REAR




Refer to the Owner's Manual for more information.


FEATURES & OPERATIONS

Front seats-Adjustments



MANUAL SEAT






POWER SEAT (DRIVER SIDE ONLY)



Rear seats-Folding



Seats-Head restraints




Multi-Information Display (MID)

Multi-Information Display (MID)



MID control switches



Press MID control switches to change and select information in the following:



Drive information



Audio system-linked display



Driving assist system information



Warning message display




Settings display

Refer to the Owner's Manual for more settings and customizable features.


Steering lock release

Without Smart Key system




When starting the engine, the engine switch may seem stuck in the "LOCK" position. To free it, turn the key while turning the steering wheel slightly left and right.

With Smart Key system



"Push ENGINE Switch while Turning The Steering Wheel in Either Direction." will be displayed on the Multi-Information Display (MID). Check that the shift lever is set in P. Press the power button while turning the steering wheel left and right.


Tilt & telescopic steering wheel




Hold the steering wheel, push the lever down, set angle and length, and return the lever.

NOTE: Do not attempt to adjust while the vehicle is in motion.

Door locks




Cup holders




Adjust size

Change depth




Auxiliary storage

Console box




Luggage compartment auxiliary boxes




Power windows

Driver side



Window lock switch



All window auto up/down

Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.

Window lock switch

Deactivates all passenger windows. Driver's window remains operable.


Air conditioning/heating

Automatic climate control ON

Adjusting the temperature setting will cause the airflow vents, air intake and fan to adjust automatically to the set temperature.

Airflow vent


In "🌀" or "🌀" mode, use outside air ("👉" indicator OFF) to reduce window fogging.



* Defoggers automatically turn off after a period of time.

** Air conditioning feature that helps lower fuel consumption by controlling and prioritizing functions like reducing fan speed, etc.

Heated seats (if equipped)



The vehicle must be on for use.

Clock

Select to change the time zone.

Select to set daylight saving time ON/OFF.

Select to set automatic adjustment of the clock by GPS on/off. When set to off, the clock can be manually adjusted.


Select to set the 24 hour time format on/off.



- 1) Push "**MENU**" button next to the screen.
- 2) Select "**Setup**" or "**General**" on the touchscreen to access the general setting screen.
- 3) Select "**Clock.**"
- 4) Select the desired items to be set.

Refer to the "Multimedia Owner's Manual" for more details.


Audio



Refer to the "Multimedia Owner's Manual" or visit www.toyota.com/audio-multimedia for additional resources.


NOTE: Always use safe driving practices and follow all traffic rules.

Power outlet-12V DC



The vehicle must be in the "ACC" or "ON" position (without Smart Key) / "ACCESSORY" or "IGNITION ON" mode (with Smart Key) for use.

Steering wheel switches & telephone controls (Bluetooth®)




Bluetooth® technology allows dialing or receipt of calls without removing your hands from the steering wheel.

Refer to the Bluetooth® device pairing in this guide or the Multimedia Owner's Manual for additional user instructions.

NOTE: Always use safe driving practices and follow all traffic rules.

USB media port



Connecting a compatible device and cable into the USB media port will support charging and music playback through the audio multimedia system.


FEATURES & OPERATIONS

Blind Spot Monitor (BSM)* and Rear Cross Traffic Alert (RCTA)*

* If equipped

Outside rear view mirror indicator

Outside rear view mirror indicator



** RCTA only

BLIND SPOT MONITOR (BSM)

The system is designed to use radar sensors to detect vehicles traveling in the C-HR's blind spot. If a vehicle is detected, the driver will be alerted via the outside rear view side mirror indicators.

REAR CROSS TRAFFIC ALERT (RCTA)


While in reverse, when a vehicle approaching from the right or left rear of the C-HR is detected, the outside rear view mirror indicators will flash and the RCTA buzzer will sound.

SYSTEM ON/OFF

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
 - (2) Press “” switches and select “” and then press “.
 The setting screen is displayed. - (3) Press “” switches and select the “BSM on/off” or “RCTA on/off” and then press “.
- (4) Press “.

Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

Rear view monitor system




The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is located above the license plate.

To adjust the image on the rear view monitor screen, press the “MENU” button and select “Display.” Select “Camera” to adjust the screen contrast and brightness.

Refer to the Multimedia Owner’s Manual for limitations and more details on this system.

Vehicle Stability Control (VSC)/ TRAC OFF switch



The VSC OFF switch can be used to help free a stuck vehicle in surroundings like mud, dirt or snow. While the vehicle is stopped, press the switch to disable the TRAC system.

To disable both VSC and TRAC systems, press and hold the switch for at least 3 seconds.

Refer to the Owner’s Manual for limitations and more details.

Quick overview-Toyota Safety Sense™ 2.5

Toyota Safety Sense™ 2.5 (TSS 2.5) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS 2.5 is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the Owner's Manual for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to www.toyota.com/safety-sense.



Pre-Collision System with Pedestrian Detection (PCS w/PD)

PCS w/PD is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system detects a potential collision with a preceding vehicle is likely to occur.

The advanced grille-mounted radar system is designed to work with the forward-facing camera to help recognize a preceding pedestrian or bicyclist, and provide an alert, mitigation and/or avoidance support in certain conditions.



Lane Tracing Assist (LTA) System

While driving on a road with clear white (yellow) lane lines, the LTA system warns the driver if the vehicle may deviate from the current lane or course, and also can slightly operate the steering wheel to help avoid deviation from the lane or course. Also, while the dynamic radar cruise control with full-speed range is operating, this system will operate the steering wheel to help maintain the vehicle's lane position.

Functions included in the LTA system are Lane Departure Alert with Steering Assist, Vehicle Sway Warning and Lane Centering.



Full-Speed Range Dynamic Radar Cruise Control (DRCC)

Full-Speed Range DRCC is designed to help maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed. The minimum set speed is approximately 20 MPH, but once activated, the operating speed range is 0-110 MPH.



Automatic High Beams (AHB)

AHB is designed to detect the headlights of oncoming vehicles and the taillights of preceding vehicles and switch between high beams and low beams as appropriate.




Road Sign Assist (RSA)


RSA is designed to recognize specific road signs using the forward-facing camera to provide information to the driver via the display.

Sensors

TSS 2.5 combines a forward-facing camera mounted in front of the inside rear view mirror and a grille-mounted radar mounted in the front grille. These sensors support the driver assist systems.



Pre-Collision System with Pedestrian Detection (PCS w/PD)



The Pre-Collision System with Pedestrian Detection (PCS w/PD) is designed to help detect a vehicle, a bicyclist, or a pedestrian in certain situations. Using both a camera and radar, PCS w/ PD can provide an audio/visual alert to warn you of a possible collision under certain circumstances. If you don't react, the system is designed to automatically brake.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the Pre-Collision System yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle or pedestrian or bicyclist may not be detected by the radar and camera sensors, preventing the system from operating or engaging properly.

See www.toyota.com/safety-sense for more information.

PRE-COLLISION SYSTEM (CONTINUED)

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist


If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.

Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.

PCS PEDESTRIAN DETECTION


Under certain conditions, the PCS included with the TSS 2.5 package may also help to detect a pedestrian or bicyclist in front of your vehicle using the forward-facing camera and the front grille-mounted radar. The forward-facing camera of PCS detects a potential pedestrian or bicyclist based on size, profile, and motion of the detected pedestrian or bicyclist. However, a pedestrian or bicyclist may not be detected depending on the conditions, including the surrounding brightness and the motion, posture, size, and angle of the potential detected pedestrian or bicyclist, preventing the system from operating or engaging.



As part of the Pre-Collision System, this function is also designed to first provide an alert and then automatic braking if needed.

Refer to the Toyota Owner's Manual for additional limitations and information.


CHANGING PCS ALERT TIMING



- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “<” switches and select “ PCS” and then press and hold “.
 The setting screen is displayed.- (3) Press “<” switches and select “Sensitivity” and then press “” to change the desired setting. Each time it is pressed, the PCS alert timing changes as shown above.
- (4) Press “” to go back to the menu.

Note: PCS is enabled each time the vehicle is turned on. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same.)

DISABLING PRE-COLLISION SYSTEM (PCS)




- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “<” switches and select “ PCS” and then press “” to turn PCS on or off.
- (3) Press “” to go back to the menu.

Note: The system is enabled each time the vehicle is turned on.

Refer to the Toyota Owner's Manual for additional information on PCS w/PD operation, settings adjustments, limitations, and precautions before attempting to use it.

Lane Tracing Assist (LTA) System



While driving on a road with clear white (yellow) lane lines, the LTA system warns the driver if the vehicle may deviate from the current lane or course, and also can slightly operate the steering wheel to help avoid deviation from the lane or course. Also, while the dynamic radar cruise control with full-speed range is operating, this system will operate the steering wheel to help maintain the vehicle's lane position. The LTA system recognizes white (yellow) lane lines or a course using the front camera. Additionally, it detects preceding vehicles using the front camera and radar.


Functions included in the LTA system are Lane Departure Alert with Steering Assist, Vehicle Sway Warning and Lane Centering.

Refer to the Toyota Owner's Manual for additional information on the LTA system operation, settings adjustments, limitations, and precautions before attempting to use it.

TURNING THE LTA SYSTEM ON/OFF


Press and hold the LTA switch to turn the LTA system OFF.

Press the LTA switch again to turn it on.



Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset. The LTA indicator is illuminated when the LTA system is on.


Press and hold the LTA switch to deactivate Lane Departure Alert with Steering Assist.



By detecting visible white/yellow lane markings or the road's edge at speeds above 32 mph, Lane Departure Alert with Steering Assist is designed to issue a visual alert and audio or steering vibration alert if an inadvertent lane departure is detected. If the driver does not take corrective action, the Steering Assist function is designed to provide gentle corrective steering.*

* See www.toyota.com/safety-sense for more information.

LTA system display



The LTA indicator is illuminated when lane departure alert is active. The LTA indicator and lane markers flash orange when operating.

LANE DEPARTURE ALERT WITH STEERING ASSIST (CONTINUED)



The LTA system  is displayed when the Multi-Information Display (MID) is switched to the driving assist system information display.

- (1) The system displays solid white lines on the Lane Departure Alert indicator when visible lane markers or the road are detected. A lane marker flashes orange to alert the driver when the vehicle deviates from its lane.
- (2) The system displays outlines on the Lane Departure Alert indicator when lane markers or the road are not detected or the function is temporarily canceled.

Note: When operational conditions are no longer met, the function may be temporarily canceled. However, when the operational conditions are met again, operation of the function is automatically restored. For example, Lane Departure Alert may not function on the side(s) where white/yellow lines are not detectable.

ADJUSTING LANE DEPARTURE ALERT SENSITIVITY

The driver can adjust the sensitivity of the Lane Departure Alert function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.

Standard - Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “◇” switches and select  LTA and then press and hold “.” The setting screen is displayed.
- (3) Press “◇” switches and select “Sensitivity” and then press “” to change the desired setting.
- (4) Press “” to go back to the menu.

SWAY WARNING SYSTEM



Continuous lane deviations from swaying.



Gentle swaying from driver's inattentiveness.



Acute steering wheel operation after the number of operations decrease due to driver's inattentiveness.

Sway warning is a function of the LTA system and is designed to detect swaying based on the vehicle location in the lane and the driver's steering wheel operation. To help prevent swaying, the system alerts the driver using a buzzer sound and a warning display on the MID.

DISABLING SWAY WARNING SYSTEM

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ LTA” and then press and hold “”. The setting screen is displayed.
- (3) Press “” switches and select “Sway Warning” and then press “” to change the desired setting.
- (4) Press “” to go back to the menu.

ADJUSTING SWAY ALERT SENSITIVITY

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ LTA” and then press and hold “”. The setting screen is displayed.
- (3) Press “” switches and select “Sway Sensitivity” and then press “” to change the desired setting.
- (4) Press “” to go back to the menu.

Note: Operation of the the LTA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.


Refer to the Toyota Owner's Manual for additional information on the LTA system operation, settings adjustments, limitations, and precautions before attempting to use it.

LANE CENTERING


Lane Centering is a function of the LTA system. Turning the LTA system off will deactivate Lane Centering.

Press and hold the LTA switch to turn the LTA system OFF.

Press the LTA switch again to turn it on and to activate/deactivate Lane Centering.




LTA system display



The lane centering function is linked with Full-Speed Range Dynamic Radar Cruise Control (DRCC) and provides the required assistance by operating the steering wheel to help keep the vehicle in its current lane.

When Full-Speed Range Dynamic Radar Cruise Control (DRCC) is not operating, the lane centering function does not operate.

See www.toyota.com/safety-sense for more information.



DISABLING LANE CENTERING FUNCTION

- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<>” switches and select  LTA” and then press and hold . The setting screen is displayed.
- (3) Press “<>” switches and select “Lane Center” and then press  to change the desired setting.
- (4) Press  to go back to the menu.

Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.


Refer to the Toyota Owner's Manual for additional information on the LTA system operation, settings adjustments, limitations, and precautions before attempting to use it.

Full-Speed Range Dynamic Radar Cruise Control (DRCC)

Intended for highway use, Full-Speed Range Dynamic Radar Cruise Control (DRCC) lets you drive at a preset speed. The system is designed to function between 0-110 mph* and uses vehicle-to-vehicle distance control, helping maintain a preset distance from the vehicle ahead of you.*


* See www.toyota.com/safety-sense for more information.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system operation may be limited.



TURNING SYSTEM ON/OFF


(1)




Press the cruise control main switch to turn DRCC on.
Press it again to turn it off.

Refer to page 36 for switching to Constant Speed (Cruise) Control Mode.

ADJUSTING SET SPEED



(3)




SET

Vehicle will cruise at a set speed, decelerate to maintain selected distance from a slower vehicle traveling in front and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.

- (1) Push the ON-OFF button. The "RADAR READY" and  indicator will come on.
- (2) Push the lever down to SET speed, push it up to resume and pull it or depress brake to cancel the speed control.
- (3) Push up to increase the set speed, push down to decrease (1 mph [1.6 km/h] or 1 km/h [0.6 mph]).

* The speed control may also be canceled by depressing the brake pedal.

ADJUSTING DISTANCE




To change the vehicle-to-vehicle distance:

Push the “” switch to cycle through the settings, which will change progressively.

This mode employs a radar sensor to detect the presence of vehicles up to approximately 328 ft (100 m) ahead, determines the current vehicle-to-vehicle following distance and operates to maintain a preset following distance from the vehicle ahead. These distances vary based on vehicle speed.

Note: Vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Constant speed cruising when there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control..

(2) Deceleration cruising and follow-up cruising when a preceding vehicle driving slower than the set speed appears

When a slower vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system may apply the brakes (the brake lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.


ADJUSTING DISTANCE (CONTINUED)

(3) Acceleration when there are no longer any preceding vehicles driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Note: When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.

SWITCHING TO CONSTANT SPEED (CRUISE) CONTROL MODE




1.5 seconds

If you are already using DRCC “”, push the ON-OFF button to turn the system off first, then push and hold the ON-OFF button for at least 1.5 seconds to switch.

Note: When the engine is turned off, it will automatically default to DRCC.

SETTING CONSTANT SPEED (CRUISE) CONTROL




Set

To adjust speed or cancel, see steps (2) and (3) of ADJUSTING SET SPEED on page 34.

Refer to the Toyota Owner's Manual for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)



The Automatic High Beams (AHB) safety system is designed to help you see more clearly at night. At speeds above 25 mph, AHB can detect the headlights of oncoming vehicles and taillights of preceding vehicles, then automatically toggles between high and low beams accordingly.

See www.toyota.com/safety-sense for more information.

Refer to the Toyota Owner's Manual for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

ACTIVATING THE AHB SYSTEM

- (1) Push the lever away from you with the headlight switch is in the “ ” or “AUTO” position.
- (2) Press the “ ” switch.

The AHB indicator will come on when the headlights are turned on automatically to indicate that the system is active.

Note: Pull the lever back toward you or press the AHB switch to turn the AHB system off.

The AHB indicator will turn off and “ ” or “ ” will turn on. To activate the system again, push the lever away from you or press the “ ” switch.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY

When all of the following conditions are met, the high beams will be automatically turned on (after approximately 1 second):

- The vehicle speed is above approximately 21 mph (34 km/h) or more.
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or taillights turned on.
- There are few streetlights on the road ahead.

If any of the following conditions occur, the high beams will be automatically turned off:

- The vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or taillights turned on.
- There are many streetlights on the road ahead.


Road Sign Assist (RSA)

Using an intelligent camera, Road Sign Assist (RSA) is designed to detect speed limit signs, stop signs, do not enter signs and yield signs, and display them on the Multi-Information Display (MID).*


* All vehicle actions must be driver-initiated and are not automated.

Refer to the Toyota Owner's Manual for additional information and limitations.

RSA DISPLAY



When the driving assist system information is selected, a maximum of 3 signs can be displayed.



When a tab other than the driving support system information is selected, the following types of road signs will be displayed.

- Speed limit sign
- Do Not Enter sign (when notification is necessary)

SUPPORTED TYPES OF ROAD SIGNS



Speed limit



Stop



Do Not Enter



Yield


SETTING RSA

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ RSA” and then press “” to turn RSA on or off.
- (3) Press “” to go back to the menu.

Note: If the vehicle was last turned off while a speed limit sign was displayed on the Multi-Information Display (MID), the same sign displays again when the vehicle is turned back on.

Refer to the Toyota Owner's Manual for additional information on RSA operation, settings adjustments, limitations, and precautions before attempting to use it.


Seat belts



NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic locking retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.


To find more information about seat belts, and how to install a child restraint system, refer to the Toyota Owner's Manual.

Seat belts-Shoulder belt anchor



Rear door child safety locks

Rear door



Moving the lever downward will allow the door to be opened only from the outside.

Tire Pressure Monitoring (warning) System (TPMS)



The tire pressure warning system can be selected on  of the Multi-Information Display (MID).

System reset initialization

- (1) Press “<>” switches and select  from from the Multi-Information Display (MID).
- (2) Press “” switches and select the “Vehicle Settings” and then press “.
- (3) Press “” switches and select “ Setup” and then press “.
- (4) Press “” switches and select “SET” and then press and hold “.


A message will be displayed on the MID and the tire pressure indicator will blink three times.

The tire pressure detected by the tire pressure warning system can be displayed on the Multi-Information Display (MID).

If the tire pressure indicator flashes for 1 minute and then remains on, take the vehicle to your local Toyota dealer.

Refer to the load label on the door jamb or the Owner's Manual for tire inflation specifications.

NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.



Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is staffed with live agents at the Toyota response center, which operates 24 hours per day, 7 days per week.


Services for subscribers include:

- Automatic collision notification
- Stolen vehicle locator
- Emergency assistance ("SOS" button)
- Enhanced roadside assistance

For limitations and additional information, refer to the "Owner's Manual" or visit www.toyota.com/connected-services.


Spare tire & tools

TOOL LOCATION




REMOVE THE SPARE TIRE


Remove the deck board and cushion.



Loosen the center fastener that secures the spare tire.



Take out the jack.



Refer to the *Toyota Owner's Manual* for tire changing and jack positioning procedures.

Star Safety System™

Your vehicle comes standard with the Star Safety System™, which combines Anti-lock Braking System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Traction Control (TRAC) and Vehicle Stability Control (VSC).

Refer to the Owner's Manual for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota's Anti-lock Brake System detects which wheels are locking up and limits wheel lockup by "pulsing" each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or "panic" braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

ENHANCED VEHICLE STABILITY CONTROL (VSC)

Enhanced Vehicle Stability Control provides cooperative control of the ABS, TRAC, VSC and EPS.

Enhanced VSC helps to maintain directional stability when loss of traction occurs during a turn.

SAFETY & EMERGENCY FEATURES

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).


Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Only use one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.




BLUETOOTH® DEVICE PAIRING SECTION

Do not attempt the Bluetooth® Pairing process while driving.

To begin the Bluetooth® Pairing process, press the HOME button.

Bluetooth® Pairing for your phone

Pairing your phone is the first step in connecting with your Toyota. This pairing process is quick and easy. All you have to do is setup the phone and multimedia system to form a connection.



Audio / Audio Plus / Premium Audio

STEP 1 Press [MENU], then select "Setup" on display screen.



iPhone bluetooth Menu



Android bluetooth Menu¹

STEP 2 Ensure Bluetooth is turned on for your phone.



STEP 3 Select "Bluetooth," then select "Add New Device" on display screen.



STEP 4 Select "Phone Name."



STEP 5 Check the display on your phone. Does the PIN XXXX match the PIN displayed? If it does, select "Pair."

¹ Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

Bluetooth® Pairing for your phone (cont.)




STEP 6 "Connecting" displays while phone is forming the connection to the multimedia system.




STEP 7 Enable Notifications (text message). While pairing your phone, a message will be displayed: **"You may need to allow message access on your phone."**

Note: You may also select "Skip" on display screen to skip enabling notifications. If skipped, proceed to **Step 8**.



STEP 8 Turn on "Show Notifications" for iPhone or "ON" for Android.



STEP 9 A confirmation will appear once your phone has been paired and connected.



C-HR

Quick Reference Guide 2022



00505QRG22CHR



Printed in U.S.A. 10/21
21-MKG-15680

toyota.com