2002 Lexus Navigation System
Quick Reference Guide

MAP/VOICE Button
Push this button to repeat a Guidance voice, cancel the one touch scroll and start a Guidance.

DESTINATION Button
Push this button to display the DESTINATION screen.

OPTION Button
Push this button to display the OPTION screen.

MENU Button
This screen allows you to make adjustments or to correct settings of various options and functions.

NORTH–UP AND MAP SCALE Symbol
This symbol indicates a map view with North–up. Press this symbol to change the map view to a head–up perspective. This symbol also indicates the map scale.

GLOBAL POSITIONING SYSTEM (GPS) Mark
This mark is displayed whenever the GPS receiver within the navigation ECU is tracking the vehicle position.

CURRENT VEHICLE POSITION Mark
This mark indicates the current position of the vehicle.

ZOOM IN/ZOOM OUT Buttons
These symbols magnify or reduce the map scale.

SAFETY INSTRUCTIONS

This system is intended to assist you in reaching your destination and, if used properly, can do so. To use your system as safely as possible, follow all safety instructions.

YOU, AS THE DRIVER, ARE SOLELY RESPONSIBLE FOR THE SAFE OPERATION OF YOUR VEHICLE AND THE SAFETY OF YOUR PASSENGERS. DO NOT USE ANY FEATURE OF THIS SYSTEM TO THE EXTENT IT DISTRACTS YOU FROM SAFE DRIVING. YOUR FIRST PRIORITY WHILE DRIVING SHOULD ALWAYS BE THE SAFE OPERATION OF YOUR VEHICLE.

- Before attempting to use this system while driving, learn how to use it. Read the entire Navigation System Manual to make sure you understand the system. Do not allow others to use this system until they have read and understand these and other instructions in this manual.

- You can input your destination and select your route only when your vehicle is not moving. While driving, listen to the voice instructions as much as possible and glance at the screen briefly and only when safe.

- The data in the system may occasionally be incomplete. Road conditions, including driving restrictions (no left turns, street closures, etc.) frequently change. Therefore, before you follow any instruction from the system, look to see whether you can comply with the instruction safely and legally.

- This system cannot warn you about such things as the quality of a neighborhood, street conditions, and availability of emergency services. If you are unsure about the safety of an area, don't drive into it.

UNDER NO CIRCUMSTANCES IS THIS SYSTEM A SUBSTITUTE FOR THE DRIVER'S PERSONAL JUDGMENT.

- The map database is normally updated once a year. Contact your dealer for information about the availability and pricing of an update.

- Use this system only in locations where it is legal to do so. Some states/provinces may have laws prohibiting video screens within sight of the driver.

Touchscreen Navigation

LS 430, GS 430/300, LX 470*, RX 300*, SC 430

1

Read the **CAUTION** screen, select English or French, if applicable, and then touch **I agree**.

2

The map screen appears. Press **DESTINATION** on the navigation face plate.

3

Make sure that you are in the desired search area. Then touch **□** to access the address screen.

4

Touch **House No** and type in the street address number.

5

Touch **Street** to input the street name and then touch **List** .

6

Use **▲** and **▼** to scroll up and down. Touch **■** to select the desired street.

7

Touch **Enter** and the system will begin searching the route.

8

Begin driving.

* Screen images may vary slightly among models.

POINT OF INTEREST INPUT

1

Read the CAUTION screen, select English or French, if applicable, and then touch **I agree**.

2

Press [DESTINATION] on the navigation face plate. Make sure that you are in the desired search area. Then touch [icon] to access the POI screen.

3

Touch **Name** to type in the name of the POI or touch **Category** to view POI categories.

4

Input the POI name using the letter keys and then touch **List**

5

Use [▲] and [▼] to scroll up and down. Then touch [■] to select the desired location.

6

Select the desired route preference and then touch **Enter** .

7

The system will begin searching the route.

8

Begin driving.

* Screen images may vary slightly among models.

Point of Interest (POI): Allows you to enter and route to categories such as airports, ATMs, gas stations, golf courses, hotels, restaurants, and Lexus dealers.

Marked Point:: Allows you to mark up to 100 of your favorite destinations including addresses and phone numbers. Retrieve these points by touching Marked Points on the Destination screen.

Previous Destination: Allows you to select one of your ten most recent destinations, saving you time by not having to enter the address again.

DEMONSTRATION MODE*

1

To view the demo mode, touch and hold Start for 10 seconds. A beep indicates that the demo mode has begun.

2

To end the demo mode, press MAP on the navigation face plate.

* Screen images may vary slightly among models

SPEECH COMMANDS (LS 430 ONLY)

Press the speech command switch on the steering wheel command module to activate the speech command option of the Lexus LS 430 Navigation System. After you hear a beep, say one of the speech commands listed below. The navigation system will confirm your command by asking, "Are you sure you want to (repeat command)?" for some commands that affect the route guidance. Press the speech command switch and reply yes or no.

For a complete list of possible speech commands, please consult the Lexus Navigation System Owner's Manual.

| DESTINATION	GUIDANCE HELP	POI DISPLAY (CONT.)
*Go home	Repeat guidance	Restaurant (American,
*Go to starting point	Show route	Continental, French,
DESTINATION FROM LIST	Show destination	Mexican, Japanese)
*Go to marked point	Show (next, first, second, third, fourth, fifth, final) waypoint	POI off
*Go to previous destination		**REPLY**
*Number one	**GUIDANCE MODE CHANGE**	Yes
*Number two	Change to arrow guidance	No
*Number three	Change to turn list guidance	**ROUTE CHANGE**
*Number four	Change to single screen	*Cancel guidance
*Number five	Change to split screen	*Reroute
MAP OPERATION	**POI DISPLAY**	*Detour
Current position	Airport	*Alternate roads
Zoom in, Zoom out	ATM	*Delete (next, first, second, third, fourth, fifth, final) waypoint
Minimum/Maximum scale	Automobile club	
Change to north up	Bank	**VOLUME**
Change to heading up	Gas station	Louder
Mark (to register a point)	Grocery store	Softer
	Hospital	Voice guidance off
	Lexus dealership	Voice guidance on
	Parking garage/Parking lot	
	Police station	
	Rest area	

*Speech commands that require confirmation.

Navigation with Tabs

**ES 300 ONLY**

DESTINATION INPUT

1

Read the **CAUTION** screen, select English or French and then touch **I agree** .

2

The map screen appears. Touch the **DEST** tab on the navigation screen.

3

Make sure that you are in the desired search area. Touch to access the address screen.

4

Touch **House No** and type in the street address number.

5

Touch **Street** to input the street name and then touch **List**

6

Use and to scroll up and down. Touch to select the desired street.

7

Touch **Enter** and the system will begin searching the route.

8

Begin driving.

1

Read the CAUTION screen, select English or French and then touch I agree .

2

The map screen appears. Touch the DEST tab on the navigation screen.

3

Make sure that you are in the desired search area. Then touch to access the POI screen.

4

Touch Name to type in the POI name or touch Category to view POI categories.

5

Input the POI name using the letter keys and touch List

6

Use and to scroll up and down.
Touch to select the desired location.

**7**

Select desired route preference or touch
Enter

8

Begin driving.

1 Read the **CAUTION** screen, use ⊕ to select English or French and press ⊡ .

2 Use ⊕ to select **I agree** and press ⊡ . The map screen appears. Press **DEST** on the remote control in the center console.

3 Make sure that you are in the desired search area. Use ⊕ to select ▣ and press ⊡ to access the address screen.

4 Use ⊕ to select **House No** and press ⊡ . To type in the street address number, use ⊕ to select the number and press ⊡ .

5 Use ⊕ to select **Street** and press ⊡ to input the street name and then select **List**

6 Use ⊕ to scroll the list of streets. To select the desired street, select ▬ and press ⊡ .

**7** Select enter and press **ENT** . The system will begin searching the route.

8 Begin driving.

1

Read the **CAUTION** screen, use ⊕ to select English or French and press ⒺⓃⓉ.

2

Then use ⊕ to select I agree and press ⒺⓃⓉ.

3

Press ᴰᴱˢᵀ on the remote control. Make sure that you are in the desired search area. Use ⊕ to select ⬛ and press ⒺⓃⓉ to access the POI screen.

4

Use ⊕ to select Name and press ⊙ or select Category to view POI categories.

5

To type in the POI name, use ⊕ to select the letters and press ⒺⓃⓉ. Select List and press ⒺⓃⓉ.

6

Use ⊕ to scroll the list of streets. Select ⬛ of the desired street and press ⒺⓃⓉ.

7

Select enter and press ⒺⓃⓉ. The system will begin searching the route.

8

Begin driving.
To add another destination, repeat steps 2–6, highlight Add and press ⒺⓃⓉ. To delete the current destination, highlight Renew and press ⒺⓃⓉ.