



2024

RZ 300e | RZ 450e AWD

WARRANTY AND SERVICES GUIDE

Owner Amenities | Warranty Information | Maintenance Requirements

SAFETY PRECAUTIONS

Your RZ 300e/RZ 450e AWD has both high-voltage DC and AC systems as well as a 12-volt system. Both DC and AC high voltage are very dangerous and can cause personal injury, severe burns, electric shock and even fatal injury.

To avoid personal injury, please follow all caution labels attached to high-voltage parts. Do not touch or attempt to remove or replace any high-voltage (orange-colored) wiring and connectors. Do not touch the service plug located inside the center console.

If an accident occurs, do not touch any high-voltage wiring, connectors or parts such as the inverter unit.

Do not touch the traction battery if liquid is leaking from or adhered to it. If electrolyte (Organic Carbonate-based electrolyte) from the traction battery comes into contact with the eyes or skin, it could cause blindness or skin wounds. In the unlikely event that it comes into contact with the eyes or skin, wash it off immediately with a large amount of water, and seek immediate medical attention.

If a vehicle fire occurs, extinguish it with a Class D powder-type fire extinguisher.

AUTHORIZED DEALERSHIP MAINTENANCE AND REPAIRS

Lexus recommends having maintenance and repairs for your vehicle performed by an authorized Lexus dealership. To locate your nearest authorized Lexus dealership, visit www.lexus.com/dealers or contact the Lexus Brand Engagement Center at (800) 255-3987.

From everyone at Lexus, thank you for purchasing one of our vehicles. Your Lexus is designed to deliver uncompromising luxury and performance. We are committed to providing you with an ownership experience that is second to none, and we look forward to serving you in the years ahead. Welcome to the Lexus family!

Taking Delivery of Your New Lexus

As you take delivery of your new vehicle, there are some important services you should know about. These include:

Lexus Personalized Settings: Your vehicle includes a variety of electronic features that can be personalized to your preferences. For example, doors can be programmed to remain locked when you shift into "Park." See your dealer for details.

Pre-Delivery Service: Your dealership has performed a thorough service to prepare your vehicle for delivery. This includes initializing certain electronic features, such as the tire pressure warning system.

Scheduled Maintenance: Your vehicle requires maintenance every six months or 5,000 miles, whichever comes first. See page 38 for details.

Dealership Service Department:

Your service department is committed to helping you keep your Lexus performing at its best. Your dealer will provide you with the department's hours of operation, appointment procedures and information on any special services.

Warranty Coverage: Your Lexus is covered by one of the finest warranties in the industry. See page 16 for a summary of coverages.

Roadside Assistance: Roadside assistance is provided for 48 months from your vehicle's in-service date, regardless of mileage. See page 6 for details.

Again, thank you for choosing Lexus. We wish you many years of safe and pleasurable driving.

Vehicle Ownership and Contact Information Updates

If you would like to update your vehicle ownership or contact information, you may do so by registering at www.lexus.com/My-Lexus, or you can complete and mail the business reply card at the back of this booklet. You will need your full 17-digit Vehicle Identification Number (VIN) to input the new information.

OWNER AMENITIES

Complimentary Services

First Scheduled Maintenance Service	4
Second Scheduled Maintenance Service	5
Alternate Transportation	5
Travel Protection	5
Roadside Assistance	6

Other Benefits and Assistance

Quality Control	7
Vehicle Service History	7
Vehicle Service Agreements	7
Body Repairs	7
Genuine Lexus Parts	8
The Smart Key	8
If You Need Assistance	9
NCDS Arbitration	10

WARRANTY INFORMATION

Introduction

The Lexus Commitment	14
Warranty Coverages at a Glance	16

Your Warranties in Detail

General Warranty Provisions	18
New Vehicle Limited Warranty	20
Tire Limited Warranty	24

Your Responsibilities

Operation and Maintenance26
 Obtaining Warranty Service27

MAINTENANCE INFORMATION

Introduction

The Importance of Scheduled Maintenance 29
 Maintenance and Lexus Warranty Coverage 30
 Lexus Dealership Service 31
 General Maintenance and Regular Use 32

Scheduled Maintenance Log

Determining Your Maintenance Interval: Months vs. Mileage34
 Special Operating Conditions34
 Complimentary First Scheduled Maintenance Service35
 Complimentary Second Scheduled Maintenance Service36
 Scheduled Maintenance Log38
 Explanation of Maintenance Items58
 Vehicle Identification61

INDEX62

To help ensure that your ownership experience is pleasant, convenient and trouble-free, Lexus provides you with a variety of complimentary services. These services are described on the following pages. Other valuable owner benefits are described in the section entitled “Other Benefits and Assistance” beginning on page 7.

First Scheduled Maintenance Service: Six Months or 5,000 Miles

This complimentary service is performed at six months or 5,000 miles, whichever occurs first. To obtain this service, contact your Lexus dealership. Your complimentary service will include these items:

- Inspect and adjust all fluid levels
- Program Lexus Personalized Settings, if requested
- Inspect brake pads and discs
- Inspect wiper blades
- Check installation of driver’s floor mat
- Road test vehicle
- Inspect tires

Personalized Settings?

Your vehicle includes a variety of electronic features that can be programmed to your preferences. For example, doors can be programmed to remain locked when you shift into “Park.” (For more information, see the “Customizable Features” section of the Specifications chapter in your *Owner’s Manual*.) Programming of these features is performed once at no charge, provided you obtain the service at the six-month/5,000-mile scheduled maintenance service. Programming of some Lexus Personalized Settings requires special equipment and may be performed only by an authorized Lexus dealership.

What are Lexus

Second Scheduled Maintenance Service: 12 Months or 10,000 Miles

This complimentary service is performed at 12 months or 10,000 miles, whichever occurs first. To obtain this service, contact your Lexus dealership. Your complimentary service will include these items:

- Inspect brake pads and discs
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Check installation of driver's floor mat
- Inspect tires
- Road test vehicle

If you do the majority of your driving under certain special operating conditions, additional items are included in this service. See the "12 Months or 10,000 Miles" chart on page 38.

Alternate Transportation

If your vehicle must be kept overnight at a Lexus dealership for a warranty-covered condition that requires more than eight hours to repair, Lexus will provide you with alternate transportation for up to five days.

Travel Protection

Lexus will reimburse for a rental car for up to five days and for overnight lodging for up to three nights (not to exceed \$200 per night) if all of the following occur:

- Your vehicle becomes inoperable or unsafe to drive when you are more than 100 miles from home.
- Your vehicle's malfunction is caused by a warranty-covered condition.
- Repairs will take longer than eight hours to complete.

To obtain reimbursement for rental car and lodging expenses, contact a Lexus dealership service consultant.

Roadside Assistance

Lexus roadside assistance coverage is for 48 months from your vehicle's in-service date, regardless of mileage. Coverage is 24 hours a day, 365 days a year for vehicles operated in the continental U.S. and Canada. With an active Safety Connect subscription, Enhanced Roadside Assistance coverage is included. See your Lexus dealer for details.

Services Provided

- Roadside services such as tire change, lockouts, vehicle extrication and towing in case of minor accident.
- Towing to the nearest Lexus dealership (or an alternate repair facility, if necessary).
- Assistance in locating alternate transportation and lodging.
- Visit the Apple and Google app stores to download the Lexus app.

How to Get Help

To obtain roadside assistance, take the following steps:

- 1) Call (800) 25-LEXUS (800/255-3987), or press the SOS button on the overhead console (requires an active Safety Connect subscription).
4G Network Dependent.

2) Have as much of the following information as possible:

- 17-digit Vehicle Identification Number (VIN) found on the vehicle registration paperwork and on the certification label located inside the driver's doorjamb
- Owner's name and home address
- Vehicle license plate number
- Location of vehicle, including the nearest major intersection

3) Wait at your vehicle or in a nearby secure location for the roadside assistance provider to arrive.

Additional Coverage

After your included coverage expires, you may renew your Safety Connect subscription by using the Lexus app. 4G Network Dependent.

Quality Control

You may have noticed a few miles on the odometer when you took delivery of your Lexus. This mileage is a result of the comprehensive process used to ensure the quality of your vehicle. This process includes extensive inspections during and after production. The final inspection takes place at the selling dealership and includes a road test conducted by a certified Lexus technician.

If you'd like to know more about Lexus quality-control procedures, ask a Lexus dealership service consultant.

Vehicle Service History

When you have your vehicle serviced at a Lexus dealership, your service information is recorded in the Lexus National Service History database. This is the first database of its kind in the automotive industry. It can be accessed by any Lexus dealership in the United States – a great convenience if you relocate or need to have your vehicle serviced while traveling.

Vehicle Service Agreements

If you plan to keep your vehicle for several years or if you accumulate mileage quickly, you may want to purchase a Lexus vehicle service agreement. These agreements cover the cost of specific repairs beyond

the factory warranty period. They also cover services such as towing, substitute transportation and lodging to minimize your inconvenience should your vehicle require repair. Lexus vehicle service agreements are available with a variety of coverage options. A Lexus dealership sales consultant can help you select the plan that's best for you.

Body Repairs

If you're involved in a collision, you want your vehicle to be returned to its pre-accident condition when repaired. That's why it is important to make sure repairs are made only with Genuine Lexus Parts. Lexus has a select group of certified and authorized collision centers that have undergone rigorous training to ensure the highest quality and customer satisfaction. A list of these Lexus Collision Centers can be found at: lexuscollisioncenter.com. Some repair shops and insurance companies may suggest using imitation or salvaged parts to save money. However, these parts do not meet Lexus' high standards for quality, fit and corrosion resistance. In addition, imitation and salvaged parts (and any damage or failures they may cause) are not covered by any Lexus warranty.

Genuine Lexus Parts

The best way to ensure that your vehicle is repaired with Genuine Lexus Parts is to take it to a Lexus dealership. Warranty coverage is not dependent upon the use of any particular brand of replacement parts and you may elect to use non-Genuine Lexus Parts for maintenance and repairs. However, use of replacement parts that are not equivalent in quality to Genuine Lexus Parts may impair the effectiveness of the vehicle systems.

The Smart Key

Your Lexus vehicle was made with two “Smart Keys” and an aluminum key-number plate. Each Smart Key includes an electronic main key that has an integrated mechanical backup key. The electronic key controls the remote-entry and theft-deterrent systems, enables the push-button start switch and controls the engine immobilizer. The mechanical key can be removed from the electronic key and used to operate the driver’s door lock, the glove box lock and the trunk lock (if equipped).

Replacing the Key

Your Lexus dealer can generate replacement keys. Certain bonded/registered locksmiths may also be able to generate replacement keys. When ordering a new key, bring all keys for the vehicle to your dealership.

If a Smart Key or the key-number plate is not available, a Lexus dealer or certain locksmiths can obtain the key code from a restricted-access database. These businesses can also access a service utility to register the keys to the vehicle if all registered keys have been lost.

If you lock your key in your vehicle and do not have a spare, your dealer can make a new mechanical key from the code on the key-number plate. Certain bonded/registered locksmiths may also be able to generate a replacement mechanical key. If a Lexus dealer is not available, please refer to www.aloa.org to find a bonded/registered locksmith who performs high-security key service.

Keeping the Key Safe

Replacing a Smart Key may be costly. We advise you to keep a spare Smart Key and the key-number plate in a safe place. If you record the key number in more than one place, do not record it in a way that can be easily identified and associated with the vehicle. For example, don’t leave the number somewhere that can be accessed by a valet. It is wise to keep a copy of the key number outside of the vehicle.

If You Need Assistance

Both Lexus and your Lexus dealer are dedicated to serving your automotive needs. Your complete satisfaction is our first priority. Should you have a problem or concern, please take the following steps to ensure the quickest possible response:

Step 1

Discuss the situation with a dealership manager, such as the service manager or customer satisfaction manager. If necessary, ask the dealership owner or general manager for assistance. In most cases, a satisfactory solution can be reached at this step.

Step 2

If the dealership does not address your concern to your satisfaction, call the Lexus Brand Engagement Center at (800) 25-LEXUS (800/255-3987) or visit lexus.com/contact. In Canada, call (800) 26-LEXUS (800/265-3987).

You may also write to us at:

Lexus Brand Engagement Center
Lexus, a division of
Toyota Motor Sales, U.S.A., Inc.
P.O. Box 259001
Plano, TX 75025-9001

Whether calling or writing, please provide the following information:

- 17-digit Vehicle Identification Number (VIN) found on the vehicle registration paperwork and on the certification label located inside the driver's doorjamb
- Current vehicle mileage
- Name of your selling and servicing Lexus dealerships
- Your day and evening telephone numbers

Step 3

If your concern has still not been resolved to your satisfaction, Lexus offers additional assistance through:

National Center for Dispute Settlement (NCDS)

P.O. Box 515791

Dallas, TX 75251-5791

(866) 272-4872

Important: You must use NCDS prior to exercising rights or seeking remedies available to you through a court action pursuant to the Magnuson-Moss Warranty Act. In addition, you must use NCDS if you are required to do so prior to exercising certain rights or seeking certain remedies available under the Lemon Laws of your state. See the *Lemon Law Guide* for specific requirements applicable in your state.

However, if your state law does not require it and/or if you choose to exercise rights and seek remedies not created by the Federal Act, you need not use NCDS.

NCDS Arbitration**What is the Dispute Settlement Program?**

This program consists of local professionals who are trained and experienced in arbitration. The arbitrator(s) appointed by NCDS will arbitrate your case by reviewing the facts, having the vehicle inspected, if necessary; and promptly rendering a fair and equitable decision.

How much will it cost?

The service is provided at no cost to you. It is part of Lexus' effort to promptly and equitably resolve your concerns. The decision-maker is an impartial third party. The decision of the arbitrator(s) is binding on Lexus but not on you.

What types of disputes are eligible?

NCDS resolves disputes involving Lexus product reliability and warranty performance that arise during the greater of 1) four years or 50,000 miles from the vehicle's in-service date, whichever is earlier; or 2) the applicable provision of the Lexus New Vehicle Limited Warranty. However, NCDS will not arbitrate 1) claims involving a vehicle used primarily for commercial purposes unless the Lemon Laws of your state cover vehicles used for commercial purposes; or 2) claims that an airbag failed to deploy or deployed when it should not have; or 3) disputes regarding fires and/or accidents and/or theft. Since there are other additional exclusions, please contact NCDS for further information on eligibility guidelines. The time period in which you can request arbitration through NCDS is limited and you should reference your applicable state law and/or contact NCDS to determine the deadline for filing a request for arbitration. To be eligible for arbitration, you must have brought the concern or alleged defect to the attention of Lexus or one of its dealers during the warranty term.

How long is the arbitration process?

The entire process – from the time NCDS receives your request for arbitration to the arbitrator's decision – is designed to take no more than 40 days. A decision may be delayed if:

- You fail to provide certain information required by NCDS.
- You fail to make your vehicle available for inspection by NCDS in a timely manner (if an inspection is required).

How do I request arbitration?

To request arbitration, you can contact the National Center for Dispute Settlement (NCDS) at 866-272-4872; electronically file your claim at www.ncdsusa.org; or reach NCDS by mail using the claim form in your warranty book and sending to PO Box 515791, Dallas, TX 75251-5791. In order to file your claim, you should have available your Vehicle Identification Number (VIN); current mileage on the vehicle; repair history/dates; and the selling and servicing dealerships.

In addition to completing the customer claim form, please provide NCDS with the following information:

- Vehicle year, make, model, VIN, mileage and date of purchase.
- A brief description of your complaint and the actions you have taken to resolve it.
- What action or remedy you believe would resolve your problem.

If you are seeking reimbursement for repairs or incidental expenses, please provide copies of applicable receipts.

Send your request to:

National Center for Dispute Settlement
P.O. Box 515791
Dallas, TX 75251-5791

Upon receipt of your request, NCDS will contact you regarding the status of your case and supply you with additional details about the program.

How does the arbitration process work?

When NCDS receives your request, it will be forwarded to the Lexus area office for response.

At the request of either party or the arbitrators, NCDS may schedule a technical inspection. This may include an inspection of the vehicle by an independent technical expert with a Lexus representative present. The technical expert will forward his or her evaluation to NCDS.

An oral hearing may be held prior to a decision being rendered. At this hearing, all relevant evidence is admissible. You and a Lexus representative will present both sides of the case to the NCDS arbitrator(s). You will each be given an equal opportunity to give testimony and provide documents. Then you will each be given an opportunity for rebuttal. After considering all testimony and documents, the arbitrator(s) will review the applicable legal standards and render a decision within 10 days.

A settlement satisfactory to all parties may be negotiated at any time during the process.

What types of decisions are rendered, and how do I know if Lexus will abide by the decision of the arbitrator(s)?

Arbitrated decisions are based on what the arbitrator(s) believe to be fair and equitable after applying the appropriate legal standards. Remedies include but are not limited to repairs; reimbursement for repairs and incidental expenses, such as towing costs; and repurchase or replacement of your vehicle.

The decision of the arbitrator(s) is binding on Lexus but not on you. Lexus must comply with the decision shortly after it is rendered, usually within 30 days of your acceptance of the decision. NCDS will contact you within 10 days of scheduled compliance to ensure that Lexus has complied in a timely manner.

Are there limits to the scope of arbitrated decisions?

Arbitrated decisions do not include:

- Attorney fees
- Punitive damages
- Multiple damages
- Consequential damages, other than incidental damages that you may be entitled to under law

What other recourse do I have?

If you are dissatisfied with the arbitrator's decision or Lexus' compliance, you may pursue any other legal remedies available to you, including small claims court. You should be aware that the decision of the arbitrator(s) may be admissible as evidence in any legal proceedings concerning your vehicle.

Is the Dispute Settlement Program subject to change?

The information in this booklet about the program is correct as of the date of printing. However, the program may be changed without notice. Contact the Lexus Brand Engagement Center at www.lexus.com/contact or (800) 255-3987 for the most current information concerning the Dispute Settlement Program.

You have purchased one of the finest vehicles built in the world today, and it is backed by one of the finest warranties in the industry. This excellent warranty coverage demonstrates not only our confidence in Lexus vehicles, but also our commitment to every Lexus customer. We're dedicated to ensuring that you enjoy exceptional quality, dependability and peace of mind throughout your ownership experience.

To further demonstrate our commitment to our customers' satisfaction, occasionally we may establish a special policy adjustment to pay for specific repairs that are no longer covered by warranty. When we establish such a policy adjustment, we mail details to all applicable owners on record. That's why it is important to send in the card at the back of this booklet if you change your address or if you have purchased your Lexus from a previous owner.


You've made a wise decision to purchase a Lexus. Your vehicle delivers world-class luxury and performance, along with an unparalleled commitment from Lexus to ensuring your satisfaction. You can be confident – as we are – that you'll enjoy owning your Lexus as much as you enjoy driving it.

This section of the *Warranty and Services Guide* describes the terms of Lexus warranty coverage as well as general owner responsibilities. The section beginning on page 29 describes your vehicle's maintenance requirements. Be sure to review this information carefully, since proper maintenance is required to ensure that warranty coverage remains intact.

All warranty information is the latest available at the time of publication.

WARRANTY COVERAGES AT A GLANCE

New Vehicle Limited Warranty



WARRANTY

Important: You must use the Dispute Settlement Program before seeking remedies through a court action pursuant to the Magnuson-Moss Warranty Act (the “Act”). However, if you choose to pursue rights and remedies not created by the Act, you are not required to use the Dispute Settlement Program. You may also be required to use the Dispute Settlement Program before seeking remedies under the “Lemon Laws” of your state. Please check this booklet and the appropriate page of the *Lexus Lemon Law Guide* booklet for additional information and the requirements applicable to your state.

Who Is the Warrantor

The warrantor for these limited warranties is Lexus, a division of: Toyota Motor Sales, U.S.A., Inc., a California corporation
P.O. Box 259001
Plano, TX 75025-9001

Which Vehicles Are Covered

These warranties apply to 2024 model-year Lexus RZ 300e/RZ 450e AWD vehicles registered and normally operated in the United States, U.S. territories and Canada. Warranty coverage is automatically transferred at no cost to subsequent vehicle owners.

Multiple Warranty Conditions

This booklet contains warranty terms and conditions that may vary depending on the part covered. A warranty for specific parts or systems, such as the Powertrain Warranty or Electric Vehicle Drive Components Warranty is governed by the coverage set forth in that warranty as well as the General Warranty Provisions.

When Warranty Begins

The warranty period begins on the vehicle’s in-service date, which is the first date the vehicle is either delivered to an ultimate purchaser, leased or used as a company car or demonstrator.

Repairs Made at No Charge

Repairs and adjustments covered by these warranties are made at no charge for parts and labor.

Parts Replacement

Any needed parts replacement will be made using new or remanufactured parts. The decision whether a part should be repaired or replaced will be made by the servicing Lexus dealership and/or Lexus. Parts scheduled to be replaced as required maintenance are warranted until their first replacement only.

Note: Lexus remanufactured parts meet or exceed all factory standards for safety, quality and reliability.

Limitations

The performance of necessary repairs and adjustments is the exclusive remedy under these warranties or any implied warranties. Lexus does not authorize any person to create for it any other obligation or liability in connection with this vehicle.

Any implied warranty of merchantability or fitness for a particular purpose is limited to the duration of these written warranties.

Some states do not allow restrictions on how long an implied warranty lasts, so this limitation may not apply to you.

Your Rights Under State Law

These warranties give you specific legal rights. You may also have other rights that vary from state to state.

WHAT IS COVERED AND HOW LONG

Basic Warranty

This warranty covers repairs and adjustments needed to correct defects in materials or workmanship of any part supplied by Lexus, subject to the exceptions indicated under “What Is Not Covered” on pages 21-23.

Coverage is for 48 months or 50,000 miles, whichever occurs first, with the exception of air conditioning recharge, wheel alignment and wheel balancing, which are covered for 12 months or 12,000 miles, whichever occurs first.

Electric Vehicle Drive Components Warranty

This warranty covers repairs needed to correct defects in materials or workmanship of the components listed here and supplied by Lexus, subject to the exceptions indicated under “What is not covered” on pages 21-23.

- Traction Battery
 - Below 70% of original capacity
- Transaxle
- Inverter with Converter

The Electrical Drive Component Warranty is in effect for 8 years or 100,000 miles from the vehicle’s in service date, whichever occurs first.

Powertrain Warranty

This warranty covers repairs needed to correct defects in materials or workmanship of any component listed here and supplied by Lexus, subject to the exceptions indicated under “What Is Not Covered” on pages 21-23.

Coverage is for 72 months or 70,000 miles, whichever occurs first.

EV Control ECU

Front-Wheel-Drive System

Axle shaft, hub, bearings, seals and gaskets.

Rear-Wheel-Drive System

Rear motor/generator, differential carrier assembly, axle carrier, axle case, axle bearing, axle shaft, seals and gaskets.

Restraint Systems Warranty

This warranty covers repairs needed to correct defects in materials or workmanship of any seatbelt or airbag system supplied by Lexus, subject to the exceptions indicated under “What Is Not Covered” on pages 21-23.

Coverage is for 72 months or 70,000 miles, whichever occurs first.

For vehicles sold and registered in Kansas, the warranty for seatbelts and related components is 10 years, regardless of mileage.

Corrosion Perforation Warranty

This warranty covers repair or replacement of any original body panel that develops perforation from corrosion (rust-through), subject to the exceptions indicated under "What Is Not Covered" on pages 21-23.

Coverage is for 72 months, regardless of mileage.

For information on how to protect your vehicle from corrosion, refer to sections related to maintenance and care in the *Owner's Manual*.

Towing

When your vehicle is inoperable due to failure of a warranted part, towing service to the nearest authorized Lexus dealership is covered.

WHAT IS NOT COVERED

This warranty does not cover damage or failures resulting directly from any of the following:

- Neglecting to follow appropriate vehicle usage, incorrect charging procedure or use of an incompatible charging device that results in a battery capacity reduction
- Fire, accidents or theft
- Abuse or negligence
- Misuse – for example, racing or overloading
- Improper repairs
- Alteration or tampering, including installation of non-Genuine Lexus Accessories
- Lack of or improper maintenance, including use of fluids other than those specified in the *Owner's Manual*
- Installation of non-Genuine Lexus Parts
- Airborne chemicals, tree sap, road debris (including stone chips), rail dust, salt, hail, floods, wind storms, lightning and other environmental conditions
- Water contamination

This warranty also does not cover the following:

Tires

Tires are covered by a separate warranty provided by the tire manufacturer. See pages 24-25.

Normal Wear and Tear

Noise, vibration, cosmetic conditions and other deterioration caused by normal wear and tear.

Gradual Capacity Reduction of Traction Battery (Lithium-ion Battery)

Lithium-ion battery capacity (the ability to hold a charge) gradually reduces with time and use. This is a natural characteristic of lithium-ion batteries. The extent at which capacity is reduced changes drastically depending on the environment (ambient temperature, etc.) and usage conditions such as

how the vehicle is driven and how the lithium-ion battery is charged. Reduction of the lithium-ion battery capacity by 30 percent or less is considered normal and not covered under warranty. In order to lessen the possibility of capacity reduction, follow the directions listed in the *Owner's Manual*.

The driving range estimates are not a measure of battery capacity. Additional factors such as environmental conditions will influence the driving range on your display monitor. As a result, your display monitor is not an indicator of battery capacity.

The traction battery warranty replacement may not restore the vehicle to an "as new" condition. Taking into consideration other factors, including the age and mileage of the vehicle, Lexus will ensure that the energy capacity of the replacement battery is at least equal to that of the original battery before the failure occurred.

The measurement method used to determine battery capacity, and the decision of whether to repair, replace, or provide reconditioned/re-manufactured parts, and the condition of any such replaced, recondition/re-manufactured parts, are at the sole discretion of Lexus.

Maintenance Expense*

Normal maintenance services such as replacement of fluids and filters; lubrication; cleaning and polishing; and replacement of worn wiper blades, brake pads and linings.

Vehicles with Altered Odometer

Failure of a vehicle on which the odometer has been altered so that actual vehicle mileage cannot be readily determined.

Software Updates

Software updates made available for download by owners directly at www.lexus.com/firmware-updates or available via Over-the-Air (OTA), either on a complimentary basis or for a fee, as determined by Lexus in its sole discretion.

Vehicles with Unknown Vehicle Identification Number

Any vehicle for which the original factory-assigned vehicle identification number cannot be determined.

Salvage or Total-Loss Vehicles

Any vehicle that has ever been branded as salvage, total loss, true mileage unknown or similar title under any state's law or has ever been declared a "total loss" or equivalent by a financial institution or insurer, such as by payment for a

*Lexus provides the first two scheduled maintenance services at no charge. See pages 4-5 for details.

claim in lieu of repairs because the cost of repairs exceeded the cash value of the vehicle. This exclusion does not apply to any open Safety Recalls/SSCs/LSCs.

Incidental Damages

Incidental or consequential damages associated with a vehicle failure. Such damages include but are not limited to inconvenience; the cost of transportation, telephone calls and lodging; the loss of personal or commercial property; and the loss of pay or revenue.

Disclaimer of Extra Expenses and Damages

The performance of necessary repairs and adjustments is the exclusive remedy under this warranty or any implied warranty. Lexus does not authorize any person to create for it any other obligation or liability in connection with this vehicle. Lexus shall not be liable for incidental or consequential damages resulting from breach of this written warranty or any implied warranty.

Any implied warranty of merchantability or fitness for a particular purpose is limited to the duration of this written warranty, except in states where this limitation is not allowed.

DISPUTE RESOLUTION

If a dispute arises regarding your warranty coverage, please follow the steps described on pages 9-10. Please note that you must use the National Center for Dispute Settlement before seeking remedies through a court action pursuant to the Magnuson-Moss Warranty Act. You may also be required to use the National Center for Dispute Settlement before seeking remedies under the Lemon Laws of your state. For the requirements applicable to your state, see the appropriate page of the *Lemon Law Guide* located in your vehicle.

OBTAINING WARRANTY SERVICE

All tires supplied as original equipment on new Lexus vehicles are warranted by the individual tire manufacturer only, and not Lexus. However, your Lexus dealer may be able to assist you in obtaining warranty service from the tire manufacturer.

Coverages by individual tire manufacturers may vary.

The terms of the tire manufacturers' warranty can be obtained from the tire manufacturers' websites. If you wish to obtain a hard copy of the tire warranty terms, please contact the tire manufacturer directly.

ORIGINAL EQUIPMENT TIRE MANUFACTURERS

BF Goodrich/ Michelin North America

P.O. Box 19001
Greenville, SC 29062
BF Goodrich: (877) 788-8899
Michelin: (800) 847-3435
www.bfgoodrichtires.com
www.michelinman.com

Bridgestone/Firestone

200 4th Avenue South
Nashville, TN 37201
Bridgestone: (800) 847-3272
Firestone: (800) 356-4644
www.bridgestone.com
www.firestonetire.com

Continental Tire of North America

1800 Continental Boulevard
Charlotte, NC 28273
(800) 847-3349
www.continentaltire.com

Dunlop Tires/Goodyear Tire and Rubber Co.

1144 East Market Street
Akron, OH 44316
(800) 321-2136
www.dunloptires.com
www.goodyear.com

Falken Tire Corporation

8656 Haven Avenue
Rancho Cucamonga, CA 91730
(800) 723-2553
www.falkentire.com

Hankook Tire**America Corporation**

1450 Valley Road
Wayne, NJ 07470
(800) 426-5665
www.hankooktire.com

Kenda Tire

7095 Americana Parkway
Reynoldsburg, OH 43068
(866) 536-3287
www.kendatire.com

Maxxis International – USA

545 Old Peachtree Road
Suwanee, GA 30024
(800) 462-9947
www.maxxis.com

Nitto Tire U.S.A. Inc.

P.O. Box 6064
Cypress, CA 90630
(888) 529-8200
www.nittotire.com

Pirelli Tire LLC

100 Pirelli Drive
Rome, GA 30161
(800) 747-3554
www.pirelli.com

Toyo Tire U.S.A. Corporation

P.O. Box 6052
Cypress, CA 90630
(800) 442-8696
www.toyotires.com

Yokohama Tire Corporation

1 MacArthur Place, Suite 800
Santa Ana, CA 92707
(800) 722-9888
www.yokohamatire.com

GENERAL INFORMATION

You are responsible for ensuring that your Lexus is operated and maintained according to the instructions in the *Owner's Manual* and the "Maintenance Information" section of this guide.

You should keep detailed records of vehicle maintenance, since under some circumstances they may be required for warranty coverage. These records should include date of service, mileage at time of service and a description of service performed and/or parts installed.

For your convenience, maintenance logs are included in the "Maintenance Information" section of this guide. If you sell your vehicle, you should give your maintenance records to the new owner.

Lexus will not deny a warranty claim solely because you do not have records to show that you maintained your vehicle. However, damage or failures caused by lack of proper maintenance are not covered under warranty.

WHERE TO GO FOR MAINTENANCE

Lexus recommends having maintenance performed by an authorized Lexus dealership. However, you may have maintenance performed on your vehicle by any qualified person or facility.

Lexus dealership technicians are specially trained to maintain and repair Lexus vehicles. They stay current on the latest service information through Lexus Technical Service Information Bulletins, service publications and training courses. Many are also certified through the Lexus Certification Program, which requires specialized, state-of-the-art training as well as rigorous exams through both Lexus and the National Institute for Automotive Service Excellence (ASE).

You can be confident you're getting the best possible service for your vehicle when you take it to a Lexus dealership. Plus, a Lexus dealership will always use Genuine Lexus Parts designed specifically for your vehicle.

REPLACEMENT PARTS

Lexus recommends using only Genuine Lexus Parts when you need to replace a part on your vehicle. Like all Lexus products, Genuine Lexus Parts are built to the highest standards of quality, durability and performance. They are also designed to fit your vehicle's exact specifications. However, warranty coverage is not dependent upon the use of any particular brand of replacement parts.

Your Lexus dealership maintains an extensive inventory of Genuine Lexus Parts to meet your vehicle service needs. And because it is linked electronically to Lexus Parts Distribution Centers, the dealership has quick access to any parts it may not have in stock.

Genuine Lexus Parts are covered by their own warranty (see your dealer for details) or the remainder of any applicable New Vehicle Limited Warranty, whichever is longer. **Non-Genuine Lexus Parts, or any damage or failures resulting from their use, are not covered by any Lexus warranty.**

BY GEOGRAPHIC REGION**In the United States,
U.S. Territories and Canada**

To obtain warranty service in the United States, U.S. territories or Canada, take your vehicle to an authorized Lexus dealership. If your vehicle cannot be driven, contact your nearest Lexus dealership for towing assistance. You do not have to pay for towing to the nearest Lexus dealership if your vehicle is inoperable due to failure of a warranted part.

**Outside the United States,
U.S. Territories and Canada**

If you are using your vehicle outside the United States, U.S. territories and Canada and need warranty service, contact a local Lexus dealership. Please note, however, that your vehicle may not be repaired free of charge because the local Lexus distributor may have no obligation to provide warranty service for your vehicle, and/or your vehicle may not comply with local regulatory or environmental requirements.

EMERGENCY REPAIRS

Lexus recommends having maintenance and repairs for your vehicle performed by an authorized Lexus dealership. To locate your nearest authorized Lexus dealership, visit www.lexus.com/dealers or contact the Lexus Brand Engagement Center at (800) 255-3987.

Maintenance and repairs not performed by an authorized Lexus dealership should be performed by a qualified technician following procedures in Lexus service and repair publications.

If your vehicle is inoperable or unsafe to drive and there is no Lexus dealership reasonably available to make repairs, you may perform the repairs yourself or have them performed by another automotive service provider. Lexus will reimburse you for any of the repairs that are covered by warranty. To receive reimbursement, present to an authorized Lexus dealership your paid repair invoices and any parts that were removed from the vehicle.

You will be reimbursed for warranted parts at the manufacturer's suggested retail price and warranted labor at a geographically appropriate hourly rate multiplied by Lexus' recommended time allowance for the repair.

If your vehicle requires emergency repair, Lexus assumes no liability for subsequent failures caused by improper repairs or the use of non-Genuine Lexus Parts unless you have the vehicle properly repaired in a timely manner. To ensure that warranty coverage remains intact, have your vehicle inspected by an authorized Lexus dealership as soon as possible after an emergency repair.

Regular maintenance is essential to obtaining the highest level of performance, safety and reliability from your Lexus. It can also enhance your vehicle's resale value. This section of the *Warranty and Services Guide* is designed to help you make sure your vehicle receives proper and timely maintenance. It includes factory-recommended maintenance guidelines as well as logs in which to document your vehicle's maintenance history.

In addition to scheduled maintenance, your Lexus requires ongoing general maintenance such as fluid checks and visual inspections. These procedures are listed on pages 32-33 of this booklet and described in detail in the "Maintenance" section of the *Owner's Manual*.

With proper maintenance and care, your vehicle will last longer and deliver more dependable, economical performance. Follow this booklet's recommendations and you'll enjoy maximum reliability and peace of mind from your Lexus for many years to come.

SERVICE

BY LEXUS

Maintaining your vehicle according to the recommendations in this booklet is required to ensure that your warranty coverage remains intact. You should keep detailed records of vehicle maintenance, including date of service, mileage at time of service and a description of service and/or parts installation performed. The maintenance logs in this booklet are a good place to record this information. If you sell your vehicle, be sure to give your maintenance records to the new owner.

Lexus will not deny a warranty claim solely because you do not have records to show that you maintained your vehicle. However, damage or failures caused by lack of proper maintenance are not covered under warranty.

Maintenance and repair services may be performed by you or by any automotive service provider you choose. Lexus will not deny a warranty claim solely because you used a service provider other than a Lexus dealership for maintenance and repairs.

However, damage or failures caused by improper maintenance or repairs are not covered under warranty.

Your dealer may recommend more frequent maintenance intervals or more maintenance services than those listed in the scheduled maintenance log. These additional services are not required to maintain your warranty coverage. Ask your dealer for an explanation of any recommended maintenance not included in the scheduled maintenance log.

For a complete description of Lexus warranty coverages, see pages 18–23 of this booklet.

To ensure that your vehicle receives first-quality service and factory-authorized parts, Lexus recommends having maintenance performed by an authorized Lexus dealership. To locate your nearest authorized Lexus dealership, visit www.lexus.com/dealers or contact the Lexus Brand Engagement Center at (800) 255-3987.

Lexus dealership technicians are experts in the maintenance and repair of Lexus vehicles. They stay current on the latest service information through Lexus Technical Service Information Bulletins, service publications and training courses. Many are also certified through the Lexus Certification Program, which requires specialized, state-of-the-art training as well as rigorous exams through both Lexus and the National Institute for Automotive Service Excellence (ASE).

Your vehicle comes with Service Connect, with up to 10-year trial subscription. 4G Network Dependent. Should you opt in, this service allows you to receive Vehicle Health Reports, as well as vehicle and maintenance alerts. Your vehicle will let your preferred dealer know when it is due for maintenance or when a warning is detected. See Lexus.com/My-Lexus for additional information.

Additionally, when you have your vehicle serviced at a Lexus dealership, your service information is recorded in the Lexus National Service History database. This is the first database of its kind in the automotive industry. It can be accessed by any Lexus dealership in the U.S. – a great convenience if you relocate or need to have your vehicle serviced while traveling.

You can be confident you're getting the best possible service for your vehicle when you take it to a Lexus dealership. Don't trust your investment to anything less than a team of Lexus specialists.

Maintenance and repairs not performed by an authorized Lexus dealership should be performed by a qualified technician following procedures in Lexus service and repair publications.

Please refer to the important safety precautions found on the inside front cover of this booklet.

In addition to scheduled maintenance, your Lexus vehicle requires ongoing general maintenance such as fluid checks and visual inspections.

The recommended guidelines for inspections are listed below. Please refer to the “Maintenance” section of the *Owner’s Manual* for a detailed description of inspection procedures.

Every 30 Days

At least once every 30 days, perform these inspections:

- Visually check brake fluid level on the see-through reservoir
- Check level of windshield washer fluid
- Check tire pressure
- Check tires for damage and wear
- Check installation of driver’s floor mat

After a Car Wash

- Check installation of driver’s floor mat

When Cleaning the Interior

- Remove dirt and dust with a vacuum cleaner. Wipe dirty surfaces with a soft cloth dampened with warm water.
- When cleaning leather interior, remove dirt and dust with a vacuum cleaner. Using a sponge, apply a small amount of neutral wool detergent mixed in water, rubbing in a circular motion. Wipe off any excess detergent and let leather dry in an open-air location.
- When cleaning carpet, remove dirt and dust with a vacuum cleaner. Apply a foaming-type carpet cleaner with a sponge or brush, allowing cleaner to work for a few minutes to loosen dirt. Continue by rubbing carpet in a circular motion. Wipe off any excess cleaner with a clean cloth. If any dirt remains, repeat process. Best results are obtained by keeping the carpet as dry as possible.

When Cleaning the Exterior

- Working from top to bottom, apply lots of low-pressure water to the body, wheel wells and underside of vehicle to remove dirt and dust. Wash the vehicle body using a soft sponge or cotton cloth with mild car-wash soap. Rinse off with water.
- If water does not bead on a clean vehicle surface, apply car wax using a soft cotton cloth when the body of the vehicle is cool.

When Cleaning the Wheels

- Wait for hot wheels to cool before getting wheels wet.
- Using a soft sponge or cotton cloth, apply same mild car-wash soap as used for the vehicle body. Quickly rinse off with water. Using a soft cotton cloth, apply same car wax as used for the vehicle body.

Maintaining Charge for 12-Volt Battery

The following tips will help you keep your vehicle's 12-volt battery fully charged:

- Drive vehicle at least weekly.
- Operate accessories with vehicle in "READY" mode.
- When parking, make sure doors and trunk are closed and lights are turned off.

Determining Your Maintenance Interval: Months vs. Mileage

Lexus recommends obtaining scheduled maintenance for your vehicle every six months or 5,000 miles, whichever occurs first.

For example:

- If at six months you have driven less than 5,000 miles, you should obtain maintenance at **six months**; don't wait until 5,000 miles.
- If you drive 5,000 miles in less than six months, you should obtain maintenance at **5,000 miles**; don't wait until six months.

Be sure to keep an eye on your mileage so that you obtain maintenance when recommended. If you are a low-mileage driver, mark your calendar to remind yourself to obtain maintenance every six months.

Special Operating Conditions

In addition to standard maintenance items, vehicles that are driven under special operating conditions require further maintenance service. These special operating conditions, which put added demands on a vehicle, include:

- Driving on dirt roads or on dusty roads
- Repeated trips of less than five miles in temperatures below 32° F or 0° C
- Towing. Not all vehicles are designed for towing. Please refer to the *Owner's Manual* for details.

Some of these special operating conditions require other maintenance items; these items are indicated in each maintenance chart.

If you drive only occasionally under any of the special operating conditions noted, it is not necessary to perform the additional services listed in the charts. This added maintenance is required only if you drive primarily under any of the special operating conditions.

Complimentary First Scheduled Maintenance Service: Six Months or 5,000 Miles

Lexus provides your first scheduled maintenance service at no charge. The service is performed at six months or 5,000 miles, whichever occurs first. To obtain this service, contact your Lexus dealership. Your complimentary service will include these items:

- Inspect and adjust all fluid levels
- Program Lexus Personalized Settings, if requested
- Inspect brake pads and discs
- Inspect wiper blades
- Check installation of driver's floor mat
- Road test vehicle
- Inspect tires

What are Lexus Personalized Settings?

Your vehicle includes a variety of electronic features that can be programmed to your preferences. For example, doors can be programmed to remain locked when you shift into "Park." (For more information, see the "Customizable Features" section of the Specifications chapter in your *Owner's Manual*.) Programming of these features is performed once at no charge, provided you obtain the service at the six-month/5,000-mile scheduled maintenance service. Programming of some Lexus Personalized Settings requires special equipment and may be performed only by an authorized Lexus dealership.

Complimentary Second Scheduled Maintenance Service: 12 Months or 10,000 Miles

Lexus also provides your second scheduled maintenance service at no charge. The service is performed at 12 months or 10,000 miles, whichever occurs first. To obtain this service, contact your Lexus dealership. Your complimentary service will include these items:

- Inspect brake pads and discs
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Check installation of driver's floor mat
- Road test vehicle
- Inspect tires

If you do the majority of your driving under certain special operating conditions, additional items are included in this service. See the "12 Months or 10,000 Miles" chart on page 38.

SCHEDULED MAINTENANCE LOG

6 Months or 5,000 Miles¹

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer³, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

12 Months or 10,000 Miles²

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer³, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹This service, excluding maintenance required for special operating conditions, is complimentary when performed by an authorized Lexus dealership.

²This service is complimentary when performed by an authorized Lexus dealership.

³Not all vehicles are designed for towing. See Owner's Manual for details.

18 Months or 15,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Body	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive shaft boots	<input type="checkbox"/> Traction battery coolant

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer³, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

24 Months or 20,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

30 Months or 25,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

36 Months or 30,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Replace brake fluid
- Replace cabin air filter
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> e-transaxle fluid
<input type="checkbox"/> Body	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake pad and disc thickness and disc runout	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive shaft boots	<input type="checkbox"/> Traction battery coolant

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

MAINTENANCE

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

42 Months or 35,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

48 Months or 40,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

54 Months or 45,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Body	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive shaft boots	<input type="checkbox"/> Traction battery coolant

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

60 Months or 50,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

5.5 Years or 55,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

6 Years or 60,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Replace brake fluid
- Replace cabin air filter
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> e-transaxle fluid
<input type="checkbox"/> Body	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake pad and disc thickness and disc runout	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive shaft boots	<input type="checkbox"/> Traction battery coolant

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Replace e-transaxle fluid
- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

6.5 Years or 65,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

7 Years or 70,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

7.5 Years or 75,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Body	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive shaft boots	<input type="checkbox"/> Traction battery coolant

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

8 Years or 80,000 Miles

- Check installation of driver's floor mat
- Fill air conditioner refrigerant (within states with ZEV regulation)
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

8.5 Years or 85,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

9 Years or 90,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Replace brake fluid
- Replace cabin air filter
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> e-transaxle fluid
<input type="checkbox"/> Body	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake pad and disc thickness and disc runout	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive shaft boots	<input type="checkbox"/> Traction battery coolant

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

9.5 Years or 95,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

10 Years or 100,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

10.5 Years or 105,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Body	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive shaft boots	<input type="checkbox"/> Traction battery coolant

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

11 Years or 110,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

11.5 Years or 115,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

12 Years or 120,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Replace brake fluid
- Replace cabin air filter
- Replace heater coolant
- Replace traction battery coolant
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Drive shaft boots
<input type="checkbox"/> Body	<input type="checkbox"/> e-transaxle fluid
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake pad and disc thickness and disc runout	<input type="checkbox"/> Tires

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Replace e-transaxle fluid
- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

12.5 Years or 125,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

13.0 Years or 130,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

13.5 Years or 135,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Body	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Tires
<input type="checkbox"/> Drive shaft boots	<input type="checkbox"/> Traction battery coolant
<input type="checkbox"/> e-transaxle fluid	

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

SCHEDULED MAINTENANCE LOG

14 Years or 140,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

14.5 Years or 145,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Inspect tires
- Road test

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Inspect ball joints and dust covers
- Inspect drive shaft boots
- Inspect rack-and-pinion assembly
- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

15 Years or 150,000 Miles

- Check installation of driver's floor mat
- Inspect and adjust all fluid levels
- Inspect wiper blades
- Inspect brake pads and discs
- Replace brake fluid
- Replace cabin air filter
- Road test
- Replace Smart Key battery
- Inspect the following:

<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Drive shaft boots
<input type="checkbox"/> Body	<input type="checkbox"/> Heater coolant
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Rack-and-pinion assembly
<input type="checkbox"/> Brake pad and disc thickness and disc runout	<input type="checkbox"/> Tires
	<input type="checkbox"/> Traction battery coolant

Note: If Driving in heavy traffic, on dirt roads or in urban, dusty or desert areas may shorten the life of the cabin air filter. Replacement may be needed if you notice reduced airflow from the air conditioner and heater or if the windows fog easily when you use the "Fresh" mode. Consult your dealer if any of these conditions occur.

If you drive primarily under either of these special operating conditions, perform these additional items:

Driving on dirt roads or on dusty roads:

- Tighten nuts and bolts on chassis and body

Towing a trailer¹, using a car-top carrier or heavy vehicle loading:

- Tighten nuts and bolts on chassis and body

Date: _____ Mileage: _____

¹Not all vehicles are designed for towing. See Owner's Manual for details.

The following descriptions are provided to give you a better understanding of the maintenance services that should be performed on your vehicle. The scheduled maintenance log indicates at which time/mileage intervals each service should be performed. Please note that many maintenance services should be performed only by a qualified technician.

For further information on maintenance services that you can perform yourself, see the maintenance sections of your *Owner's Manual*.

Air Conditioning Refrigerant

Inspect and adjust refrigerant level at specified intervals. A qualified technician should perform these operations.

Drive Shaft Boots

Check the drive shaft boots and clamps for cracks, deterioration and damage. Replace any deteriorated or damaged parts and, if necessary, repack the grease. A qualified technician should perform these operations.

Ball Joints and Dust Covers

Check the suspension and steering linkage ball joints for looseness and damage. Check all dust covers for deterioration and damage. A qualified technician should perform these inspections.

Brake Lines and Hoses

Visually inspect for proper installation. Check for chafing, cracks, deterioration and signs of leakage. Replace any deteriorated or damaged parts. A qualified technician should perform these operations.

Brake Pads and Discs

Check brake pads and rotors for excessive wear; check brake rotors for runout. Check brake calipers for fluid leakage. A qualified technician should perform these inspections.

Cabin Air Filter

Replace at specified intervals. More frequent replacement may be required when driving in dusty conditions, heavy traffic areas, urban areas, desert areas or dirt roads. Refer to your *Owner's Manual* for service details.

Driver's Floor Mat

- Only use the driver's floor mat designed specifically for the model and model year of your vehicle, such as Lexus Genuine floor mats.
- Always properly secure the driver's floor mat using the retaining hooks.
- Never install another floor mat on top of the existing driver's floor mat.
- Never install the driver's floor mat upside down.

e-transaxle Fluid

Inspect or replace at specified intervals. When performing inspections, check each component for signs of leakage. If you discover any leakage, have it repaired by a qualified technician immediately.

Heater Coolant

Drain the cooling system and refill with an ethylene-glycol type coolant. Inspect hoses and connections for corrosion and leaks. Tighten connections and replace parts when necessary. A qualified technician should perform these operations. (For further details, refer to "Radiator, Condenser and Hoses" in the "Maintenance and Care" section of the *Owner's Manual*).

Your Lexus is equipped with Genuine Lexus Super Long-Life Coolant. The replacement intervals for heater coolant recommended in this booklet are based on replacement with Genuine Lexus Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids). If another type of ethylene-glycol coolant is used, replacement intervals may be different.

Nuts and Bolts on Chassis

Check that tightness of the seat-mounting bolts and front/rear suspension-member retaining bolts matches torque measurements specified in the *Repair Manual*.

Rack-and-Pinion Assembly

With the vehicle stopped, check for excessive freeplay in the steering wheel. Inspect the linkage for bending and damage and the dust boots for deterioration, cracks and damage. Replace any damaged parts. A qualified technician should perform these operations.

Traction Battery Coolant

Inspect hoses and connections for corrosion and leaks. Tighten connections and replace parts when necessary. A qualified technician should perform these operations.

In order to ensure maximum performance of the traction battery cooling system and limit risks of battery short-circuit and other damage to using “Lexus Genuine Traction Battery Coolant” or similar high-quality ethylene glycol-based, low electric conductivity coolant, non-amine and non-borate coolant withazole additives. Lexus cannot guarantee that the use of a product other than “Lexus Genuine Traction Battery Coolant” will prevent risks of battery short-circuit or other damage.

Wiper Blades

The wiper blades should not show any signs of cracking, splitting, wear, contamination or deformation. The wiper blades should clear the windshield without streaking or skipping.

VEHICLE IDENTIFICATION

Model _____

In-service date _____

Mileage at delivery _____

Selling dealership _____

Selling dealership phone number _____

Vehicle Identification Number _____

MAINTENANCE

Alternate Transportation	5
Drive shaft boots	38-57*; 58
Ball joints and dust covers	38-57*; 58
Battery: 12-volt (auxiliary battery)	inside front cover, 32
Body inspection	38-57*
Body repairs	7
Brakes	
Fluid	32, 38-57*; 58
Lines and hoses	38-57*; 58
Pads and discs	38-57*; 58
Cabin air filter	38-57*; 58
Complimentary services	
Maintenance services	4-5, 35-36
Other services	5-6
Dispute resolution	10-13, 23
Driver's floor mat	38-57*; 59
Emergency repairs	27-28
Inspections, general maintenance	32-33
Keys	8
Lexus Personalized Settings	1, 4, 35
Maintenance	
As related to warranty coverage	30
Complimentary first and second services	4-5, 35-36
Explanation of maintenance items	58-62
General maintenance and inspections	32-33
Importance of maintenance	29
Maintenance intervals	34
Scheduled maintenance log	38-57
Where to obtain maintenance	inside front cover, 26, 31


* See *scheduled maintenance log* for maintenance interval.

Nuts and bolts on chassis.....	38-57*,60
Owner responsibilities.....	25-28
Parts replacement.....	7-8,19
Pre-delivery service.....	1
Quality control.....	7
Road test.....	38-57*
Roadside assistance.....	1,6
Safety precautions.....	inside front cover
Service agreements.....	7
Service history.....	7
Rack-and-pinion assembly.....	38-57*,60
Tire inspections.....	32
Tires, warranty coverage.....	24-25
Travel protection.....	5
Warranty coverages	
Basic.....	20
Corrosion perforation.....	21
Coverages at a glance.....	16-17
General provisions.....	18-19
Powertrain.....	20
Restraint systems.....	20
Tires.....	24-25
Towing.....	21
What is not covered.....	19, 21-23, 25, 32
Wiper blades.....	38-57*,60

* See scheduled maintenance log for maintenance interval.



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL

FIRST-CLASS MAIL

PERMIT NO.88

PLANO TX

POSTAGE WILL BE PAID BY ADDRESSEE

LEXUS BRAND ENGAGEMENT CENTER
LEXUS A DIVISION OF TOYOTA MOTOR SALES USA INC
PO BOX 259001
PLANO TX 75025-9830





23-TCS-17313
Printed 11/23



0050524WSGRZ