

## 2004 ES 330

Mileage	Content
5000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 <sup>2</sup>
10000	Replace engine oil and oil filter
	Replace air conditioner filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
15000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1, #2
20000	Replace engine oil and oil filter
	Replace air conditioner filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
25000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 <sup>2</sup>
30000	Replace engine oil and oil filter
	Measure brake pad thickness and rotor runout
	Replace air conditioner filter
	Replace brake fluid
	Replace engine air filter
	Rotate tires
	Road test vehicle
Inspection #1, #2, & #3	
35000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 <sup>2</sup>
40000	Replace engine oil and oil filter
	Replace air conditioner filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
45000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1, #2
50000	Replace engine oil and oil filter
	Replace air conditioner filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
55000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 <sup>2</sup>
60000	Replace engine oil and oil filter
	Measure brake pad thickness and rotor runout
	Replace brake fluid
	Replace engine air filter
	Rotate tires
65000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 <sup>2</sup>
70000	Replace engine oil and oil filter
	Replace air conditioner filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
75000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1, #2
80000	Replace engine oil and oil filter
	Replace air conditioner filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
85000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 <sup>2</sup>
90000	Replace engine oil and oil filter
	Measure brake pad thickness and rotor runout
	Replace air conditioner filter
	Replace brake fluid
	Replace engine air filter
	Replace timing belt
	Rotate tires
	Road test vehicle
	Inspect drive belts
Inspect differential oil	
Inspection #1, #2, #3	
95000	Replace engine oil and oil filter
	Rotate tires
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 <sup>2</sup>
100000	Replace engine oil and oil filter
	Replace coolant
	Replace air conditioner filter
	Rotate tires
	Visually inspect brake pads/discs

### Inspection #1

- Ball joints and dust covers
- Drive shaft boots
- Engine Air Filter
- Nuts & Bolts on Chassis
- Steering linkage and boots

<sup>1</sup> Reset "Maint Req'd" light after replacing engine oil

<sup>2</sup> Required only if vehicle is operated primarily on dirt roads

### Inspection #2

- Body
- Brake lines and hoses
- Differential oil
- Exhaust pipes and mountings
- Rack and pinion assembly
- Engine Coolant

### Inspection #3

- Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses
- Fuel tank cap gasket
- Transmission Fluid