

2004 IS 300

Mileage	Content
5000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
10000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
15000	Replace engine oil and oil filter
	Rotate tires (except IS 300 Sportcross)
	Re- Torque drive shaft flange bolts
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1, #2
20000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
25000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
30000	Replace engine oil and oil filter
	Measure brake pad thickness and rotor runout
	Replace air conditioner filter
	Replace brake fluid
	Replace engine air filter
	Re- Torque drive shaft flange bolts
Rotate tires (except IS 300 Sportcross)	
Road test vehicle	
Inspection #1, #2, & #3	
35000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
40000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
45000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1, #2
50000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
55000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²

Inspection #1

- Ball joints and dust covers
- Drive shaft boots
- Engine Air Filter
- Nuts & Bolts on Chassis
- Steering linkage and boots

¹ Reset "Maint Req'd" light after replacing engine oil

² Required only if vehicle is operated primarily on dirt roads

60000	Replace engine oil and oil filter
	Measure brake pad thickness and rotor runout
	Replace brake fluid
	Replace engine air filter
	Replace spark plugs
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Road test vehicle
65000	Replace air conditioner filter
	Inspect engine valves clearance (audible)
	Inspect drive belts
	Inspection #1, #2, #3
70000	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
75000	Inspection #1 ²
	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
80000	Road test vehicle
	Inspection #1 ²
	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
	Rotate tires (except IS 300 Sportcross)
85000	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
	Replace engine oil and oil filter
	Re- Torque drive shaft flange bolts
90000	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²
	Replace engine oil and oil filter
	Measure brake pad thickness and rotor runout
	Replace air conditioner filter
	Replace brake fluid
	Replace engine air filter
	Replace timing belt
Re- Torque drive shaft flange bolts	
Rotate tires (except IS 300 Sportcross)	
Road test vehicle	
Inspect drive belts	
Inspection #1, #2, #3	
95000	Inspection #1 ²
	Road test vehicle
	Visually inspect brake pads/discs
	Rotate tires (except IS 300 Sportcross)
	Re- Torque drive shaft flange bolts
100000	Replace coolant
	Rotate tires (except IS 300 Sportcross)
	Visually inspect brake pads/discs
	Road test vehicle
	Inspection #1 ²

Inspection #2

- Body
- Brake lines and hoses
- Differential oil
- Exhaust pipes and mountings
- Rack and pinion assembly
- Engine Coolant

Inspection #3

- Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses
- Fuel tank cap gasket
- Transmission Fluid
- Manual transmission oil