TOYOTA

AVALON

Quick Reference Guide

2008 Toyota Navigation System

AVALON

DEMONSTRATION MODE:

To view the demonstration mode, use the dial to highlight the ■ next to start. While start is highlighted, press and hold the dial until the system beeps to indicate that the demo mode has begun.

To end the demo mode, press MENU on the control panel.

EMERGENCY SCREEN:

To access the Emergency screen, press DEST on the control panel. Use the dial to highlight ⚠, then press the dial.

The emergency screen will appear and offer several choices.

SAFETY INSTRUCTIONS

This system is intended to assist you in reaching your destination and, if used properly, can do so. To use your system as safely as possible, follow all safety instructions.

YOU, AS THE DRIVER, ARE SOLELY RESPONSIBLE FOR THE SAFE OPERATION OF YOUR VEHICLE AND THE SAFETY OF YOUR PASSENGERS. DO NOT USE ANY FEATURE OF THIS SYSTEM TO THE EXTENT IT DISTRACTS YOU FROM SAFE DRIVING. YOUR FIRST PRIORITY WHILE DRIVING SHOULD ALWAYS BE THE SAFE OPERATION OF YOUR VEHICLE.

- Before attempting to use this system while driving, learn how to use it. Read the entire Navigation System Manual to make sure you understand the system. Do not allow others to use this system until they have read and understand these and other instructions in this manual.

- You can input your destination and select your route only when your vehicle is not moving. While driving, listen to the voice instructions as much as possible and glance at the screen briefly and only when safe.

- The data in the system may occasionally be incomplete. Road conditions, including driving restrictions (no left turns, street closures, etc.) frequently change. Therefore, before you follow any instruction from the system, look to see whether you can comply with the instruction safely and legally. The map database is normally updated once a year. Contact your dealer for information about the availability and pricing of an update.

- This system cannot warn you about such things as the quality of a neighborhood, street conditions, and availability of emergency services. If you are unsure about the safety of an area, don't drive into it.

UNDER NO CIRCUMSTANCES IS THIS SYSTEM A SUBSTITUTE FOR THE DRIVER'S PERSONAL JUDGMENT.

- Use this system only in locations where it is legal to do so. Some states/provinces may have laws prohibiting video screens within sight of the driver.

TOYOTA AVALON NAVIGATION SYSTEM CONTROL PANEL

MAP/VOICE Button
Repeat the last voice guidance command, cancel the map scroll or initiate a system guidance.

MENU Button
Display the MENU screen to make adjustments or to correct settings of various options and functions.

CLIMATE Button
Display the climate control screen.

ZOOM OUT Button
Reduce the map scale.

BACK Button
Go back to the previous screen.

INFO Button
Access the Maintenance, Calendar or Language screen.

Navigation Voice Recognition Switch

AUDIO Button
Display the audio screen to set radio stations, balance the sound or scan the radio stations automatically.

ZOOM IN Button
Magnify the map scale.

DEST Button
Display the destination screen input options:
- ADDRESS
- POI
- HOME
- MARKED POINT

DISP Button
Access the DISPLAY screen to make adjustments to the brightness, contrast or switch off the screen.

ENTER Button
This button has a dual function. Toggle the button up, down, left or right to choose a selection. Press down on the ENTER button to make a selection.

DESTINATION INPUT

step 1
Read the CAUTION screen, use to select English or French and press. Use to select I agree and press.

step 2
The map screen appears. Press DEST on the control panel to access the destination screen.

step 3
Make sure that you are in the desired search area. Use to select (Address) and press to access the address screen.

step 4
Use to select House No. and press. To input the street address number, use to highlight the number and press.

step 5
Select Street and press. Highlight the desired letter and press. The List function provides an optional search method.

step 6
Use to scroll up and down the list of streets. Highlight the by the desired street and press.

step 7
Use to highlight the next to Enter and press. The system will begin searching the route.

step 8
Begin driving.

POINT OF INTEREST INPUT

step 1
Read the CAUTION screen, use to select English or French and press. Use to select I agree and press.

step 2
Press DEST on the control panel. Make sure that you are in the desired search area. Use to select (POI) and press.

step 3
Use to select Name and press. To view the POI categories, select Category and press.

step 4
To input the POI name, use to highlight the desired letters and press. The List function provides an optional search method.

step 5
Use to scroll up and down the list of POIs. Highlight the by the desired POI and press.

step 6
Use to highlight the next to Enter and press. The system will begin searching the route.

step 7
Begin driving. To add an additional destination to the route, repeat steps 2-6 and then step 8.

step 8
Use to highlight Add and press. To delete the current destination, use to highlight Renew and press.