

BASIC OPERATION

Must be detached
to access **On/Off** button

Push to detach
screen from
main unit.




Quick Tip: The TomTom unit can be used without being docked.

Note: To reattach the navigation unit, slide it from left to right, then push in the right side.

LIMITATIONS OF THIS QUICK REFERENCE GUIDE


This Quick Reference Guide is designed to provide information on the basic operation and key features of the navigation system. The Quick Reference Guide is not intended as a substitute for the Navigation Owner's Manual. We strongly encourage you to review the Navigation Owner's Manual so you will have a better understanding of the navigation system capabilities and limitations.

REGISTER/CHANGE HOME LOCATION




1 Touch the map area to bring up Main Menu. Touch .

2 Touch  to navigate to next screen and touch .



3 Touch .

4 Touch  , or  . See tip below.



5 Input, then touch the city name. Input, then touch the street name.

6 Enter the house number and touch .

3


Tip: For security reasons, use a point close to your home instead of your actual home address.

DESTINATION INPUT

BY ADDRESS




1 Touch the map area to bring up Main Menu. Touch .




2 Touch .


Quick Tip: Touch  if the destination has been previously entered.



3 Touch .



4 Input, then touch the city name. Input, then touch the street name.



5 Enter the house number and touch . See page 11 to enter an arrival time.




6 Touch  to view route information, or touch  to begin route guidance.

DESTINATION INPUT – POINTS OF INTEREST (POI)


POINTS OF INTEREST BY NAME




1 Touch the map area to bring up Main Menu. Touch .



2 Touch .




3 Touch . Input city name then select from provided options.



4 Touch .





5 Input the POI name and touch . Touch the desired destination.



6 Touch  to view route information, or touch  to begin route guidance.



DESTINATION INPUT – POINTS OF INTEREST (POI)

POINTS OF INTEREST BY CATEGORY




1 Touch the map area to bring up Main Menu. Touch  .

2 Touch  .



3 Touch  .

4 Touch  to see the points of interest in the vicinity.




5 Input POI category (see pg. 14), or scroll  or  if necessary. Touch the desired category and then touch the desired destination.

6 Touch  to view route information, or touch  to begin route guidance.


BLUETOOTH TELEPHONE PAIRING




1 Touch the map area to bring up Main Menu. Touch .




2 Touch . Verify that Bluetooth feature on the phone is ON and is in discoverable mode, touch .



3 Input the password listed on the screen into your mobile phone. Touch  and then touch  again.



4 You will be informed if your phone has wireless data connection capabilities. Touch .




5 To transfer cell phone book, touch .

Quick Tip: Verify that your Bluetooth cell phone has been approved by visiting www.Toyota.Letstalk.com.

Quick Tip: After a device is paired, touch ,  and  to register additional devices.




1 Touch the map area to bring up Main Menu. Touch .




2 The TomTom must be docked to make hands-free calls. Touch .



3 Touch .



4 Dial phone number. Touch .




5 To end call, touch map screen and select . Touch .

RECEIVING A CALL

To receive an incoming call, touch .

ADDITIONAL NAVIGATION FEATURES


DRIVING VIEW



- 1 Touch to magnify or reduce the map scale.
- 2 Indicates the current position of the vehicle.
- 3 Name of the next major road or road sign information, if applicable.
- 4 Next instruction.
- 5 Name of the next street to turn onto.
- 6 Information about trip (displays remaining trip time, remaining distance and arrival time.)
- 7 Indicates strength of GPS signal.

ADDITIONAL NAVIGATION FEATURES

ARRIVAL TIME



Touch  and input desired arrival time. Touch .

MORE ROUTE INFORMATION




Once destination is selected touch  for different ways to view your complete route.

FIND ALTERNATIVE ROUTES




Main Menu > Touch .

START-UP PREFERENCES




Main Menu > Touch , use  to navigate to .

PLANNING PREFERENCES



Main Menu > Touch , use  to navigate to .



TOLL ROAD PREFERENCES



Main Menu > Touch , use  to navigate to .



ADDITIONAL NAVIGATION FEATURES

SAFETY PREFERENCES





Main Menu > Touch  >  .

SET CLOCK



Main Menu > Touch  , use  to navigate to  .

KEYBOARD SETTINGS



Main Menu > Touch  , use  to navigate to  .

ICON INDEX

Main Menu

Menu 1 of 3

- Navigate to...
- Find alternative...
- TomTom Traffic
- Mobile Phone
- Change preferences

Menu 3 of 3

- TomTom Weather
- TomTom PLUS Services
- Clear route
- Guided tours
- Slow version

Preferences *

Preferences 1 of 7

- Use night colors
- Turn on 3D display
- Safety preferences
- Enable/disable POIs
- Turn off sound

Preferences 3 of 7

- Status bar preferences
- Set clock
- Docking preferences
- Change map colors
- Brightness preferences

Preferences 5 of 7

- Set units
- Operate left-handed
- Keyboard preferences
- Name preferences
- Hide tips

Preferences 7 of 7

- Bluetooth preferences
- Disable wireless data
- Show fewer menu options
- Do not ask arrival time
- Reset factory settings

Menu 2 of 3

- Advance planning
- Browse map
- View route
- Add Favorite
- Itinerary planning

Preferences 2 of 7

- Volume preferences
- Manage Favorites
- Change Home location
- Manage maps
- Manage POIs

Preferences 4 of 7

- Planning preferences
- Toll road preferences
- Compass preferences
- Change voice
- Change language

Preferences 6 of 7

- Set owner
- Disable ASN
- Configure GPS
- Edit TomTom PLUS account
- Start-up preferences

* **Show ALL menu options**
(Preferences menu) must be selected
to view all buttons and features listed.

POI CATEGORIES

Airport	Gas station	Post office
Amusement park	Golf course	Railway station
ATM/Bank Machine	Hospital/clinic	Rest area
Beach	Hotel/motel	Restaurant
Border crossing	Ice skating rink	School
Camping ground	Library	Shopping center
Car dealership	Marina/Yacht Club	Sports center
Car rental facility	Movie Theater	Stadium
Car repair/garage	Museum	Swimming pool
Casino	Nightlife	Tennis court
College/university	Open parking	Theater
Company	Park and recreation area	Tourist attraction
Concert hall	Parking garage	Tourist information office
Convention center	Pharmacy	Winery
Cultural center	Place of worship	Zoo
Exhibition center	Playing field	
Ferry terminal	Police station	
Fire stations		

TOMTOM PLUS

TomTom PLUS is an optional collection of services that keeps you informed and entertained while on the road.

You can subscribe to a range of extras and either download them directly to your TomTom, or download them to your computer and then transfer them to your TomTom.

- Traffic
- Safety cameras
- Maps
- Voices
- Buddies
- Weather
- Points of Interest

*Not all services are available in all countries.
For more information, visit www.tomtom.com/plus.*



Customer Experience Center
1-800-331-4331