

## DEMONSTRATION MODE



To view the demonstration mode, use to highlight the next to start. While start is highlighted, press and hold until the system beeps to indicate that the demo mode has begun.



To end the demo mode, press on the control panel.

## EMERGENCY SCREEN



To access the Emergency screen, press on the control panel. Use to highlight , then press .



The emergency screen will appear and offer three emergency choices. When you select an option while the vehicle is in motion, the system will show nearest locations.

## SAFETY INSTRUCTIONS

This system is intended to assist you in reaching your destination and, if used properly, can do so. To use your system as safely as possible, follow all safety instructions.

**YOU, AS THE DRIVER, ARE SOLELY RESPONSIBLE FOR THE SAFE OPERATION OF YOUR VEHICLE AND THE SAFETY OF YOUR PASSENGERS. DO NOT USE ANY FEATURE OF THIS SYSTEM TO THE EXTENT IT DISTRACTS YOU FROM SAFE DRIVING. YOUR FIRST PRIORITY WHILE DRIVING SHOULD ALWAYS BE THE SAFE OPERATION OF YOUR VEHICLE.**

- Before attempting to use this system while driving, learn how to use it. Read the entire Navigation System Owner's Manual to make sure you understand the system. Do not allow others to use this system until they have read and understand these and other instructions in this manual.
- You can input your destination and select your route only when your vehicle is not moving. While driving, listen to the voice instructions as much as possible and glance at the screen briefly and only when safe.
- The data in the system may occasionally be incomplete. Road conditions, including driving restrictions (no left turns, street closures, etc.) frequently change. Therefore, before you follow any instruction from the system, look to see whether you can comply with the instruction safely and legally. The map database is normally updated once a year. Contact your dealer for information about the availability and pricing of an update.
- This system cannot warn you about such things as the quality of a neighborhood, street conditions, and availability of emergency services. If you are unsure about the safety of an area, don't drive into it.

**UNDER NO CIRCUMSTANCES IS THIS SYSTEM A SUBSTITUTE FOR THE DRIVER'S PERSONAL JUDGMENT.**

- Use this system only in locations where it is legal to do so. Some states/provinces may have laws prohibiting video screens within sight of the driver.


# 2009 Toyota Navigation System

## Quick Reference Guide


# AVALON



# Toyota Avalon Navigation System CONTROL PANEL



NAVIGATION VOICE RECOGNITION BUTTON



CLIMATE Button  
Display the climate control screen.

MAP/VOICE Button  
Repeat the last voice guidance command, cancel the map scroll or initiate a system guidance.

ZOOM OUT Button  
Reduce the map scale.

BACK Button  
Go back to the previous screen.

MENU Button  
Access or modify map appearance, set-up, volume and marked points.

INFO Button  
Access Maintenance, Calendar or Language screen.

AUDIO Button  
Set the radio station presets, and adjust the balance and tone controls.


ZOOM IN Button  
Magnify the map scale.

ENTER Button  
This button has dual function. Toggle the button up, down, left or right to choose a selection. Press down on the ENTER button to confirm the selection.


DEST Button  
Display the destination screen input options:  
 ADDRESS  
 POI  
 HOME  
 MARKED POINTS

DISP Button  
Access the DISPLAY screen to make adjustments to the brightness, contrast or turn off the screen.

## DESTINATION INPUT by ADDRESS



**step 1** Read the CAUTION screen, use to select English or French and press . Use to select and press .



**step 2** The map screen appears. Press on the control panel to access the destination screen.



**step 3** Make sure that you are in the desired search area. Change search area by selecting if necessary. Use to select and press to access the address screen.



**step 4** Use to select and press . To input the street address number, use to highlight the number and press .



**step 5** Select and press . Highlight the desired letter and press . The function provides an optional search method.



**step 6** Use to scroll up and down the list of streets. Highlight the by the desired street and press .



**step 7** Use to highlight the next to Enter and press . The system will begin searching the route.



**step 8** Begin driving.

## DESTINATION INPUT by POINT OF INTEREST • If CAUTION screen is displayed, read and select "I agree."



**step 1** Press on the control panel. Make sure that you are in the desired search area. Use to select and press .



**step 2** Use to select and press . To view the POI categories, select and press .



**step 3** To input the POI name, use to highlight the desired letters and press . The function provides an optional search method.



**step 4** Use to scroll up and down the list of POIs. Highlight the by the desired POI and press .



**step 5** Use to highlight the next to Enter and press . The system will begin searching the route.



**step 6** Begin driving. To add an additional destination to the route, repeat steps 1-5 and then step 7.



**step 7** Use to highlight and press . To delete the current destination, use to highlight and press .