



Customer Experience Center 1-800-331-4331



*2009 Navigation System
Quick Reference Guide*

TABLE OF CONTENTS

LIMITATIONS OF THIS QUICK REFERENCE GUIDE	1
BASIC OPERATION	2
DESTINATION INPUT	3
<i>By Address</i>	3
DESTINATION INPUT - POINTS OF INTEREST (POI)	5
<i>Points of Interest by Name</i>	5
<i>Points of Interest by Category</i>	6
DESTINATION INPUT - TELEPHONE NUMBER	7
<i>Business or Registered Memory Points</i>	7
REGISTER HOME	8
ADDITIONAL NAVIGATION FEATURES	10
<i>Search Area</i>	10
<i>Route Preferences</i>	10
<i>3 Routes</i>	10
<i>Screen Preferences</i>	10
<i>Beep Setting</i>	11
<i>Volume Setting</i>	11
<i>Keyboard Setting</i>	11
<i>Screen Transition</i>	11
<i>Freeway Exit Info Mode</i>	11
<i>Estimated Distance and Time</i>	12
<i>Operation of Your Vehicle Emergency Screen</i>	12
XM NAVTRAFFIC®	13

LIMITATIONS OF THIS QUICK REFERENCE GUIDE

This Quick Reference Guide is designed to provide information on the basic operation and key features of the navigation system. The Quick Reference Guide is not intended as a substitute for the Navigation Owner's Manual. We strongly encourage you to review the Navigation Owner's Manual so you will have a better understanding of the navigation system capabilities and limitations.

XM NAVTRAFFIC® PREFERENCES



step 1 Press the **MENU** panel button, and then touch .



step 2 Select preferences.

- 1 Show XM NavTraffic Information:** Touch  to display traffic information on the map. Traffic flow is displayed by color lines right along the side of the freeways:
 -  Free flow traffic
 -  Light traffic jam
 -  Heavy traffic jam
- 2 Auto Avoid Traffic:** Touch  to make selecting another route offered by the system when heavy or moderate traffic is detected on the guidance route.
- 3 Traffic Voice Guidance:** Touch  to have traffic information provided using voice guidance.
- 4 Show Free Flowing Traffic:** Touch  to show free flowing traffic illustrated by green arrows on the map.



- 1 NORTH UP OR COMPASS MODE Icon**
Touch to change the map display between North-up or Head-up perspectives.
- 2 ZOOM IN/ZOOM OUT Icons**
Touch to magnify or reduce the map scale.
- 3 INFO Button**
Access Maintenance, Telephone, Calendar, Language, and Screen Settings.
- 4 DISPLAY/TILT Button**
Adjust the contrast, brightness or turn off the screen. Change the angle of the screen for best viewing.
- 5 AUDIO Button**
Set the radio station presets, adjust the balance and tone controls.
- 6 MENU Button**
Access Voice Guidance Volume, Select User, My Places, Setup and Suspend Guidance.
- 7 DESTINATION Button**
Input the destination by one of several methods and initiate route guidance.
- 8 MAP/VOICE Button**
Repeat the last voice guidance prompt or cancel one touch scroll.
- 9 CURRENT VEHICLE POSITION Mark**
Indicates the current position of the vehicle and its directional heading.

DESTINATION INPUT

BY ADDRESS



step 1 Press the **DEST** panel button followed by  and move to step 3. To change Search Area, touch  and move to step 2.



step 2 Select the appropriate Search Area, then touch OK to confirm the selection.



step 3 Input the house number using the number keys.



step 4 Touch  and input the street name using the letter keys. Touch  to see all of the available options.



step 5 Use  or  to scroll up or down one page if necessary. Touch the desired street.




step 6 Touch  to type in the city name or select from a previously registered city. If the city is not available try the next largest city in the vicinity.

DESTINATION INPUT

BY ADDRESS




step 7 Use  or  to scroll up or down one page if necessary. Touch the desired city.



step 8 Select the desired Route Preference by touching the Route Preference icon.



step 9 Select the desired Route Preference(s) for the trip. When the yellow bar appears, the route has been selected. Touch  to confirm your selection.



step 10 If necessary, use the arrow keys to adjust the position on the map to put you closer to your destination. Touch  to confirm the position.



step 11 Touch .


Quick Tip - Enter the street name without prefixes such as North or the letter N. The system will display all of the options available.

DESTINATION INPUT - POINTS OF INTEREST (POI)

POINTS OF INTEREST BY NAME




step 1 Press the **DEST** panel button followed by **POI** icon to access points of interest by name.



step 2 Touch **Search by Name**.



step 3 Input the POI name using the letter keys and then touch **List**.



step 4 Use **Up** or **Down** to scroll up or down one page if necessary. Touch the desired selection.



step 5 Select the desired Route Preference and then touch **Enter**.



step 6 Touch **Guide**.

Quick Tip - If the POI isn't listed in the database verify the spelling and Search Area for accuracy.


Quick Tip - Touching the **Info** button next to the POI name will display the address and telephone number.

DESTINATION INPUT - POINTS OF INTEREST (POI)

POINTS OF INTEREST BY CATEGORY



step 1 Press the **DEST** panel button followed by the **POI** icon to access the points of interest by category.



step 2 Touch **Search by Category**.



step 3 Touch the **Current Position** icon to search for points of interest in the vicinity.



step 4 Touch the **Travel** icon.



step 5 Touch the **Travel** icon followed by OK and then touch **Travel** to see the points of interest in the vicinity.



step 6 Use **Up** or **Down** to scroll up or down one page if necessary. Touch the point of interest followed by **Enter** and then **Change**.

DESTINATION INPUT - TELEPHONE NUMBER


BUSINESS OR REGISTERED MEMORY POINTS



step 1 Press the **DEST** panel button followed by the  icon.



step 2 Input the area code and telephone number using the number keys followed by the  icon. It is not necessary to dial "1."



step 3 Select the business or assigned memory point from the screen.



step 4 Select the desired Route Preference and then touch **Enter**.



step 5 Touch **Guide**.



step 1 Press the **MENU** panel button followed by the **My Places** icon to register your home.



step 2 Touch **Register** to input your home address.

Tip - For security reasons, use a point close to your home instead of your actual home address.



step 3 Make sure that you are in the desired Search Area. Touch the **Address** icon to begin address input.



step 4 Input the house number using the number keys.



step 5 Touch **Street** and input the street name using the letter keys. Touch **List** to see all of the available options.




step 6 Touch **Input City Name** or select from a previously registered city.

REGISTER HOME



step 7 Touch the desired city.



step 8 If necessary use the arrow keys to adjust the position on the map. Touch **Enter** to confirm the position.



step 9 Touch **Icon** at the top left of the screen to change the home icon.



step 10 Touch the desired icon for your home.




step 11 Touch **OK** at the bottom of the screen. Press the **MAP VOICE** panel button to complete the registration of your home.

ADDITIONAL NAVIGATION FEATURES

SEARCH AREA



Prior to inputting the desired address select the appropriate Search Area by pressing **Change**. If the incorrect Search Area is chosen, the system will either find an address that closely matches in that area or will indicate that the address cannot be found.



Select the appropriate Search Area, then touch OK to confirm the selection.

ROUTE PREFERENCES



Once the address has been inputted, select the desired route preference(s) for the trip. For example, if Allow Toll Roads is not selected, the system will route over non-toll roads which may take longer to reach the destination.

3 ROUTES




One of the three routes may be chosen for the trip. Quick 1 offers the shortest route by time; Quick 2 is the second fastest route. Short is the most direct route based upon driven mileage.

* The system does not account for traffic signals or traffic flow.

SCREEN PREFERENCES



Touch  to select from seven different screen viewing options. Three screen preferences are available when the map is visible and four additional are available during route guidance only. Please refer to the list of screen preferences located below.



ADDITIONAL NAVIGATION FEATURES

BEEP SETTING



PRESS INFO > BEEP OFF

Switch off the confirmation tone by touching **Beep Off** at the top of the screen. When the yellow bar appears this feature has been disabled.

VOLUME SETTING



PRESS MENU > VOLUME

The Volume feature allows for the adjustment of the voice guidance commands. Touch the desired volume level and touch OK to confirm your selection.


KEYBOARD SETTING



PRESS MENU > SETUP

Set the layout of the keyboard as alphabetical or standard QWERTY keyboard. Touch OK to confirm your selection.

SCREEN TRANSITION



PRESS INFO > SCREEN SETTING

Touch OFF to prevent the system from reverting to the map display. Once the screen transition is switched off, the audio or climate control screen (if equipped) will remain without reverting to the map display. Touch OK to confirm your selection.

FREEWAY EXIT INFO MODE

During Route Guidance on a Freeway or Toll Road, a variety of points of interest such as Gas Stations, Restaurants or Hotels can be viewed during your trip.

To access this feature, select Freeway Exit Info Mode from the Screen Preferences. Upcoming freeway exits will be listed by the number or name along with the POIs in the vicinity of the exit ramp. Select the desired exit from the list to see the POIs at that particular exit.




* This feature is only available while in Route Guidance and travelling on a freeway or Toll Road.

ADDITIONAL NAVIGATION FEATURES

ESTIMATED DISTANCE AND TIME*

The navigation system will provide an estimate of the distance and time to the destination based upon the suggested route during guidance. The system automatically calculates the remaining miles until you arrive at the destination. Based upon the distance traveled, the system will also provide an estimated time until arriving at your destination.

The system can be customized to match your driving habits. To adjust the speed for residential, main streets or freeways please refer to the Navigation Owner's Manual for a complete description of this feature.



* The system does not account for traffic signals or traffic flow.

OPERATION OF YOUR VEHICLE EMERGENCY SCREEN:



Press the **DEST** button on the navigation face plate. Touch  which will provide four different choices: • Police Stn. • Hospital • Dealer • Fire Stn. Touch to select the desired destination.



Once selected, the system will provide a list of locations sorted by distance. If the vehicle is in motion, the system will route you to the nearest location automatically.

XM NAVTRAFFIC®




XM NavTraffic® is an optional subscription service that can send traffic information gathered by a variety of sources to vehicles with Navigation Systems via XM's satellite network. Displayed traffic information can help your drive by providing freeway traffic and incident information in nearly 80 markets (and expanding) across the U.S.

New Corolla Matrix owners with factory-installed navigation receive a 90-day complimentary trial subscription from XM.

Traffic information provided by XM NavTraffic®:
<http://www.xmradio.com/navtraffic/index.xmc>



Traffic flow.



Road construction and road closures.



Accidents, disabled vehicles and weather-related issues.