

DEMONSTRATION MODE



To view the demonstration mode, use  to highlight the  next to start. While start is highlighted, press and hold  until the system beeps to indicate that the demo mode has begun.



To end the demo mode, press  on the control panel.

EMERGENCY SCREEN



To access the Emergency screen, press  on the control panel. Use  to highlight , then press .



The emergency screen will appear and offer three emergency choices. When you select an option while the vehicle is in motion, the system will show nearest locations.

SAFETY INSTRUCTIONS

This system is intended to assist you in reaching your destination and, if used properly, can do so. To use your system as safely as possible, follow all safety instructions.

YOU, AS THE DRIVER, ARE SOLELY RESPONSIBLE FOR THE SAFE OPERATION OF YOUR VEHICLE AND THE SAFETY OF YOUR PASSENGERS. DO NOT USE ANY FEATURE OF THIS SYSTEM TO THE EXTENT IT DISTRACTS YOU FROM SAFE DRIVING. YOUR FIRST PRIORITY WHILE DRIVING SHOULD ALWAYS BE THE SAFE OPERATION OF YOUR VEHICLE.

- Before attempting to use this system while driving, learn how to use it. Read the entire Navigation System Owner's Manual to make sure you understand the system. Do not allow others to use this system until they have read and understand these and other instructions in this manual.
- You can input your destination and select your route only when your vehicle is not moving. While driving, listen to the voice instructions as much as possible and glance at the screen briefly and only when safe.
- The data in the system may occasionally be incomplete. Road conditions, including driving restrictions (no left turns, street closures, etc.) frequently change. Therefore, before you follow any instruction from the system, look to see whether you can comply with the instruction safely and legally. The map database is normally updated once a year. Contact your dealer for information about the availability and pricing of an update.
- This system cannot warn you about such things as the quality of a neighborhood, street conditions, and availability of emergency services. If you are unsure about the safety of an area, don't drive into it.

UNDER NO CIRCUMSTANCES IS THIS SYSTEM A SUBSTITUTE FOR THE DRIVER'S PERSONAL JUDGMENT.

- Use this system only in locations where it is legal to do so. Some states/provinces may have laws prohibiting video screens within sight of the driver.


2010 Toyota Navigation System

Quick Reference Guide


AVAILON



Toyota Avalon Navigation System CONTROL PANEL



NAVIGATION VOICE RECOGNITION BUTTON



AUDIO Button
Set the radio station presets, and adjust the balance and tone controls.

DESTINATION INPUT by ADDRESS



step 1 Read the CAUTION screen, use **ENTER** to select English or French and press **ENTER**. Use **ENTER** to select **ADDRESS** and press **ENTER**.




step 2 The map screen appears. Press **DEST** on the control panel to access the destination screen.



step 3 Make sure that you are in the desired search area. Change search area by selecting **Change** if necessary. Use **ENTER** to select and press **ENTER** to access the address screen.




step 4 Use **ENTER** to select **House No.** and press **ENTER** to input the street address number, use **ENTER** to highlight the number and press **ENTER**.




step 5 Select **Street** and press **ENTER**. Highlight the desired letter and press **ENTER**. Select **List** to show all matching streets.



step 6 Use **ENTER** to scroll up and down the list of streets. Highlight the street by the desired street and press **ENTER**.



step 7 Use **ENTER** to highlight the **ENTER** next to Enter and press **ENTER**. The system will begin searching the route.



step 8 Begin driving.


DESTINATION INPUT by POINT OF INTEREST • If CAUTION screen is displayed, read and select "I agree."



step 1 Press **DEST** on the control panel. Make sure that you are in the desired search area. Use **ENTER** to select **POI** and press **ENTER**.



step 2 Use **ENTER** to select **Home** and press **ENTER**. To view the POI categories, select **Category** and press **ENTER**.



step 3 To input the POI name, use **ENTER** to highlight the desired letters and press **ENTER**. Select **List** to show all matching locations.




step 4 Use **ENTER** to scroll up and down the list of POIs. Highlight the POI by the desired POI and press **ENTER**.



step 5 Use **ENTER** to highlight the **ENTER** next to Enter and press **ENTER**. The system will begin searching the route.



step 6 Begin driving. To add an additional destination to the route, repeat steps 1-5 and then step 7.



step 7 Use **ENTER** to highlight **Home** and press **ENTER**. To delete the current destination, use **ENTER** to highlight **Home** and press **ENTER**.