

2 0 1 8



PRIUS PRIME

- Entune™ Premium Audio
with Integrated Navigation
- Entune® App Suite
- Prius Prime Apps



ENTUNE™ SYSTEM
QUICK REFERENCE GUIDE

TABLE OF CONTENTS

OVERVIEW	7INCH	11.6INCH
LIMITATIONS OF THE QUICK REFERENCE GUIDE	2	
BASIC MAP OPERATION	2	3-4
INTRODUCTION		
WHAT IS ENTUNE® APP SUITE?, ENTUNE APP SUITE, PHONE COMPATIBILITY		5
WHAT ENTUNE™ SYSTEM DO YOU HAVE?		6
ENTUNE - HOW TO GET STARTED		
BASIC OVERVIEW		7
ACCOUNT CREATION		7
DOWNLOADING ENTUNE® APP SUITE TO YOUR PHONE		7
ENTUNE - NEW CUSTOMER REGISTRATION		
LAUNCH APP, CONNECT PHONE, ACCESSING ENTUNE® APPS	8	8
CONNECT A BLUETOOTH® PHONE		
BLUETOOTH PAIRING FOR ANDROID PHONE AND ENTUNE TOUCH SCREEN SYSTEM	9-11	34
BLUETOOTH PAIRING FOR IPHONE AND ENTUNE TOUCH SCREEN SYSTEM	12-14	34-35
BLUETOOTH PAIRING FOR WINDOWS PHONE AND ENTUNE TOUCH SCREEN SYSTEM	15-17	
ADVANCED VOICE RECOGNITION SYSTEM		
TRAIN VOICE RECOGNITION, VOICE RECOGNITION TUTORIAL	18	36
CALLING BY VOICE RECOGNITION		
DIAL BY NUMBER	19	37
DIAL BY NAME	20	38
DESTINATION INPUT		
BY ADDRESS	21-22	39-40
NOTE ON VOICE RECOGNITION, TIPS FOR USING VOICE RECOGNITION, BY ADDRESS - VOICE RECOGNITION	23	41
DESTINATION INPUT - POINT OF INTEREST (POI)		
POINT OF INTEREST BY NAME	24	42
POINT OF INTEREST BY CATEGORY	25	43
POINT OF INTEREST BY CATEGORY - VOICE RECOGNITION	26	44
SET HOME	27-28	45-46
ADDITIONAL NAVIGATION FEATURES		
OPERATION OF EMERGENCY SCREEN, SEARCH AREA, ROUTE PREFERENCES, 3 ROUTES, SCREEN CONFIGURATIONS	29	47
BEEP SETTING, VOICE VOLUME, LANGUAGE, SYSTEM TIME, AUTO CHANGE TO HOME SCREEN, CACHE RADIO	30	48
TRAFFIC		
TRAFFIC EVENT LIST, PREDICTIVE TRAFFIC MAP	31	49
MY TRAFFIC ROUTES, AUTOMATICALLY AVOID TRAFFIC, TRAFFIC INCIDENT WARNING	32	50
WEATHER	33	51
ENTUNE® APP SUITE FEATURES		
APPS MENU, IHEARTRADIO, MOVIE TICKETS.COM, OPENTABLE, PANDORA, FACEBOOK PLACES		53
YELP, DESTINATION SEARCH		54
SLACKER RADIO		55
SIRI® EYES FREE		56
PRIUS PRIME APPS		
CHARGE MANAGEMENT		57
CHARGING STATION MAP		57
REMOTE CLIMATE		57
ECO DASHBOARD		58
VEHICLE FINDER		58

LIMITATIONS OF THE QUICK REFERENCE GUIDE

The Quick Reference Guide is designed to provide information on the basic operation and key features of the navigation system and Entune™. The Quick Reference Guide is not intended as a substitute for the Navigation Owner's Manual. We strongly encourage you to review the Navigation Owner's Manual, the quick reference guide and visit www.toyota.com/entune so you will have a better understanding of all your vehicles features and controls.

BASIC MAP OPERATION

7 inch screen

NORTH-UP OR COMPASS MODE Icon

Touch to change the map display between North-up or Head-up perspectives.

CURRENT VEHICLE POSITION Mark

Indicates the current position of the vehicle and its directional heading.

AUDIO Button


Access to audio functions.

APPS Button

Access to APPS, Entune® App Suite (MovieTickets.com, OpenTable, etc....) traffic, fuel guide, sports, stocks, weather, and navigation.

HOME Button

Access to Navigation Screen.



ZOOM IN/ZOOM OUT Icons

Touch to magnify or reduce the map scale.

Quick Tip – The USB and AUX port location and design are different depending on the vehicle. For details, see the Owner's Manual.

OVERVIEW

BASIC MAP OPERATION

11.6 inch screen

"Info"

Access to "Energy Monitor", "Fuel consumption", "Traffic information", "Weather information", "Charge Schedule" screen.

"App Suite"

Access to APPS, Entune® App Suite (MovieTickets.com, OpenTable, etc...), sports, stocks, fuel guide, and Charging Station Map.

"Phone"

Access to hands-free phone functions.

"Settings"

Access to the "Setup" screen.

"Destination"

The "Destination" screen enables to search for a destination (Navigation).

HOME Button

Press to display the home (Map) screen.

MENU Button

Press to display the Menu (This) screen.

VOL Button

Press "▲" or "▼" to adjust the volume.

AUDIO Button

Press to turn audio system on and off.

"Display"

Adjust display image and camera image.



Access to Climate Control

Access to Audio Source

Display the menu

Press the  button or swipe upward.



Audio control

Press Audio at the bottom of the screen to access audio control functions.



Hide the menu Press the  button or Swipe downward.

3 shortcuts

The first 3 buttons displayed on the App Suite screen are displayed as shortcuts. App Suite apps can be reordered to customize shortcuts.

BASIC MAP OPERATION

11.6 inch screen

Setup

Press  to access "Setup" screen:

- Select to change the selected language, operation sound, keyboard layout settings, etc.
- Select to set the voice settings.
- Select to set Bluetooth® phones and Bluetooth® audio devices.
- Select to set traffic information.
- Select to set memory points (home, preset destinations, address book entries, areas to avoid), navigation details or to delete previous destinations.
- Select to set audio settings.
- Select to set vehicle information.
- Select to set the phone sound, contacts, message settings, etc.
- Select to set Entune App Suite settings.
- Select to set data services settings.





PLEASE READ

SAFETY

Concentrating on the road should always be your first priority while driving. Do not use the Entune system if it will distract you.

WHAT IS ENTUNE® APP SUITE?

The available Entune® App Suite system is a collection of popular mobile applications and data services integrated with select 2017 Toyota vehicles. Entune® App Suite is subscription free.

Once the phone is connected to the vehicle using Bluetooth® wireless technology, Entune's App Suite features are operated using the vehicle's controls or, for some services, by voice recognition. Entune® App Suite includes mobile apps for Destination Search, iHeartRadio, MovieTickets.com, OpenTable®, Pandora®, Facebook Places, Yelp, and Slacker Radio. Data Services include Fuel Guide, Sports, Stocks, Traffic and Weather. All apps and data services are subject to change without notice. See www.toyota.com/entune for availability of apps and data services.

ENTUNE® APP SUITE*

In order to access Entune® App Suite applications from your vehicle's touch screen, an Entune® App Suite compatible phone, the Entune mobile application and Entune® App Suite are required. Use your smartphone to download the Entune™ mobile application from the appropriate app store and register via the mobile application. You may also register for Entune® App Suite through myentune.com and visit www.toyota.com/entune to learn more about the Entune® App Suite.

PHONE COMPATIBILITY

An Entune® App Suite compatible phone is required to use the additional features. Check phone compatibility by one of the following methods:

- Visit: www.toyota.com/connect
- Call the Toyota Customer Experience Center at 1-800-331-4331

Note: You do not need an Entune App Suite compatible phone to use Bluetooth® hands-free, Bluetooth audio or the navigation system. To connect a Bluetooth Phone, refer to page 9.

WHAT ENTUNE™ SYSTEM DO YOU HAVE?

Entune™ Premium Audio with Integrated Navigation and App Suite

- 7" Touchscreen
- Siri® Eyes Free**
- SiriusXM® Satellite Radio, HD Radio™, HD Radio™ Traffic / Weather
- **Integrated Navigation**
- **Entune® App Suite**
- AM/FM Cache Radio

Entune™ Premium Audio with 11.6-in. HD Multimedia Display, Integrated Navigation and App Suite

- basic *Entune™ Premium feature (excluding CD Player)* +
- 11.6–in. HD Multimedia Display
 - Charging Station Map

Entune™ Premium JBL® Audio with 11.6-in. HD Multimedia Display, Integrated Navigation and App Suite

- basic *Entune™ Premium feature (excluding CD Player)* +
- 11.6–in. HD Multimedia Display
 - Prius Prime Apps (Remote Charge Management, Charging Station Map, ECO Dashboard, Remote Climate, Vehicle Finder)
 - JBL® Speakers/Amp system

*Be sure to obey traffic regulations and maintain awareness of road and traffic conditions. Select Entune® App Suite use a large amount of data and you are responsible for all data charges. Apps and services vary by phone and carrier. Not all apps and data services are available at all times and all locations. Apps identified by "™" or "®" are trademarks or registered trademarks of their respective companies and cannot be used without permission. See toyota.com/entune for the latest information regarding apps and services.

BASIC OVERVIEW

	Step	Reference	
Phone Compatibility	1 Confirm that your phone is able to run the Entune™ App.	Go to "PHONE COMPATIBILITY" on page 5.	
Download App	2 Download the Entune™ App to your phone.	Using your cell phone, find the Entune™ App in the Apple App Store™ or Google Play™.	
Account Creation	3 Enroll via your mobile device or register on www.myentune.com and create a personal Entune™ App account using your computer.	Go to "ACCOUNT CREATION".	
Launch App and Login	4 Launch the Entune™ App on your phone and sign in.	The Entune™ App must be running on the mobile device in order to use the internet services.	User Name: <input type="text"/> Password: <input type="password"/>
Connect	5 Connect your phone to your vehicle via Bluetooth®, and experience Entune™ App.	Go to "CONNECT A BLUETOOTH PHONE" on page 9.	

ACCOUNT CREATION

- | | |
|--|---|
| <p>step 1 From a mobile device (Entune™ App) or a computer, access www.myentune.com</p> | <p>step 2 From a mobile device, click "Sign Up for Entune," or from a computer, click on the Register button on the right hand side of the screen.</p> |
| <p>step 3 Create your Entune™ App account.</p> | <p>step 4 Follow the easy steps to complete your account.</p> |

DOWNLOADING ENTUNE® APP SUITE TO YOUR PHONE

Using your cell phone, connect to your app store (Apple App Store™, Google Play™), search for Entune™ and download. Contact your mobile device provider if you need assistance.

LAUNCH APP

In order to view the Entune® App Suite on your vehicle display, some phones may require an additional step after they have been connected. After connecting through Bluetooth and signing in, launch the Entune™ app to ensure the phone is connected and running the app.

CONNECT PHONE

See page "Connect a bluetooth phone" section of this guide for instructions.

ACCESSING ENTUNE APPS

7 inch display:

step 1 Press the **APPS** button  on the faceplate.

step 2 Use  or  or swipe with your finger to access the additional apps.



11.6 inch display:

step 1 Press the **"App Suite"**  on the screen.

step 2 Use  or  or swipe with your finger to access the additional apps.



The Entune™ App contains only the included applications that will work with your vehicle. Other apps downloaded on your phone are not available through Entune™.

If Entune® App Suite is not pre-installed, you will be prompted on the vehicle touchscreen to download a mandatory update when your Bluetooth phone with the Entune™ app running on it is connected to the vehicle. Follow the touchscreen prompts to download and install the Entune™ apps to your system.

The Entune™ App must be running on the mobile device in order to use the internet services.

CONNECT A BLUETOOTH PHONE (7 INCH DISPLAY)

To begin the Bluetooth Pairing process, press the HOME button on the faceplate of your Toyota Vehicle Entune™ Multimedia Head Unit.

BLUETOOTH PAIRING FOR ANDROID PHONE AND ENTUNE TOUCH SCREEN SYSTEM

****Do not attempt the Bluetooth® Pairing process while driving.****

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Android mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to "talk" to each other and form a connection.¹

INITIATE BLUETOOTH ON YOUR ANDROID



step 1

From your **APPS SCREEN**, select **SETTINGS**.




step 2

Select **CONNECTIONS** and select **BLUETOOTH**.



step 3

Ensure **BLUETOOTH** is **ON**.



step 4

Select **YOUR PHONE DEVICE** to make it discoverable.



step 5

While your Android device is seeking out Bluetooth devices, proceed to your Entune™ Multimedia Head Unit on your Toyota vehicle.

Phone will seek out Bluetooth devices while remaining discoverable.

¹ Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

INITIATE BLUETOOTH ON YOUR ENTUNE MULTIMEDIA HEAD UNIT

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune™ head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune™ system.



step 6

7 inch display:


On your Toyota Vehicle Entune™ Multimedia Head Unit, select **SETUP BUTTON** on the Home Screen.

For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen.




step 7

Select **BLUETOOTH**.




step 8

Select **ADD**, to add your phone device.




step 9

Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.



step 10

Your smartphone is now paired with Entune™.



step 11

Once paired, Entune™ will attempt to connect audio and contacts on your phone.

You may need to enter the provided Bluetooth PIN on your phone.

CONNECT A BLUETOOTH PHONE (7 INCH DISPLAY)

INITIATE BLUETOOTH ON YOUR ENTUNE MULTIMEDIA HEAD UNIT (CONTINUED)



step 12

Using your smartphone, you will need to allow Entune™ access to your messaging and contacts.

It is recommended to check the "Don't ask again" box, so as not to have to press OK every time the phone makes a Bluetooth connection with your Toyota.



step 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

BLUETOOTH PAIRING FOR IPHONE AND ENTUNE TOUCH SCREEN SYSTEM

****Do not attempt the Bluetooth® Pairing process while driving.****

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth®. This pairing process is quick and easy: all iPhone® mobile digital devices have Bluetooth® integrated; all you have to do is setup the phone and multimedia system to "talk" to each other and form a connection.

INITIATE BLUETOOTH ON YOUR IPHONE



step 1

From the **HOME SCREEN**, select **SETTINGS**.



step 2

Select **BLUETOOTH**.



step 3

Ensure **BLUETOOTH** is **ON**.



step 4

Your iPhone will seek out Bluetooth devices while remaining discoverable.



step 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune™ Multimedia Head Unit on your Toyota vehicle.

CONNECT A BLUETOOTH PHONE (7 INCH DISPLAY)

INITIATE BLUETOOTH ON YOUR ENTUNE MULTIMEDIA HEAD UNIT

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune™ head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune™ system.



step 6


On your Toyota Vehicle Entune™ Multimedia Head Unit, select **SETUP BUTTON** on the Home Screen.

For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen



step 7

Select **BLUETOOTH**.



step 8


Select **ADD**, to add your phone device.



step 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



step 10


Your smartphone is now paired with Entune™.



step 11

Once paired, Entune™ will attempt to connect audio and contacts on your phone.

INITIATE BLUETOOTH ON YOUR ENTUNE MULTIMEDIA HEAD UNIT (CONTINUED)



step 12

Using your smartphone, you may need to allow Entune™ access to your messaging and contacts.

Only current iPhone text messages can be viewed on the head unit. iPhone does not allow text message reply.



step 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

CONNECT A BLUETOOTH PHONE (7 INCH DISPLAY)

BLUETOOTH PAIRING FOR WINDOWS PHONE AND ENTUNE TOUCH SCREEN SYSTEM

****Do not attempt the Bluetooth® Pairing process while driving.****


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth®. This pairing process is quick and easy: all Windows Phone® mobile digital devices have Bluetooth® integrated; all you have to do is setup the phone and multimedia system to "talk" to each other and form a connection.

INITIATE BLUETOOTH ON YOUR WINDOWS PHONE




step 1

From your APP LIST, select **SETTINGS**.



step 2

Select **BLUETOOTH**.



step 3

Ensure **BLUETOOTH** is **ON**.



step 4

Phone will seek out Bluetooth devices while remaining discoverable.



step 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune™ Multimedia Head Unit on your Toyota vehicle.

INITIATE BLUETOOTH ON YOUR ENTUNE MULTIMEDIA HEAD UNIT

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune™ head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune™ system.



step 6


On your Toyota Vehicle Entune™ Multimedia Head Unit, select **SETUP BUTTON** on the Home Screen.

For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen




step 7

Select **BLUETOOTH**.



step 8


Select **ADD**, to add your phone device.



step 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



step 10

Your smartphone is now paired with Entune™.




step 11

Once paired, Entune™ will attempt to connect audio and contacts on your phone.


CONNECT A BLUETOOTH PHONE (7 INCH DISPLAY)

INITIATE BLUETOOTH ON YOUR ENTUNE MULTIMEDIA HEAD UNIT (CONTINUED)



step 12

Using your smartphone, you may need to allow Entune™ access to your contacts.



step 13

A confirmation will appear that your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

ADVANCED VOICE RECOGNITION SYSTEM

VOICE RECOGNITION TRAINING AND TUTORIAL

(7 INCH DISPLAY)

Before you begin using the voice recognition system, it is recommended that you access "Train Voice Recognition" and "Voice Recognition Tutorial" in the Setup menu. Voice recognition training is a feature that will help train the voice recognition system to better understand your voice. For best results, it is recommended that voice recognition training be done when there is minimal background noise. The voice recognition tutorial will give an overview of how to use the voice recognition system, including how to make calls and how to customize your experience.

TRAIN VOICE RECOGNITION



step 1 Press the Setup icon  on the faceplate followed by . Then select .

step 2 Follow the system prompts and repeat a series of phrases after each beep. From the Voice Settings screen, you will also be able to select the desired level of system guidance by selecting Voice Recognition Prompts.

VOICE RECOGNITION TUTORIAL




step 1 Press the Setup icon  on the faceplate followed by . Then select .

step 2 Select desired tutorial program to run.

CALLING BY VOICE RECOGNITION

DIAL BY NUMBER

(7 INCH DISPLAY)



step 1 Press  on the steering wheel. After the beep say, "Dial <number>." Say the phone number digits individually, without pausing (e.g. "Dial Three, one, zero, four...").

Quick Tip – If you know your next command, you can press  at any time to interrupt the prompt. Say your command after the beep.



step 2 The system will ask you to verify the number.



step 3 Call will begin dialing.



step 4 Call is active when  is indicated. To end call, press  on the screen or  on the steering wheel.


Quick Tip – It is recommended that you reduce background noise prior to using the Voice Recognition system. Conversation, high fan speed, wind noise (open windows), etc., may prevent the voice recognition system from understanding your commands.

CALLING BY VOICE RECOGNITION

DIAL BY NAME

(7 INCH DISPLAY)

If you are able to successfully transfer your phonebook, you can dial by name using voice recognition. Please say the name exactly as it is entered in your phone when in the telephone screen. If you have difficulty pairing your phone, or are unable to transfer your cell phonebook, please refer to the cell phone manufacturer's user guide.



step 1 Press  on the steering wheel. After the beep say, "Call <name>.*." Please say the name exactly as it is entered in your phone.

step 2 Verify the contact name, and then dialing will begin.

*NOTE: When saying contact name, be sure to say it exactly as it is entered in your address book

Quick Tip – If you know your next command, you can press  at any time to interrupt the prompt. Say your command after the beep.



step 3 Call is active when  is indicated. To end call, press  on the screen or  on the steering wheel.

DESTINATION INPUT

BY ADDRESS


(7 INCH DISPLAY)



step 1 From the home screen, touch the map, followed by **Dest.**




step 2 Press **Address** and enter the desired State/Province.



step 3 Touch **City** and go to step 4.



step 4 Input the city name.



step 5 Touch the desired city name.



step 6 Input the street name and touch **OK**

Quick Tip – Input the street name without prefixes such as North or the letter N. The system will display the base street name without prefixes or suffixes on the next screen.

DESTINATION INPUT

BY ADDRESS



step 7 Touch the desired street name.



step 8 Input the house number and touch



step 9 Touch



step 10 Touch



step 11 Select the desired Route.



step 12 Touch

DESTINATION INPUT

NOTE ON VOICE RECOGNITION


The navigation system's voice recognition feature will compare your spoken words with computer-generated word patterns preprogrammed in the database. If the system does not provide your intended match, please try a different pronunciation. Voice-activation names are not available for every street and city.

TIPS FOR USING VOICE RECOGNITION

- tip 1** Before using voice recognition, roll up all windows and set the climate control fan on low or off to reduce background noise in the cabin.
- tip 2** Have the full and correct address in mind. The system will ask for the state, city, and street name followed by the house number as separate inputs.
- tip 3** Say the street name without prefixes or suffixes. Examples:
1st Street, say: "First"
E 15th Street, say: "Fifteenth"
190th Street, say "One hundred ninetieth"
Point Court, say "Point"
- tip 4** Say a street address number as single digits. Examples:
125, say: "One two five"
2000, say: "Two zero zero zero"
32307, say: "Three two three zero seven"
- tip 5** Speak at a normal volume and pace, and pronounce words clearly.
- tip 6** The zip code is not needed.

BY ADDRESS-VOICE RECOGNITION (While on the navigation map)

(7 INCH DISPLAY)



DESTINATION INPUT - POINT OF INTEREST (POI)

POINT OF INTEREST BY NAME

(7 INCH DISPLAY)




step 1 From the home screen, touch the map. followed by **Dest.**. Press **OK**.



step 2 Touch **Name**.



step 3 Input the POI name and if necessary touch **OK**.



step 4 Use **Up** or **Down** to scroll up or down. Touch the desired destination.



step 5 Touch **Go**.

Quick Tip – If the POI isn't listed in the database verify the spelling and Search Area for accuracy.

DESTINATION INPUT - POINT OF INTEREST (POI)

POINT OF INTEREST BY CATEGORY

(7 INCH DISPLAY)



step 1 From the home screen, touch the map. followed by **Dest.**. Press **Points of Interest**.



step 2 Touch **Category** followed by the category location and desired sub-category.




step 3 Scroll to select desired POI and touch **Go**.

DESTINATION INPUT - POINT OF INTEREST (POI)

POINT OF INTEREST BY CATEGORY - VOICE RECOGNITION

(7 INCH DISPLAY)


Quick Tip – You can search for many dining, hotel and fuel chains by name, e.g., "Find Nearby Starbucks."



step 1 Press  on the steering wheel. After the beep say, "Find Nearby <POI category>" (e.g., "Find Nearby Hotel.")

step 2 After the beep say, the number that corresponds to the desired destination.

Quick Tip – If you know your next command, you can press  at any time to interrupt the prompt. Speak your command after the beep.



step 3 After the beep say, "Start guidance" or "Call them."


step 4 Start route guidance.

SET HOME


(7 INCH DISPLAY)




step 1 Press the Set Up icon  on the faceplate followed by .




step 2 Touch .




step 3 Touch .



step 4 Touch .


Tip – For security reasons, use a point close to your home instead of your actual home address.



step 5 Touch .



step 6 Input the city name.



step 7 Touch the desired city name.



step 8 Input the street name and touch **OK**.

Quick Tip – Enter the street name without prefixes such as North or the letter N. The system will display the base street name without prefixes or suffixes on the next screen.




step 9 Touch the desired street name.



step 10 Input the house number and touch **OK**.



step 11 Confirm location and touch **Enter**.




Touch **Edit** followed by the desired icon for your home. Touch **OK**.

ADDITIONAL NAVIGATION FEATURES

(7 INCH DISPLAY)

OPERATION OF EMERGENCY SCREEN



PRESS >  

Touch the desired emergency category. If the vehicle is in motion, only nearby police stations, dealers, hospitals or fire stations are shown.

SEARCH AREA



Prior to inputting the desired address, select the State/Province by pressing . The system is only capable of searching for an address within one state or province at a time.

ROUTE PREFERENCES



Once the address has been inputted, select the desired route preference(s) for the trip. By selecting  the system will display time, toll roads, ferry and freeway information.

3 ROUTES



One of three routes may be chosen for the trip:
Quick– is the easiest route, usually the fastest
Short– is the most direct based upon driven mileage
Alternate– is the second fastest route

SCREEN CONFIGURATIONS



SELECT NAVIGATION APP > 

Select what information to display with the map. Some selections are available during route guidance mode only.



ADDITIONAL NAVIGATION FEATURES

BEEP SETTING



PRESS SET UP ICON  > 

Check the Beep box on or off.


VOICE VOLUME



PRESS SET UP ICON  > 

Adjust the Voice Guidance volume level.

LANGUAGE



PRESS SET UP ICON  > 

Select Language Preference: English, French or Spanish.

SYSTEM TIME



PRESS SET UP ICON  > 

Adjust the Time Zone and Daylight Saving Time option.

AUTO CHANGE TO HOME SCREEN



PRESS SET UP ICON  >  > 

Once the screen transition is unchecked (off), the audio screen will remain without reverting to the map display.

CACHE RADIO



The Cache Radio features a pause function that will record the last 20 minutes of live radio for playback later. This is only available for FM/AM radio.

NOTE: When the vehicle is turned off or the radio station is changed, any saved audio content will be lost.


TRAFFIC


(7 INCH DISPLAY)




The Traffic App integrates with your navigation system to display continuously updated traffic information for over 100 markets. Just begin by pressing the APPS button and selecting .

TRAFFIC EVENT LIST



To see local traffic events, touch  and you will see a list of events at your location. Touch  to see events along your current route.


PREDICTIVE TRAFFIC MAP



Predictive Traffic Map is a feature that displays traffic conditions for the current time based on historical trends at the location. To see a predictive traffic map, touch . The Predictive Traffic Map can be set to predict traffic conditions 15, 30 and 45 minutes from the current time.


Always drive safely, obey traffic laws & focus on the road while driving. Availability and accuracy of the information provided by HD services is dependent upon many factors. Services not available in every city or roadway. Use common sense when relying on information provided. HD Radio™ Technology manufactured under license from iBiquity Digital Corporation U.S. and Foreign Patents. HD Radio™ and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.

MY TRAFFIC ROUTES



My Traffic Routes lets you store favorite and previously traveled routes to check traffic conditions. To see traffic routes, touch .



AUTOMATICALLY AVOID TRAFFIC



step 1 Press the Set Up icon  on the faceplate followed by .

step 2 Select the **Avoid Traffic** option to switch from Manual to Automatic and press . The system will automatically select another route when moderate or heavy traffic is detected during route guidance.

TRAFFIC INCIDENT WARNING



step 1 Press the Set Up icon  on the faceplate followed by .

step 2 Select the **Traffic Incident Warning** option to receive voice notification of traffic events including incident within 20 miles along the current route. Press .

CONNECT A BLUETOOTH PHONE (11.6 INCH DISPLAY)

BLUETOOTH PAIRING FOR A PHONE AND TOUCH SCREEN SYSTEM

****Do not attempt the Bluetooth® Pairing process while driving.****


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth®. This pairing process is quick and easy: all Windows Phone® mobile digital devices have Bluetooth® integrated; all you have to do is setup the phone and multimedia system to "talk" to each other and form a connection.

INITIATE BLUETOOTH ON YOUR ANDROID




step 1

From your **APPS SCREEN**, select **SETTINGS**.




step 2

Select **CONNECTIONS** and select **BLUETOOTH**.



step 3

Ensure **BLUETOOTH** is **ON**.



step 4

Select **YOUR PHONE DEVICE** to make it discoverable.

Your phone will seek out Bluetooth devices while remaining discoverable.

INITIATE BLUETOOTH ON YOUR IPHONE



step 1

From the **HOME SCREEN**, select **SETTINGS**.



step 2

Select **BLUETOOTH**.



step 3


Ensure **BLUETOOTH** is **ON**.



step 4

Your phone will seek out Bluetooth devices while remaining discoverable.

CONNECT A BLUETOOTH PHONE (11.6 INCH DISPLAY)



step 5


Press the  button or swipe upwards to show the menu, swipe to side to change to **"Phone"**.

Press **"Connect phone"**.

- Operations up to this point can also be performed by pressing the switch on the steering wheel.

Select **"Yes"** to register a phone.

ANDROID



iPhone



step 6

When this screen is displayed, search for the device name displayed on this screen on the screen of your Bluetooth® device.

- For details about operating the Bluetooth® device, see the manual that comes with it.
- To cancel the registration, select "Cancel".

step 7

Register the Bluetooth® device using your Bluetooth® device.



step 8

Check that the screen is displayed when registration is complete.

- The system waits for connection requests coming from the registered device.
- At this stage, the Bluetooth® functions are not yet available.

step 9

Check that "Connected" is displayed and registration is complete.

- If displayed, select "OK" to complete the registration process.
- If an error message is displayed, follow the guidance on the screen to try again.

ADVANCED VOICE RECOGNITION SYSTEM

VOICE RECOGNITION TRAINING AND TUTORIAL

(11.6 INCH DISPLAY)


TRAIN VOICE RECOGNITION



step 1 Press  "MENU" button



step 2 Press  "Setting" button



step 3 Press  "VOICE" button



step 4

Press "Train Voice Recognition" button.



step 5

In order to improve voice recognition performance, select "Train Voice Recognition" on the "Voice Settings" screen. When "Train Voice Recognition" is selected, the user will be asked to say 10 sample phrases. This will help the voice command system adapt to the user's accent.

VOICE RECOGNITION TUTORIAL

step 1 Press  "MENU" button

step 2 Press  "MENU" button

step 3 Press  "VOICE" button



step 4 Press "Voice Recognition Tutorial" button.



step 5 Select desired tutorial program to run.

CALLING BY VOICE RECOGNITION

DIAL BY NUMBER

(11.6 INCH DISPLAY)



step 1 Press  on the steering wheel. After the beep say, "Phone."



step 2 Then After the beep say, "Dial by Number"

Quick Tip – If you know your next command, you can press  at any time to interrupt the prompt. Say your command after the beep.




step 3 Say the phone number digits individually, without pausing (e.g. "Dial Three, one, zero, four...").





step 4 The system will confirm your number. Select the number from the list to make a call.



step 5 Call will begin dialing.



step 6 Call is active when  is indicated. To end call, press  on the screen or  on the steering wheel.

Quick Tip – It is recommended that you reduce background noise prior to using the Voice Recognition system. Conversation, high fan speed, wind noise (open windows), etc., may prevent the voice recognition system from understanding your commands.

 Some Bluetooth® equipped cell phones may show battery or signal strength on the display

CALLING BY VOICE RECOGNITION

DIAL BY NAME

(11.6 INCH DISPLAY)



step 1 Press  on the steering wheel. After the beep say, "Phone."



step 2 Suggested commands will appear. After the beep say, "Call a Contact."

Quick Tip – If you know your next command, you can press  at any time to interrupt the prompt.

Say your command after the beep.



step 3 Say the name.



step 4 The system will confirm your name. Select the number from the list to make a call.



step 5 Call will begin dialing.



step 6 Call is active when  is indicated. To end call, press  on the screen or  on the steering wheel.

DESTINATION INPUT

BY ADDRESS


(11.6 INCH DISPLAY)



step 1 From the home screen, touch **Dest.** on the map.



step 2 Press **Address** and enter the desired State/Province.



step 3 Touch **City** and go to step 4.



step 4 Input the city name.



step 5 Touch the desired city name.



step 6 Input the street name and touch **OK**.


Quick Tip – Input the street name without prefixes such as North or the letter N. The system will display the base street name without prefixes or suffixes on the next screen.

DESTINATION INPUT

BY ADDRESS



step 7 Touch the desired street name.




step 8 Input the house number and touch



step 9 Touch



step 10 Touch



step 11 Select the desired Route.



step 12 Touch



to start route guidance.

DESTINATION INPUT

NOTE ON VOICE RECOGNITION

(11.6 INCH DISPLAY)

The navigation system's voice recognition feature will compare your spoken words with computer-generated word patterns preprogrammed in the database. If the system does not provide your intended match, please try a different pronunciation. Voice-activation names are not available for every street and city.

TIPS FOR USING VOICE RECOGNITION

- tip 1** Before using voice recognition, roll up all windows and set the climate control fan on low or off to reduce background noise in the cabin.
- tip 2** Have the full and correct address in mind. The system will ask for the state, city, and street name followed by the house number as separate inputs.
- tip 3** Say the street name without prefixes or suffixes. Examples:
1st Street, say: "First"
E 15th Street, say "Fifteenth"
190th Street, say "One hundred ninetieth"
Point Court, say "Point"
- tip 4** Say a street address number as single digits. Examples:
125, say: "One two five"
2000, say: "Two zero zero zero"
32307, say: "Three two three zero seven"
- tip 5** Speak at a normal volume and pace, and pronounce words clearly.
- tip 6** The zip code is not needed.

BY ADDRESS-VOICE RECOGNITION (While on the navigation map)



- step 1** Press  on the steering wheel. After the beep, say "Enter an address" and then say the entire address in one action.

Quick Tip – If you know your next command, you can press  at any time to interrupt the prompt. say your command after the beep.



- step 2** Verify, and then confirm the address after the beep, or touch .


DESTINATION INPUT - POINT OF INTEREST (POI)

POINT OF INTEREST BY NAME

(11.6 INCH DISPLAY)



step 1 From the home screen, touch **Dest** on the map and Press **Point of Interest**.



step 2 Touch **Name**.



step 3 Input the POI name and if necessary touch **OK**.



step 4 Use **↑** or **↓** to scroll up or down. Touch the desired destination.



step 5 Touch **Go**.

Quick Tip – If the POI isn't listed in the database verify the spelling and Search Area for accuracy.


DESTINATION INPUT - POINT OF INTEREST (POI)

POINT OF INTEREST BY CATEGORY


(11.6 INCH DISPLAY)



step 1 From the home screen, touch  on the map and Press .



step 2 Touch .



step 3 Touch .

DESTINATION INPUT - POINT OF INTEREST (POI)

POINT OF INTEREST BY CATEGORY - VOICE RECOGNITION

(11.6 INCH DISPLAY)

Quick Tip – You can search for many dining, hotel and fuel chains by name, e.g., "Find Nearby Starbucks."



step 1 Press  on the steering wheel. After the beep say, "Navigation."

step 2 After the beep say, the number that corresponds to the desired destination.

Quick Tip – If you know your next command, you can press  at any time to interrupt the prompt.


Say your command after the beep.




step 3 After the beep say, "Yes" to start guidance or "Call" to call them.

SET HOME

(11.6 INCH DISPLAY)




step 1 Press  "MENU" button and then press  "Setting" button.



step 2 Touch .



step 3 Touch .



step 4 Touch .

Tip – For security reasons, use a point close to your home instead of your actual home address.



step 5 Touch .



step 6 Input the city name.



step 7 Touch the desired city name.



step 8 Input the street name and touch **OK**.

Quick Tip – Enter the street name without prefixes such as North or the letter N. The system will display the base street name without prefixes or suffixes on the next screen.



step 9 Touch the desired street name.



step 10 Input the house number and touch **OK**.



step 11 Confirm location and touch **Enter**.



step 12 Touch **Enter** followed by the desired icon for your home. Touch **OK**.

ADDITIONAL NAVIGATION FEATURES

(11.6 INCH DISPLAY)


OPERATION OF EMERGENCY SCREEN



Press  and then press .

Touch the desired emergency category. If the vehicle is in motion, only nearby police stations, dealers, hospitals or fire stations are shown.

SEARCH AREA



Prior to inputting the desired address, select the State/Province by pressing . The system is only capable of searching for an address within one state or province at a time.

ROUTE PREFERENCES



Once the address has been inputted, select the desired route preference(s) for the trip. By selecting  the system will display time, toll roads, ferry and freeway information.

3 ROUTES



One of three routes may be chosen for the trip:
Quick– is the easiest route, usually the fastest
Short– is the most direct based upon driven mileage
Alternate– is the second fastest route

SCREEN CONFIGURATIONS



Press option > 

Select what information to display with the map. Some selections are available during route guidance mode only.



ADDITIONAL NAVIGATION FEATURES

BEEP SETTING



Press  and then press . Press .
Check the Beep box on or off.

VOICE VOLUME



Press  and then press . Press .
Adjust the Voice Guidance volume level.

LANGUAGE



Press  and then press . Press .
Select Language Preference: English, French or Spanish.

SYSTEM TIME



Press  and then press . Press .
Adjust the Time Zone and Daylight Saving Time option.

CACHE RADIO



The Cache Radio features a pause function that will record the last 20 minutes of live radio for playback later. This is only available for FM/AM radio.

NOTE: When the vehicle is turned off or the radio station is changed, any saved audio content will be lost.

TRAFFIC

(11.6 INCH DISPLAY)




Press  "Menu" button on the faceplate and select  "Setting" to access **Setup** screen. Then Select  "Traffic".


TRAFFIC EVENT LIST



To see local traffic events, touch  and you will see a list of events at your location. Touch  to see events along your current route.

PREDICTIVE TRAFFIC MAP



Predictive Traffic Map is a feature that displays traffic conditions for the current time based on historical trends at the location. To see a predictive traffic map, touch . The Predictive Traffic Map can be set to predict traffic conditions 15, 30 and 45 minutes from the current time.


Always drive safely, obey traffic laws & focus on the road while driving. Availability and accuracy of the information provided by HD services is dependent upon many factors. Services not available in every city or roadway. Use common sense when relying on information provided. HD Radio™ Technology manufactured under license from iBiquity Digital Corporation U.S. and Foreign Patents. HD Radio™ and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.

MY TRAFFIC ROUTES



Specific routes (such as frequently used routes) on which you wish to receive traffic information can be registered as "My Traffic Routes". A route is set by defining a start point and end point.

AUTOMATICALLY AVOID TRAFFIC




Select the **Avoid Traffic** option to switch from Manual to Automatic and press . When heavy traffic is detected during route guidance and a faster route is available, the system will automatically switch to the faster route.

WEATHER

(11.6 INCH DISPLAY)

To access "Weather", press  "Menu" button on the faceplate and select  "Info"



Touch  and choose your desired category.



Once you have selected which city, you can check the current weather as well as see forecasts for the next 3 days or next 6 hours, for whichever city you have chosen.



By selecting  you can check an HD Radio™ Doppler radar weather map of your area. To move around the map touch and swipe to the desired location.

Always drive safely, obey traffic laws & focus on the road while driving. Availability and accuracy of the information provided by HD services is dependent upon many factors. Services not available in every city or roadway. Use common sense when relying on information provided. HD Radio™ Technology manufactured under license from iBiquity Digital Corporation U.S. and Foreign Patents. HD Radio® and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.



ENTUNE APP SUITE FEATURES

For 7-in. Display, press APPS to access Entune® App Suite apps.

For 11.6-in. Display, press App Suite button to access Entune® App Suite apps.

Once your phone is connected via Bluetooth, Entune lets you access many useful apps. These are some of the top featured apps you can access by pressing the APPS button  on the console.


APPS MENU



SELECT APPS or App Suite button
, **SCROLL TO NEXT SCREEN**

Begin by pressing the APPS button on the console and choosing the desired app.

MOVIETICKETS.COM



SELECT APPS or App Suite button



Select Movietickets.com App to find a local movie theater and see showtimes.

PANDORA



SELECT APPS or App Suite button



Select Pandora App to connect to desired Pandora stations.

iHeartRadio



SELECT APPS or App Suite button



Select iHeartRadio App to connect to desired iHeartRadio stations.

OPENTABLE




SELECT APPS or App Suite button



Select OpenTable App to check a location and reserve a table.

FACEBOOK PLACES




SELECT APPS or App Suite button



Select Facebook Places App to check in at a location and to tag friends with you.

ENTUNE APP SUITE FEATURES

YELP




SELECT APPS or App Suite button



Select Yelp App to find local restaurants and see reviews.

DESTINATION SEARCH




SELECT APPS or App Suite button




Select Destination Search App to search local POI and navigate to your destination.



step 1 Type in POI to search.



step 2 The system lists all related names and locations.



step 3 Select one from the list to see the detail information. You can select  to call or select  see the map.

ENTUNE APP SUITE FEATURES


SLACKER RADIO



SELECT APPS




Select Slacker App to connect to desired Slacker radio station.



SELECT




To access Slacker stations. (Genre/Category)



SELECT



to access New & Trending.



SELECT




to access My Music. Select "Recently played" or listed stations.



SELECT



to access My Vibe.



SELECT



to search and find a station that plays inputted artist, song, album, or similar music

SIRI® EYES FREE

Siri® Eyes Free allows customers with compatible iPhones to access Apple's Siri® voice recognition system via the vehicle's steering wheel controls and the in-vehicle microphone; responses are played back via the vehicle's audio speakers. To use Siri® Eyes Free, compatible iPhone must be paired to the Entune™ system via Bluetooth.



Push and hold to access Siri® Eyes Free

With Siri® Eyes Free, you can make calls, send e-mails, retrieve text messages, select music, find calendar information and more.

Always drive safely, obey traffic laws and focus on the road while driving. Siri® is available only on iPhone® 4s or later, iPad® with Retina® display, iPad® mini, & iPod® touch (5th generation) and requires Internet access. Siri® is not available in all languages or all areas, and features vary by area. Some Siri® functionality and commands are not accessible in the vehicle. Data charges may apply. See Apple.com & phone carrier for details.

PRIUS PRIME APPS (IF EQUIPPED)

To begin, be sure to enroll in Safety Connect (contact your dealer if you have questions about enrolling). Once your phone is connected via Bluetooth, Entune lets you access many useful apps. These are some of the featured apps specific to your Prius Prime Advanced. These apps can be accessed via Entune on your phone. To connect via Entune, first go to www.myentune.com to register for Prius Prime Apps by entering a Safety Connect contract ID.

CHARGE MANAGEMENT



SELECT ENTUNE >



Begin by opening the Entune App on your mobile device. Select the Charge Management icon. Charge Management allows you to see the current range based on the existing charge and set charge time.

CHARGING STATION MAP



SELECT ENTUNE >



Charging Stations will automatically download as POI icons onto your navigation map when the vehicle is paired with your phone. Please be sure to have Charging Station POI icons activated by pressing the Options button on the map...etc. In addition, you can reload POI icons if you move map areas by pressing THIS button.

REMOTE CLIMATE



SELECT ENTUNE >



Remote Climate allows you to remotely activate the air conditioning system in your Prius Prime in order to reach the last set temperature within the vehicle. If the cabin temperature is hotter than the set temperature, air conditioning will engage. It also allows you to set MAX A/C or MAX Heat and turn on front and rear defrost. Your desired temperature in vehicle must be set using the climate control system in your vehicle prior to engaging Remote Climate Control from mobile device.

***CAUTION:** Do not initiate a Remote Climate Activation if people are in the vehicle. Children and pets left inside the vehicle may suffer heatstroke, dehydration or hypothermia, or could result in death or serious injury.

ECO DASHBOARD



SELECT ENTUNE >



Begin by opening the Entune App on your mobile device. Select the ECO Dashboard icon. The ECO Dashboard feature allows you to see how your energy usage compares with other Pug-in Hybrid Advanced vehicles. You can see your ECO ranking and ECO History. You can also participate in the ECO Challenge with other vehicles and post your ECO driving status to Social Media.

VEHICLE FINDER



SELECT ENTUNE >



Begin by opening the Entune App on your mobile device. Select the Vehicle Finder icon. This app is useful for locating where you parked your vehicle from your phone. You can zoom in and out to see the vehicle's location.







You can find additional support at:

Web

<http://www.toyota.com/entune/support/>

or

Call

1-800-331-4331.

Monday – Friday 7:00 AM to 7:00 PM CT

and Saturday 7:00 AM to 4:30 PM CT.

or

See Entune™ Audio tutorials on

<https://www.youtube.com/user/ToyotaUSA> and search Entune.



www.toyota.com/owners

CUSTOMER EXPERIENCE CENTER
1-800-331-4331



Printed in U.S.A. 12/17
17-MKG-11337



00505NAV18PR1PM