



TOYOTA

Getting Started with

- Bluetooth® Pairing
- Toyota app
- Connected Services
- Apple CarPlay®
- Android Auto™
- Amazon Alexa
- SiriusXM®
- Online Support Tool

Scan QR Code to Download Toyota app

Apple



Android




Bluetooth® Pairing¹



Note: Do not attempt the Bluetooth® Pairing process while driving.

STEP 1

Press **[MENU]** on the faceplate, then select **"Setup"** on display screen.




iPhone Bluetooth Menu



Android Bluetooth Menu

STEP 2

Ensure Bluetooth is turned on for your phone.



STEP 3

Select **"Bluetooth,"** then select **"Add New Device"** on display screen.



STEP 4

Select **"Phone Name."**




STEP 5

Check the display on your phone. Does the PIN XXXX match the PIN displayed? If it does, select **"Pair."**



STEP 6


"Connecting" displays while phone is forming the connection to the multimedia system.



STEP 7


Enable Notifications (text message). While pairing your phone this message will display: **"You may need to allow message access on your phone."**

Note: You may also select **"Skip"** on display screen to skip enabling notifications. If skipped proceed to **STEP 9.**



STEP 8

Turn on **"Show Notifications"** for iPhone® or **"ON"** for Android.



STEP 9

A confirmation will appear once your phone has been paired and connected.

Getting Started with Toyota app



TOYOTA

Toyota app allows access to valuable information about your vehicle and control of capable features equipped with your vehicle.

- Manuals & Warranties
- Schedule Maintenance
- Roadside Assistance
- Vehicle Health Report
- SiriusXM® Radio
- Safety Recalls
- Toyota Financial Services – Vehicle Payment

Remote Connect equipped vehicle functions:

- Lock/Unlock
- Start Vehicle
- Vehicle Finder
- Guest Driver settings

Scan QR Code to Download Toyota app.

Apple



Android



Or

Search “Toyota” at your applicable app store.



If you have a Toyota Owner's account, use your credentials to **“Sign In”** and Get Started with Toyota app.

Or

If you do not have a Toyota Owner's account, **“Register”** now to Get Started with Toyota app.



Getting Started with Connected Services²


Safety Connect³

- (SOS) EMERGENCY ASSISTANCE BUTTON
- AUTOMATIC COLLISION NOTIFICATION
- ROADSIDE ASSISTANCE
- STOLEN VEHICLE LOCATOR

Remote Connect⁴ (if equipped)

- START VEHICLE
- VEHICLE STATUS ALERTS
- LOCK/UNLOCK VEHICLE DOORS
- VEHICLE FINDER

Authentication is required to enable Remote Connect.




Available on select 2018 and newer vehicles. (Remote Start/Stop is not available on vehicles equipped with Manual Transmission.)

- STEP 1** Press [APPS] on the faceplate, then select "Communications" on display screen.




- STEP 2** Select "Authorization" icon.



- STEP 3** Enter the 6 character authorization code you received via email to enable remote services.



- STEP 4** Select "Submit."




- STEP 5** The vehicle has been successfully authorized for remote services. Select "OK."

Service Connect⁵ (if equipped)

- VEHICLE HEALTH REPORT
- VEHICLE MAINTENANCE ALERT NOTIFICATION

Available on select 2018 and newer vehicles.

- STEP 1** After registering and opting into Service Connect, you will be greeted with a notification of the following language "Would you like to start Toyota Service Connect Activation?"




- STEP 2** Select "Yes."



- STEP 3** Select "OK."

Destination Assist⁶ (if equipped)



Destination Assist provides drivers 24–hour access to a live agent who can provide directions through the vehicle’s factory–installed navigation system to an address or point of interest.

Wi-Fi Connect⁷

Multiple mobile devices

- Connect up to 5 Wi-Fi enabled devices
- Passengers can use smartphones, laptops and tablets

Infotainment

- Browse the internet
- Send and receive email
- Stay connected on social media
- Access favorite apps
- Stream movies




Several factors may affect smartphone and/or system performance *including*:

1. Smartphone operating system software version
2. Smartphone battery power level
3. Poor cellular reception to the smartphone
4. Multiple applications running on a smartphone at the same time
5. Charge/media cable quality
6. Smartphone operating system updates may also affect Toyota app functionality

For additional information, please visit: www.Toyota.com/connected-services

Connected Services Online Support



Toyota’s online support tool provides intuitive “How–To” instruction and videos.

To begin please visit:

<https://toyotaaudioandconnectedservicesupport.com/>

Apple CarPlay® (If equipped)


Setup of Apple CarPlay®



STEP 1 Ensure Siri® is enabled on your phone.



STEP 2 Plug a compatible iPhone® into the USB media port using an Apple® approved cable.



STEP 3 Select **Always Enable** to use CarPlay® each time the vehicle is operated.



STEP 4 Select **Allow** to use CarPlay® while the phone is locked.



* Screen depiction accurate at time of posting.

STEP 5 Apple CarPlay® is now ready to operate.

Requirements:

Bluetooth® functions will be inoperable while CarPlay® is in use. Wireless CarPlay® is not supported. Features may vary by vehicle model and phone.

To learn more about how your iPhone® works with CarPlay® visit: <https://support.apple.com/en-us/HT205634>
To view a full list of CarPlay® supported apps visit: <https://www.apple.com/ios/carplay/>

Siri® through CarPlay®



Push and hold the voice command talk switch for 2–3 second to activate.



* Screen depiction accurate at time of posting.

Once Siri® is activated you can ask to: make calls, send and receive text messages, listen to music and more.

Android Auto™ (If equipped)

Setup of Android Auto™




STEP 1 With Android 9 or below, the Android Auto™ app download is required. With Android 10, Android Auto™ is built in and the app is NOT required.



STEP 2 Open Android Auto™ app and tap get started.



STEP 3 Ensure Android Auto™ is enabled on the phone.




STEP 4 In the Projection Settings screen select Android Auto™ to on.



STEP 5 Plug a compatible Android™ smartphone into the USB media port using an Android approved cable.



STEP 6 Press menu button and then select the Android Auto™ icon.



STEP 7 * Screen depiction accurate at time of posting. Android Auto™ is now ready to operate.

Requirements:

Bluetooth® functions will be inoperable while Android Auto™ is in use. Wireless Android Auto™ is not supported. Features may vary by vehicle model and phone.

To learn more about how to use Android Auto™ visit: <https://www.android.com/auto>

Google Assistant through Android Auto™



Push and hold the voice command talk switch for 2–3 second to activate.



* Screen depiction accurate at time of posting.

Once Google Assistant is activated you can ask to: make calls, send and receive text messages, listen to music and more.

Amazon Alexa (If equipped)

Toyota + Alexa Setup



STEP 1 **Toyota app** and **Toyota+Alexa** apps are available to download at your app store.




STEP 2 Once **Toyota+Alexa** has successfully installed, open the app to complete the setup. Tap **Get started**.



iPhone users




STEP 3 Depending on your phone and application settings, Toyota+Alexa may automatically sign you in. Otherwise, **Sign In** or **Create a new Amazon account**.



STEP 4 Tap **Allow** for Toyota+Alexa to access Alexa Voice Services and Alexa Account Connection. Allow permissions.



Android users




STEP 3 Depending on your phone and application settings, Toyota+Alexa may automatically sign you in. Otherwise, **Sign In** or **Create a new Amazon account**.



STEP 4 Tap **Allow** for Toyota+Alexa to access Alexa Voice Services and Alexa Account Connection. Tap **Enable Permissions**.



STEP 5 To use the Toyota+Alexa app, your mobile device must be paired to the vehicle via **Bluetooth®**.



STEP 6 To launch Toyota+Alexa, press **Apps** and select **Toyota+Alexa**. Toyota+Alexa is now ready. Just say "Alexa" and wait for the tone, then speak your command.

Note: Ensure the Toyota + Alexa app is open on the paired phone.

SiriusXM®⁸ (If equipped)

SiriusXM® Audio



Toyota vehicles equipped with SiriusXM® come with a 3-month All Access trial subscription. Also enjoy SiriusXM® when you're not in your vehicle by linking the vehicle account with the SiriusXM® app.



* Screen depiction accurate at time of posting.

Audio Multimedia Online Support

A screenshot of the Toyota Audio & Connected Services Support website. The page features a woman in a car's driver seat, looking at the infotainment screen. Overlaid on the image is a form with the following fields: 'Select Vehicle Model' (dropdown), 'Select Vehicle Year' (dropdown), 'OR', and 'Enter 17 Digit VIN'. A red 'Get Started' button is at the bottom of the form. The website header includes the Toyota logo and 'Audio & Connected Services Support' text, along with a 'Support Videos' dropdown. The footer contains 'Helpful Links' with links to 'Audio Multimedia', 'Connected Services', 'Toyota.com', and 'Toyota Audio And Connected Services Support'. It also includes a 'Privacy Policy | California Privacy | Legal Terms' link and a copyright notice: '©2020 Toyota Motor Sales, U.S.A., Inc. All information applies to U.S. vehicles only'.

Toyota's online support tool provides intuitive "How-To" instruction and videos.

To begin please visit:

<https://toyotaaudioandconnectedservicesupport.com/>

Privacy & Protection

To learn about Toyota's Connected Services data collection, use, sharing and retention, visit: www.Toyota.com/privacyvts.

- ¹ The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage and carrier.
- ² Visit Toyota.com/connected-services or see your local Toyota Dealer for additional details.
- ³ Safety Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, all of which can limit system functionality or availability, including access to response center and emergency support. Stolen vehicle police report required to use Stolen Vehicle Locator. Some features may require the Toyota app. Registration required. Subscription required after trial. Service subject to change at any time without notice. Terms of Use apply. Data charges may apply. Service may vary by vehicle and region. See usage precautions and service limitations in Owner's Manual and Toyota.com/connected-services/ for additional details. To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁴ Toyota – Remote Connect
Use only if aware of circumstances surrounding vehicle and it is legal and safe to do so (e.g., do not remotely start engine if vehicle is in an enclosed space or vehicle is occupied by a child). Toyota Remote Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, which can limit system functionality and availability. Service may vary by vehicle and region. Registration and Toyota app download required. Subscription required after trial. Terms of Use apply. Data charges may apply. Remote start/stop not available on manual transmission-equipped vehicles. Services subject to change at any time without notice. See usage precautions and service limitations in Toyota Owner's Manual and <https://www.toyota.com/connected-services> for additional details. To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁵ Service Connect information provided is based on the last time data was collected from the vehicle and is not real time data. Service Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, which can limit functionality or availability. Service may vary by vehicle and region. Registration required. Subscription required after trial. Service subject to change at any time without notice. Terms of Use apply. Data charges may apply. See usage precautions and service limitations in Owner's Manual and Toyota.com/connected-services for additional details. To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁶ Destination Assist depends on an operative telematics device, a cellular connection, navigation map data and GPS signal strength and other factors outside of Toyota's control, which can limit system ability functionality or availability. Use common sense when relying on this information. Service may vary by vehicle and region. Registration required. Subscription required after trial. Services subject to change at any time without notice. Terms of Use apply. Data charges may apply. See Owner's Manual and Toyota.com/connected-services for additional limitations and details. To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁷ Wi-Fi Connect is available on select 2018 and newer Toyota vehicles. Visit Toyota.com/connectedservices for vehicle availability.
- ⁸ SiriusXM® audio services require a subscription sold separately by Sirius XM Radio Inc. To cancel, you must call SiriusXM at 1-866-635-2349. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com. All fees and programming subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. SiriusXM and all related marks and logos are trademarks of Sirius XM Radio Inc.

