

PRIUS *c*
2 0 1 8



QUICK REFERENCE GUIDE

2018

PRIUS *c*

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new Prius *c*.

A word about safe vehicle operations

This Quick Reference Guide is not a full description of Prius *c* operations. Every Prius *c* owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

INDEX

OVERVIEW

| | |
|---------------------------------|-----|
| Engine maintenance | 9 |
| Fuel tank door release & cap | 7 |
| Hood release | 8 |
| Indicator symbols | 4-5 |
| Instrument cluster | 4 |
| Instrument panel | 2-3 |
| Instrument panel light control | 8 |
| Keyless entry ^{1,2} | 6 |
| Smart Key system ^{1,2} | 7 |

FEATURES & OPERATIONS

| | |
|---|----|
| Audio | 18 |
| Auto lock/unlock ^{1,2} | 17 |
| Automatic air conditioning/heating | 16 |
| Clock | 22 |
| Cruise control | 20 |
| Drive mode | 11 |
| Hill-start Assist Control (HAC) | 23 |
| Hybrid Synergy Drive System | 10 |
| Hybrid transmission | 11 |
| Lights ^{1,2} & turn signals | 15 |
| Moonroof | 17 |
| Multi-Information Display (MID) ¹ | 21 |
| Parking brake | 20 |
| Power outlet-12V DC | 18 |
| Rear view monitor system | 23 |
| Seat adjustments-Front | 12 |
| Seat-Folding down rear seat | 13 |
| Seat heaters | 16 |
| Seats-Head restraints | 12 |
| Steering wheel switches | 19 |
| Telephone controls (Bluetooth®) | 22 |
| Tilt & telescopic steering wheel | 21 |
| Vehicle Stability Control (VSC)/ TRAC OFF switch | 23 |
| USB/AUX port | 19 |
| Windows-Power | 13 |
| Windshield wipers & washers | 14 |

TOYOTA SAFETY SENSE™ C (TSS-C)

| | |
|--------------------------------|-------|
| Automatic High Beams (AHB) | 29 |
| Lane Departure Alert (LDA) | 27-28 |
| Pre-Collision System (PCS) | 25-26 |
| Quick overview- | |
| Toyota Safety Sense™ C (TSS-C) | 24 |
| Sensors | 24 |

SAFETY & EMERGENCY FEATURES

| | |
|---|-------|
| Door locks | 31 |
| Floor mat installation | 33 |
| Rear door child safety locks | 31 |
| Seat belts | 30 |
| Spare tire & tools | 31 |
| Star Safety System™ | 32-33 |
| Tire Pressure Monitoring (warning) System (TPMS) | 30 |



BLUETOOTH® DEVICE PAIRING SECTION

34-43

¹ Visit your Toyota dealer for information on customizing this feature.


² Programmable by customer. Refer to the Owner's Manual for instructions and more information.

Instrument panel




¹ If equipped.

² For details, refer to the “Navigation System Owner’s Manual” and “2018 Entune™ Audio Quick Reference Guide.”



Instrument cluster



Indicator symbols

For details, refer to "Indicators and warning lights," Section 2-2, 2018 Owner's Manual.

-  Airbag SRS warning¹
-  **ABS** Anti-lock Brake System warning¹
-  Arrow direction indicates fuel tank door position
-  **AUTO** Automatic High Beam (AHB) indicator^{1a}
-  **BRAKE** Brake system warning¹
-  Brake system warning light (yellow indicator)¹
-  **SET** Cruise control²/cruise control "SET" indicators²
-  **ECO MODE** Eco Mode indicator
-  Electric power steering system warning¹
-  **EV** EV drive indicator
-  **EV MODE** EV Drive Mode indicator

-  Front fog light indicator²
-  Headlight low/high beam indicator
-  Immobilizer system indicator²
-  Lane Departure Alert (LDA) indicator
-  Low fuel level warning
-  Low outside temperature indicator
-  Low tire pressure warning¹
-  Malfunction/Check Engine indicator¹
-  Master warning¹
-  Parking brake warning
-  Pre-Collision System (PCS) warning¹
-  READY indicator
-  Seat belt reminder
(alarm will sound if speed is over 12 mph)
-  Shift position indicator
-  Slip indicator/Hill-start Assist Control indicator¹
-  SRS airbag on-off indicator¹
-  Turn signal indicator
-  Vehicle Stability Control (VSC) OFF indicator¹

¹ If indicator does not turn off within a few seconds of starting Hybrid System, there may be a malfunction. Have vehicle inspected by your Toyota dealer.

² If equipped.

OVERVIEW


Keyless entry

UNLOCKING OPERATION




NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.


LOCKING OPERATION



BACK DOOR LOCKING/UNLOCKING



PANIC BUTTON




* Driver door unlocking function can be programmed to unlock driver door only, or all doors. In some models, grasping front passenger door handle will unlock all doors. *Please refer to the Owner's Manual for more details on how to program the doors.*

NOTE: Doors may also be locked/unlocked using remote.

Smart Key system (if equipped)


START FUNCTION




NOTE: Gear shift lever must be in Park and brake pedal depressed.

POWER (WITHOUT STARTING HYBRID SYSTEM)

Without depressing the brake pedal, pressing the “POWER” switch will change the operation mode in succession from:




Fuel tank door release & cap




NOTE: Tighten until one click is heard. If the cap is not locked or tightened, Check Engine “” indicator may illuminate.

Hood release




Instrument panel light control



Engine maintenance

Windshield washer fluid tank

Engine oil filler cap



Engine oil level dipstick

Engine coolant reservoir

NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the “Warranty & Maintenance Guide.”

Maintenance reset light instructions can be found in “Maintenance Requirements Chapter” in Owner’s Manual.

FEATURES & OPERATIONS

Hybrid Synergy Drive System


The Hybrid Synergy Drive System utilizes a computer-controlled gasoline engine and electric motor to provide the most efficient combination of power for the vehicle. To conserve energy, when the brakes are applied the braking force generates electricity which is then sent to the traction battery. In addition, the engine shuts off when the vehicle is stopped. The benefits are better fuel economy, reduced vehicle emissions and improved performance.

NOTE: Fuel consumption and energy information of the Hybrid System are shown on the multi-information display or the Display Audio System.

TIPS FOR IMPROVED FUEL ECONOMY


- Ensure tire pressures are maintained at levels specified in the Owner's Manual.
- When possible, link trips to reduce engine cold starts.
- Avoid driving at speeds that are higher than necessary, especially on the highway.
- When possible, avoid sudden stops to maximize regenerative braking energy.
- Minimize use of the Air Conditioning.

STARTING THE HYBRID SYSTEM



- (1) Put the selector lever in "P."
- (2) Vehicles with Smart Key system:
Depress the brake pedal, and press the "POWER" switch briefly and firmly.
Vehicles without Smart Key system:
Depress the brake pedal, and turn the key to the "START" position.
- (3) The "READY" light will blink. After a few seconds, when the light remains steady and a beep sounds, you may begin driving.

Hybrid transmission




| | |
|----------|---------------------------|
| P | Park ¹ |
| R | Reverse |
| N | Neutral |
| D | Drive |
| B | Engine brake ² |

¹ The “POWER”/ignition switch must be “ON” and the brake pedal depressed to shift from Park.

² The engine brake is the equivalent of downshifting. Shift to “B” when engine braking is desired (e.g. downhill driving, coasting to a stop).

Drive mode


ECO MODE



Eco Mode helps achieve low fuel consumption during trips that involve frequent accelerating and braking.

Refer to the Owner's Manual for more details.

EV MODE




EV Drive Mode allows the electric motor (traction motor), powered by the hybrid battery (traction battery), to be used to drive the vehicle under certain driving conditions.


FEATURES & OPERATIONS

Seats-Head restraints


FRONT (ADJUSTABLE TYPE)/REAR CENTER



REAR OUTBOARD




Seat adjustments-Front




Seat-Folding down rear seat

SPLIT REAR SEATS





NON-SPLIT REAR SEAT



Windows-Power

Driver side



Automatic operation (driver side only) Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.


Window lock switch Deactivates all passenger windows. Driver's window remains operable.

FEATURES & OPERATIONS


Windshield wipers & washers

FRONT

Type A




Type B




* Intermittent windshield wiper frequency adjustment Rotate to increase/decrease wipe frequency. (if equipped)

REAR (IF EQUIPPED)

Type A



Type B




* The wipers will automatically operate a couple of times after the washer squirts.



Lights & turn signals

HEADLIGHTS

Type A




Type B




Daytime Running Light system (DRL) Automatically turns on the headlights at a reduced intensity.

FRONT FOG LIGHTS (IF EQUIPPED)

Type A




Type B



Front fog lights come on only when the headlights are on low beam.


TURN SIGNALS




Automatic air conditioning/heating

Automatic climate control ON

Adjusting the temperature setting will cause the airflow vents, air intake and fan to adjust automatically.




Seat heaters (if equipped)



Moonroof (if equipped)


SLIDING OPERATION

Push once to open to recommended position; again to open completely.



Recommended open position to minimize wind noise.

TILTING OPERATION



Push once to open; moonroof will automatically stop at the recommended position. Push again to open completely.

Auto lock/unlock

Automatic door locks can be programmed to operate in different modes, or turned OFF.

Shift position linked door locking/unlocking function

- Doors lock when shifting from Park.
- Doors unlock when shifting into Park.

Speed linked door locking function

- Doors lock when the vehicle speed goes above approximately 12 mph.

Driver's door linked door unlocking function


- Doors unlock when the engine switch is set from "ON" to "ACC" or "LOCK" and driver's door is opened.
- (With Smart Key) Doors unlock when the "ENGINE START STOP" switch is set to OFF and driver's door is opened.

Refer to the Owner's Manual for more details.


FEATURES & OPERATIONS

Audio

ENTUNE™ AUDIO



ENTUNE™ PREMIUM AUDIO WITH INTEGRATED NAVIGATION AND APP SUITE




Refer to the "Navigation System Owner's Manual" and "2018 Entune™ Audio Quick Reference Guide."

Power outlet-12V DC



For vehicles with a "POWER" button, make sure vehicle is in "POWER ON" mode. Or, for vehicles with an ignition switch, key must be in the "ACC" or "ON" position for use.

USB/AUX port



USB port

By connecting a USB-compatible portable audio device or USB memory stick to the USB port, you can listen to music from the portable audio device or USB memory stick through the vehicle's speaker system.


AUX port

By inserting a mini plug into the AUX port, you can listen to music from a portable audio device through the vehicle's speaker system while in AUX mode.

Steering wheel switches


Audio controls

Volume control



Meter controls

Scroll up/down or select menu
Enter/select



“MODE”

Push to change audio source, mute or pause the current operation. To mute or pause the current operation, press and hold. To cancel the mute or pause, press and hold again.

“ \wedge / \vee ” or “ \langle / \rangle ”

Use the steering wheel controls to your left, to search within the selected audio medium (radio, CD, etc.). Use the steering wheel controls to your right, to scroll through menu items and select or return to the previous screen.


“”

Push and hold to access mobile assistant. Once you connect a compatible, registered mobile phone, you can access Siri Eyes Free using mobile assistant switch.


Refer to Owner's Manual for more details.

Cruise control

TURNING SYSTEM ON/OFF




FUNCTIONS




¹ The set speed may also be cancelled by depressing the brake pedal.

Parking brake



Set



Release



Tilt & telescopic steering wheel




Hold wheel, push lever down, set angle and length, and return lever.


NOTE: Do not attempt to adjust while the vehicle is in motion.

Multi-Information Display (MID)

Display



Meter controls



Push “ \wedge / \vee ” or “ \leftarrow / \rightarrow ” to scroll through the following information screens:

- (1) Drive information
- (2) Settings and screen OFF
- (3) Warning messages
- (4) Menu icons


Menu icons

-  Drive information
-  ECO fuel consumption information
-  LDA operational status
-  Settings display


* Factory default is OFF. To activate, access settings through “Settings & Screen Off.”

Clock

Display




Meter control switches




- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
 - (2) Press “<>” switches and press “⊙” to select Meter Settings screen.
 - (3) Press “⊙” to select Time and date screen.
 - (4) Press “<>” switches and press “⊙” to select Clock screen to adjust time.
- You can press “←” to go back to the previous screen at any time.

Telephone controls (Bluetooth®)


Microphone (Type A, with moonroof)




Microphone (Type B, without moonroof)



Audio unit





Steering wheel telephone switches



Bluetooth® technology allows dialing or receipt of calls without taking hands from the steering wheel or using a cable to connect the telephone and the system.

Refer to “Bluetooth® Device Pairing Section,” in this guide, for more information about phone connections and compatibility.



Hill-start Assist Control (HAC)



HAC helps prevent rolling backwards on an incline. To engage, push further down on brake pedal while at a complete stop until a beep sounds and slip indicator illuminates. HAC holds for approximately two seconds after releasing brake pedal.

Refer to the Owner's Manual for more details.

Rear view monitor system




The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is located above the license plate.

To adjust the image on the rear view monitor screen, press the "SETUP" button and select "Display" on the "Setup" screen. Select "Camera" to adjust the screen contrast and brightness.

Refer to the Owner's Manual for limitations and more details on this system.

Vehicle Stability Control (VSC)/TRAC OFF switch



The VSC OFF switch can be used to help free a stuck vehicle in surroundings like mud, dirt or snow. While car is stopped, press switch to disable the TRAC system.

To disable both VSC and TRAC systems, press the switch for at least 3 seconds.

Refer to the Owner's Manual for more details.

Quick overview-Toyota Safety Sense™ C (TSS-C)

Toyota Safety Sense™ C (TSS-C) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS-C is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the Owner's Manual for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to <http://www.toyota.com/safety-sense>.



Pre-Collision System (PCS)

PCS is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system detects a potential collision with a preceding vehicle is likely to occur.



Lane Departure Alert (LDA)

LDA is designed to provide notification when the system detects an unintended lane departure.




Automatic High Beams (AHB)

AHB is designed to detect the headlights of oncoming vehicles and the tail lights of preceding vehicles and switch between high beams and low beams as appropriate.

Sensors

TSS-C combines an in-vehicle camera and laser mounted in front of the inside rear view mirror. These sensors support the driver assist systems.



Pre-Collision System (PCS)



The Pre-Collision System uses a laser sensor and camera sensor to help detect vehicles in front of your vehicle.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the Pre-Collision System yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle may not be detected by the laser and camera sensors, preventing the system from operating or engaging properly.

Refer to a Toyota Owner's Manual for a list of additional situations where the system may not operate, or system effectiveness is limited.

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist

If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.


Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.

Refer to the Toyota Owner's Manual for additional information on PCS operation, settings adjustments, limitations, and precautions before attempting to use it.


TOYOTA SAFETY SENSE™

CHANGING THE PRE-COLLISION ALERT TIMING



Each time the PCS switch is pressed, the response to the PCS alert timing changes.

DISABLING THE PRE-COLLISION SYSTEM (PCS)



To disable the system


Press the PCS switch for 3 seconds or more.
The  will turn on and a message will be displayed on the Multi-Information Display (MID).

To enable the system

Press the PCS switch again.
The system is enabled.

Note: PCS is enabled each time the engine switch is turned to Ignition On. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same).


Lane Departure Alert (LDA)



LDA in TSS-C uses an in-vehicle camera designed to detect visible white and yellow lane markers in front of the vehicle and the vehicle's position on the road. If the system determines that the vehicle is starting to unintentionally deviate from its lane, the system alerts the driver with an audio and visual alert. When the alerts occur, the driver must check the surrounding road situation and carefully operate the steering wheel to move the vehicle back to the center part of their lane.

LDA is designed to function at speeds of approximately 32 MPH or higher on relatively straight roadways.

TURNING ON THE LDA SYSTEM



Press the LDA switch to turn the LDA system on. Depress again to turn it off.


Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.

Refer to the Toyota Owner's Manual for additional information on LDA operation, settings adjustments, limitations, and precautions before attempting to use it.

LDA FUNCTIONS

The LDA function displays when the Multi-Information Display (MID) is switched to the driving assist system information screen.

LDA function display



Lane Departure Alert (LDA) indicator flashes orange when operating.



The system displays solid white lines on the LDA indicator when visible lane markers on the road are detected. A side flashes orange to alert the driver when the vehicle deviates from its lane.




The system displays outlines on the LDA indicator when lane markers on the road are not detected or the function is temporarily canceled.

Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, LDA may not function on the side(s) where white/yellow lines are not detectable.

Refer to the Toyota Owner's Manual for additional information on LDA operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)



AHB is a safety system designed to help drivers see more of what's ahead at nighttime without dazzling other drivers. When enabled, AHB uses an in-vehicle camera to help detect the headlights of oncoming vehicles and tail lights of preceding vehicles, then automatically switches between high and low beams as appropriate to provide the most light possible and enhance forward visibility. By using high beams more frequently, the system may allow earlier detection of pedestrians and obstacles.

Refer to the Toyota Owner's Manual for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

ACTIVATING THE AHB SYSTEM

With the engine switch in IGNITION ON mode and headlight switch turned to "AUTO" position, push lever away from you.

The  will come on when the headlights are turned on automatically to indicate that the system is active.

Note: Pull the lever back toward you to turn the AHB system off.

The  will turn off and the high beam indicator turns on.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY

When all of these conditions are met, high beams will be automatically turned on (after approximately 1 second):


- Vehicle speed is above approximately 21 mph (33 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.

If any of these conditions occur, high beams will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

SAFETY & EMERGENCY FEATURES

Seat belts




Keep as low on hips as possible

NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic Locking Retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the Owner's Manual.

Tire Pressure Monitoring (warning) System (TPMS)



System reset initialization

1. Push and hold "SET" button until the indicator blinks three times.
2. Wait a few minutes to allow initialization to complete.




After adjusting tire pressures, or after tires have been rotated or replaced, turn the "POWER"/ignition switch "ON" and press and hold the "SET" button until indicator blinks three times. Let the vehicle sit for a few minutes to allow initialization to complete.

Refer to the load label on the door jamb or the Owner's Manual for tire inflation specifications.

If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota dealer.


NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.

Door locks



Rear door child safety locks


Rear door



Moving the lever to the lock position will allow the door to be opened only from the outside.

Spare tire & tools


Tool location



¹ For detailed directions on removing the jack from under the driver's seat, refer to the Owner's Manual.

² Jack handle, wheel nut wrench and towing eyelet

Removing the spare tire



Refer to the Owner's Manual for tire changing and jack positioning procedures.

SAFETY & EMERGENCY FEATURES

Star Safety System™

All new Toyota vehicles come standard with the Star Safety System™, which combines Anti-lock Braking System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Traction Control (TRAC) and Vehicle Stability Control (VSC),

Refer to the Owner's Manual for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by "pulsing" each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or "panic" braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. Abrupt stops can cause a vehicle to tilt forward, reducing the braking power of the rear wheels. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).

Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

VEHICLE STABILITY CONTROL (VSC)

VSC helps prevent loss of traction during cornering by reducing engine power and applying brake force to selected wheels.


Toyota's VSC monitors steering angle and the direction your vehicle is traveling. When it senses that the front or rear wheels begin to lose traction, VSC reduces engine power and applies braking to selected wheels. This helps restore traction and vehicle control.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



BLUETOOTH® DEVICE PAIRING SECTION


Do not attempt the Bluetooth® Pairing process while driving.

To begin the Bluetooth® Pairing process, press the HOME button on the faceplate of your Toyota Vehicle Entune™ Multimedia Head Unit.¹

Bluetooth® Pairing for Android phone and Entune™ touch screen system


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Android mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.²

Initiate Bluetooth® on your Android®



STEP 1

From your **APPS SCREEN**, select **SETTINGS**.



STEP 2

Select **CONNECTIONS** and select **BLUETOOTH**.



STEP 3


Ensure **BLUETOOTH** is **ON**.



STEP 4

Select **YOUR PHONE DEVICE** to make it discoverable.

Phone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your Android device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

¹ To determine which head unit is installed in your vehicle, refer to the Audio section in this guide. Entune™ Premium Audio screens are shown in this section. Screens and features may vary by Entune™ system.

² Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

BLUETOOTH® DEVICE PAIRING

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6


On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.



STEP 7

Select **BLUETOOTH**.


Image shown is a sample image, features may vary.



STEP 8

Select **ADD**, to add your phone device.

For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen.



STEP 9

Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit



STEP 12

Using your smartphone, you will need to allow Entune access to your messaging and contacts.

It is recommended to check the "Don't ask again" box, so as not to have to press OK every time the phone makes a Bluetooth connection with your Toyota.



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

Bluetooth® Pairing for iPhone and Entune™ touch screen system

****Do not attempt the Bluetooth® Pairing process while driving.****


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all iPhone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

Initiate Bluetooth® on your iPhone®



STEP 1

From the **HOME SCREEN**, select **SETTINGS**.



STEP 2

Select **BLUETOOTH**.




STEP 3

Ensure **BLUETOOTH** is **ON**.



STEP 4

Your iPhone will seek out Bluetooth devices while remaining discoverable.




STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.

For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen.



STEP 7


Select **BLUETOOTH**.

Image shown is a sample image, features may vary.



STEP 8

Select **ADD**, to add your phone device.



STEP 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.

BLUETOOTH® DEVICE PAIRING



STEP 12

Using your smartphone, you may need to allow Entune access to your messaging and contacts.

Only current iPhone text messages can be viewed on the head unit. iPhone does not allow text message reply.



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

Bluetooth® Pairing for Windows Phone and Entune™ touch screen system

****Do not attempt the Bluetooth® Pairing process while driving.****

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Windows Phone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

Initiate Bluetooth® on your Windows Phone®




STEP 1

From your APP LIST, select **SETTINGS**.



STEP 2

Select **BLUETOOTH**.



STEP 3

Ensure **BLUETOOTH** is **ON**.



STEP 4

Phone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

BLUETOOTH® DEVICE PAIRING

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.



STEP 7

Select **BLUETOOTH**.

Image shown is a sample image, features may vary.



STEP 8

Select **ADD**, to add your phone device.

For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen.



STEP 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10

Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit



STEP 12

Using your smartphone, you may need to allow Entune access to your contacts.



STEP 13

A confirmation will appear that your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

NOTES

NOTES



www.toyota.com/owners

CUSTOMER EXPERIENCE CENTER

1-800-331-4331



Printed in U.S.A. 6/17
17-MKG-10173



00505QRG18PRIC