

QUICK REFERENCE GUIDE



MIRAI

2023



2023

MIRAI

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new Mirai.

A word about safe vehicle operations

This Quick Reference Guide is not a full description of Mirai operations. Every Mirai owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

INDEX

OVERVIEW

Fuel cell compartment maintenance	9
Fuel door release button & cap	8
Hood release	9
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
Instrument panel light control	8
Keyless entry ^{1,2}	6-7
Smart Key system ^{1,2}	7

HYDROGEN FUEL CELL SYSTEM & SAFETY FEATURES

Hydrogen Fuel Cell System	10-14
Water release (H ₂ O) switch	15

FEATURES & OPERATIONS

Active Sound Control (ASC)	18
Advanced Park ²	44-45
Air conditioning/heating ^{1,2}	34-36
Audio Multimedia	31
Auto lock/unlock ^{1,2}	16
Automatic transmission	16
Blind Spot Monitor (BSM) ² and Rear Cross Traffic Alert (RCTA) ²	39
Clock	20
Door lock switches	18
Driving mode select switch	17
Electric parking brake	26
Electric sunshade	21
Front and Rear Parking Assist with Automatic Braking (PA w/AB) ²	42-43
Front seats-Adjustments	22
Garage door opener (HomeLink®) ³	23
Head-Up Display (HUD) ²	25
Heated steering wheel, Heated/ventilated seats ^{1,2}	33
Intuitive parking assist ²	41
Lights ^{1,2} & turn signals ¹	28
Luggage security system	20
Multi-Information Display (MID) ^{1,2}	24
Panoramic View Monitor (PVM)	40
Power outlet-12V DC	29
Power outlets-120V AC	30
Power windows ¹	18
Qi wireless charger	32

FEATURES & OPERATIONS (continued)

RCD (Rear Camera Detection) ²	38
Rear sunshade ¹	21
Rear view monitor system	37
Seats-Head restraints	22
Snow mode	17
Steering lock release	19
Steering wheel switches & telephone controls (Bluetooth®)	29
Tilt & telescopic steering wheel	19
USB Type-A media port	31
USB Type-C charge ports	31
Vehicle Stability Control (VSC)/ TRAC OFF switch	37
Windshield wipers & washers	27

TOYOTA SAFETY SENSE™ 2.5+ (TSS 2.5+)

Automatic High Beams (AHB)	59-60
Full-Speed Range Dynamic Radar Cruise Control (DRCC)	56-58
Lane Tracing Assist (LTA) System	50-55
Pre-Collision System with Pedestrian Detection (PCS w/PD)	47-49
Quick overview-Toyota Safety Sense™ 2.5+ (TSS 2.5+)	46
Road Sign Assist (RSA)	60-61
Sensors	47

SAFETY & EMERGENCY FEATURES

Emergency tire puncture repair kit	64-65
Floor mat installation	67
Rear door child safety locks	62
Safety Connect®	62
Seat belts	63
Seat belts-Shoulder belt anchor	63
Star Safety System™	66-67
Tire Pressure Monitoring (warning) System (TPMS)	65
Trunk-Internal release	63

GETTING STARTED WITH TOYOTA AUDIO MULTIMEDIA AND CONNECTED SERVICES

	68-79
--	-------

¹ Visit your Toyota dealer for information on customizing this feature.

² Programmable by customer. Refer to the "Owner's Manual" for instructions and more information.

³ HomeLink® is a registered trademark of Gentex Corporation.

OVERVIEW

Instrument panel

Multi-Information Display (MID) control switches

Telephone switch²

Full-Speed Range Dynamic Radar Cruise Control (DRCC) vehicle-to-vehicle distance switch

Audio volume control switch²

Full-Speed Range Dynamic Radar Cruise Control (DRCC) switch

Voice command talk switch²

Lane Tracing Assist (LTA) switch

Audio control switches²

Steering wheel controls

HUD (Head-Up Display) switch¹


Windshield wiper and washer control

Instrument panel light control switches

Meters/Multi-Information Display (MID)

"ODO/TRIP" switch

Headlights/turn signals control




Automatic High Beams (AHB) switch

VSC OFF switch

Panoramic View Monitor (PVM) switch^{1,2}

Snow mode switch

Power outlet-120V AC¹



Rear sunshade switch¹

Windshield wiper de-icer switch

Trunk opener switch

Fuel tank door release switch

Hood lock release lever



Tilt and telescopic steering release lever¹

Power tilt and telescopic steering control switch¹


"POWER" button

¹ If equipped.

² For details, refer to the “Multimedia Owner’s Manual” or visit www.toyota.com/audio-multimedia for additional resources.



Instrument cluster



Indicator symbols

For details, refer to “Warning lights and indicators,” Section 3-1, 2023 “Owner’s Manual”.



AIRBAG ON/OFF indicator¹



ABS (Anti-lock Brake System) warning¹



Advanced Drive indicator⁴



Advanced Drive warning^{1,4}



AHB (Automatic high beams) indicator



BSM (Blind Spot Monitor) OFF indicator¹



BSM outside rear view mirror indicators¹



Br mode indicator



Brake hold operating indicator^{1,2,6}



Brake hold standby indicator¹



Brake system warning^{1,6}



Brake system warning^{1,6} [yellow]

	Charging system warning ⁶		Open door warning
	Constant speed cruise control/Full-Speed Range Dynamic Radar Cruise Control (DRCC) indicator		Parking brake indicator ^{2,6}
	Constant speed cruise control/Full-Speed Range DRCC SET indicator		Pop Up Hood warning ¹
	Driver's and front passenger's seat belt reminder (alarm will sound when the vehicle is on)		PCS (Pre-Collision System) warning ^{1,2}
	Eco drive mode indicator		RCD (Rear Camera Detection) OFF indicator ^{1,2,6}
	Electric power steering system warning ^{1,6} [red/yellow]		READY indicator
	Front and Rear Parking Assist with Automatic Braking OFF indicator ^{1,4,5,6}		RCTA (Rear Cross Traffic Alert) OFF indicator ^{1,2,6}
	Fuel cell system overheat warning ⁶		Rear passengers' seatbelt reminder ⁶
	Headlight low/high beam indicator		Security indicator
	High coolant temperature warning [red]/Low coolant temperature indicator [blue]		Smart key system indicator
	Hydrogen leak warning ^{1,6}		Slip indicator ^{1,3}
	Inappropriate pedal operation warning ⁶		Snow mode indicator
	Intuitive parking assist OFF indicator ^{4,6}		Sport mode indicator
	LTA (Lane Tracing Assist) indicator ⁶ [white/green/orange ³]		SRS airbag warning ¹
	Low fuel level warning		Turn signal indicator
	Low outside temperature indicator		VSC (Vehicle Stability Control) OFF indicator ¹
	Low tire pressure warning ¹		

¹ If the indicator does not turn off within a few seconds of starting the fuel cell system, there may be a malfunction. Have the vehicle inspected by your Toyota dealer.

² If the indicator flashes, there may be a malfunction. Refer to the "Owner's Manual".

³ If the indicator flashes, it indicates that the system is operating.

⁴ If equipped.


⁵ Refer to section PKSB (Parking Support Braking function) in the "Owner's Manual".

⁶ With warning buzzer.

OVERVIEW

Keyless entry

UNLOCKING OPERATION




Press
ONCE: Driver door
TWICE: All doors

Carry Smart
Key remote


Driver door unlock*

Grasp



NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

LOCKING OPERATION



Press


Carry Smart
Key remote

All-door lock

Touch



TRUNK LID OPERATION (OPENING/LOCKING/UNLOCKING)



HOLD



Press and hold

Carry Smart
Key remote




* Driver door unlocking function can be programmed to unlock driver door only, or all doors. Grasping any passenger door handle will unlock all doors.

Please refer to the "Owner's Manual" for more details on how to program the doors.

NOTE: Doors may also be locked/unlocked using the mechanical key. (Slide the release lever on the bottom of Smart Key and take the mechanical key out.)

PANIC BUTTON




HOLD
Press and hold



Smart Key system


START FUNCTION



NOTE: The Smart Key must be carried to enable the start function. With the shift lever in Park and the brake pedal depressed, press the power button.


POWER (WITHOUT STARTING THE FUEL CELL SYSTEM)

Without depressing the brake pedal, pressing the power button will change the operation mode in succession from:




A - "ACCESSORY", **B** - "IGNITION ON"

Fuel door release button & cap




Closing the door





When the fuel door is open, the fuel cell system will not start. When the "READY" indicator is on or the vehicle is on, the fuel door will not open.


Instrument panel light control



Hood release



Fuel cell compartment maintenance



NOTE: Regularly scheduled maintenance at your Toyota dealer will help extend the life of your vehicle and maintain performance.
Please refer to the “Warranty & Maintenance Guide.”

HYDROGEN FUEL CELL SYSTEM & SAFETY FEATURES

Hydrogen Fuel Cell System

Fuel cell vehicles use electricity, which is generated by a chemical reaction between hydrogen and oxygen in a fuel cell stack. Excess electricity is stored in a traction battery that is used to power high voltage systems and assist on initial acceleration.

The fuel is H₂ (compressed hydrogen gas), so the exhaust, when running, is only water and water vapor. As they do not emit CO₂ (Carbon Dioxide) and NO_x (Nitrogen Oxides) at the tailpipe, fuel cell vehicles are considered zero emission vehicles.

NOTE: Fuel consumption and energy information of the Hydrogen Fuel Cell System are shown on the Multi-Information Display (MID) and the multimedia display.

TIPS FOR IMPROVED FUEL ECONOMY

- Ensure the tire pressures are maintained at levels specified in the “Owner’s Manual”.
- Drive the vehicle smoothly. Avoid abrupt acceleration and deceleration.
- Avoid driving at speeds that are higher than necessary, especially on the highway.
- When possible, avoid sudden stops to maximize regenerative braking energy.
- Minimize use of the air conditioning.

Fill with fuel at hydrogen stations compliant with SAE J2601.

If you have questions about hydrogen station compliance, consult your Authorized Mirai Fuel Cell Toyota Dealer.

Observe the notices and cautions shown at the hydrogen station.

The filling time and amount may differ depending on the equipment of the hydrogen station. It may make the possible driving distance shorter.

BEFORE FUELING

When you arrive at the station, prepare for fueling:


- 1) Ensure the vehicle is OFF and in Park with parking brake set.
- 2) Press the fuel door release button and refer to instructions in ‘Fuel door release button & cap section’ to prepare the vehicle to accept hydrogen fuel.

Note: Fuel door will not open if the READY indicator is on. The fuel door will automatically re-lock if you don’t open within 30 seconds.

- 3) Now you are ready to refuel. Outside the vehicle at the pump, use the station’s best practice guidelines and instructions on how to refuel using their nozzle.


For assistance, call Mirai Dedicated Customer Support toll free at 1-800-331-4331 (Option 3.)

TATSUNO H70 HYDROGEN GAS NOZZLE




The integrated collar snaps into place with a “click,” creating a secure connection.

Place nozzle on receptacle



- (1) Grasp the black handle with one hand, and support the blue collar with the other.
- (2) Place the nozzle on Mirai's fuel receptacle and push toward the car using the handle.
- (3) A yellow ring will be visible below the collar when the nozzle is fully connected. To ensure a positive connection, gently tug on the handle. Begin fueling.
- (4) Once fueling is finished, grab the black handle with one hand while supporting the blue collar with the other, just as before.
- (5) Pull on the collar and the nozzle will release. Keep pulling until the nozzle is fully disconnected.


WALTHER H70 HYDROGEN GAS NOZZLE



Operation of the Walther nozzle is identical to that of the Tatsuno nozzle with one notable exception: When connected, the Walther indicator ring is green.


HYDROGEN FUEL CELL SYSTEM & SAFETY FEATURES

WEH H70 HYDROGEN GAS NOZZLE




The integrated hand grip locks and unlocks the nozzle, creating a secure connection for safe fueling.

Place nozzle on receptacle




- (1) Seat the nozzle onto the receptacle fully. (This is the first step to help create a secure connection for safe fueling.)

- (2) To lock the nozzle to the vehicle, squeeze the hand grip until the latch is engaged.




- (3) Gently pull back on the nozzle to ensure it is locked onto the receptacle. (Be careful not to squeeze or contact the hand grip when checking if the nozzle is secure, as it may unlock the nozzle.)



Once the nozzle is secure, you can follow the station's instructions to begin dispensing fuel.


CAUTION: Ensure that the nozzle lock is properly engaged to the vehicle. Failure to do this may result in the nozzle **coming off when the flow of hydrogen begins**. This may result in damage to the nozzle, station, or vehicle and/or injury/death to you and people near the fueling station.

- (4) After fueling is complete, pull the latch to unlock the hand grip and remove the nozzle.



WEH H35 HYDROGEN GAS NOZZLE


H35 allows for up to a half tank fill from empty.




Integrated collar snaps into place with a 'click.' Rotate the cam lock handle clockwise to secure connection for safe fueling.

Place nozzle on receptacle


(1) Make sure the lock is in the OFF position.




(2) Holding the handle, fully seat the nozzle onto the receptacle.



(3) Rotate the lock fully clockwise to the ON position to lock the nozzle.



(4) Holding the handle, gently pull back on the collar to ensure the nozzle is securely locked. Once the nozzle is secure, you can follow the station's instructions to begin dispensing fuel.




CAUTION: Ensure that the nozzle lock is properly engaged to the vehicle. Failure to do this may result in the nozzle **coming off when the flow of hydrogen begins**. This may result in damage to the nozzle, station, or vehicle and/or injury/death to you and people near the fueling station.


HYDROGEN FUEL CELL SYSTEM & SAFETY FEATURES

WEH H35 HYDROGEN GAS NOZZLE (CONTINUED)

- (5) After filling is complete, rotate the lock back to the OFF position.



- (6) Holding the handle and collar, pull back on the collar to unlock and remove the fuel nozzle.




TIP-AFTER REFUELING

NOTE: If the nozzle cannot be removed after fueling, it may be frozen to the vehicle. Wait for the hydrogen nozzle to thaw before attempting to remove. Do not pull or rotate the hydrogen nozzle forcibly or damage will occur.

Refer to the Refueling section in the "Owner's Manual" for additional information.

Water release (H₂O) switch



Water is a natural by-product of the fuel cell process. The system is designed to automatically purge water from the drain pipe at the rear of the vehicle while driving and sometimes while it is shut off.

Water can be manually purged before parking in certain situations by pressing the "H₂O" switch with the vehicle in "READY" mode. The system will regulate water levels automatically. Drivers should typically let the vehicle handle this as opposed to using this switch.

Refer to the "Owner's Manual" for more details on this system before attempting to use it.

FEATURES & OPERATIONS

Auto lock/unlock

Automatic door locks can be programmed to operate in different modes, or turned OFF.

DEFAULT SETTING

Shift position linked door locking/unlocking function

- Doors lock when shifting from Park.
- Doors unlock when shifting into P.

CUSTOMIZED SETTING

Speed linked door locking function


- Doors lock when the vehicle speed is approximately 12 mph (20 km/h) or higher.

Driver's door linked door unlocking function

- Doors unlock when the driver's door is opened within approximately 45 seconds after the vehicle is turned off.

Refer to the "Owner's Manual" for more details.


Automatic transmission



- * Br Mode is the equivalent of downshifting. Shift to "Br" when strong regenerative braking is desired (i.e. downhill driving, coasting to a stop, etc.).
To select Br mode, shift the shift lever down.

Refer to the "Owner's Manual" for limitations and more details on this system.

Driving mode select switch



Sport mode

Use Sport mode when agile driving response is desired, for example, when driving on roads with many curves.

Normal mode

Use for normal driving.

Eco drive mode


Use Eco drive mode to help achieve low fuel consumption during trips that involve frequent accelerating.

Refer to the "Owner's Manual" for limitations and more details on this system.


Snow mode

Snow mode can be selected to suit the conditions when driving on slippery road surfaces, such as on snow.

Type A




Type B




FEATURES & OPERATIONS

Active Sound Control (ASC) (if equipped)


The ASC is a system that conveys the operating conditions, such as acceleration and deceleration of the vehicle, with sounds to the driver. The respective tone changes for normal mode and sport mode.



Door lock switches



Power windows




All window auto up/down

Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.

Window lock switch

Deactivates all passenger windows. Driver's window remains operable.


Steering lock release



When the steering lock cannot be released, “Push Power Button while Turning Steering Wheel in Either Direction” will be displayed on the Multi-Information Display (MID). Press the power button shortly and firmly while turning the steering wheel left and right.


Tilt & telescopic steering wheel

MANUAL (IF EQUIPPED)



Hold the steering wheel, push the lever down, set angle and length and return the lever.

POWER (IF EQUIPPED)




Toggle the control switch to set angle and length.

NOTE: Do not attempt to adjust while the vehicle is in motion.

Automatic tilt-away & returning function (if equipped): When the vehicle is turned off, the steering wheel moves up and away from driver and stows, but returns to its position when the vehicle is “ACC” or “ON” mode.

Power easy access system (if equipped): The steering wheel and driver’s seat move in accordance with power switch mode and the driver’s seat belt condition.

Clock



- 1) Press “” on the main menu.
- 2) Select “**General**” on the submenu.
- 3) Select “**Date & Time**.”
- 4) Select the desired items to be set.


NOTE: It is recommended to “Set date & time by GPS” feature to ON for automatic time updates based on your location.

Refer to the “Multimedia Owner’s Manual” for more details.

Luggage security system

To protect luggage stored in the trunk against theft, the luggage security system can be set to on.


Trunk opener main switch (in the glove box)



To disable the trunk opener switch, turn the main switch off.

The trunk lid cannot be opened even with the wireless remote control or the entry function.

Electric sunshade (if equipped)



Lightly press either side of the switch while opening/closing is in progress, the electric sunshade stops partway.

The vehicle must be on for use.


Rear sunshade (if equipped)

The rear sunshade can be extended and retracted using the rear sunshade switch and rear control panel.

OPERATION

From front seat


Press the switch to extend/retract.



From rear seat


Press "⏻" on the rear control panel.

Then select "SHADE".



The vehicle must be on for use.


Front seats-Adjustments



* If equipped.


Power easy access system (if equipped): The driver's seat and steering wheel move in accordance with power switch mode and the driver's seat belt condition.

Seats-Head restraints




Garage door opener (HomeLink®)*

VEHICLES WITH AUTO ANTI-GLARE INSIDE REAR VIEW MIRROR



VEHICLES WITH DIGITAL REARVIEW MIRROR



Garage door openers manufactured under license from HomeLink®* can be programmed to operate garage doors, estate gates, security lighting, etc.



Refer to the "Owner's Manual" for more details.

For programming assistance, contact HomeLink® at 1-800-355-3515, or visit www.homelink.com/toyota.



* HomeLink® is a registered trademark of Gentex Corporation.

Multi-Information Display (MID)




Press MID control switches to change and select information in the following:

-  Driving information display
-  Navigation system-linked display
-  Audio system-linked display
-  Vehicle information display
-  Settings display
-  Warning message display


Refer to the "Owner's Manual" for more settings and customizable features.

Head-Up Display (HUD) (if equipped)

The head-up display projects a variety of driving-related information and the operating state of the driving support systems on the windshield.



DISPLAY ON/OFF



CHANGE SETTINGS


Press MID control switches and select “” on the Multi-Information Display (MID) and select “Head-up Display” to access Head-up display settings. And push “” to enter selection.

Refer to the “Owner’s Manual” for more details.

Electric parking brake

PARKING BRAKE


Automatic mode



A "EPB Shift Interlock Function Activated"

B "EPB Shift Interlock Function Deactivated"

Manual mode



Automatic mode (shift lever operation)

To turn automatic mode ON, while vehicle is stopped, pull and hold the parking brake switch until "EPB Shift Interlock Function Activated" displays on the Multi-Information Display (MID). While depressing the brake pedal, shifting the lever into P position will automatically set the brake and turn the parking brake indicator light on. To release the brake pedal, depress brake and shift the lever out of P. The indicator will turn off.


To turn automatic mode OFF, press and hold the parking brake switch until "EPB Shift Interlock Function Deactivated" displays on the MID.

Manual mode

While the vehicle is stopped and the brake pedal is depressed, pull the switch to set the parking brake and turn the parking brake indicator light on. To release, depress the brake pedal and press the switch. The indicator will turn off.

Refer to the "Owner's Manual" for limitations and more details.

BRAKE HOLD



Standby indicator


Operating indicator

The brake hold system keeps the brake applied when the shift lever is in D or N while the system is on and the brake pedal has been depressed to stop the vehicle. The system releases the brake when the accelerator pedal is depressed with the shift lever in D to allow smooth start off.

Refer to the "Owner's Manual" for limitations and more details.

Windshield wipers & washers


WITH INTERMITTENT WIPER




Pull to wash and wipe

* **Intermittent windshield wiper frequency adjustment:** Rotate to increase/decrease wiper frequency.

WITH RAIN-SENSING WIPER



Push to wash rear camera



Pull to wash and wipe

** **Rain-sensing windshield wiper sensitivity adjustment:** Rotate to increase/decrease sensor sensitivity.


Refer to the "Owner's Manual" for more information.

FEATURES & OPERATIONS

Lights & turn signals

HEADLIGHTS

Operating the “☀️” switch turns on the headlight indicator .



Daytime Running Light system (DRL)

Automatically turns on under certain conditions to make vehicle more visible to other drivers. Not for use at night. (The parking brake needs to be released and the headlight switch must be in the “>><<” or “AUTO” position while the vehicle is on.)

Automatic light cut off system (AUTO)

- Headlights are on: The headlights and taillights will turn off automatically 30 seconds after the vehicle is turned from ON to ACC or OFF and the driver’s door is opened and closed. (If the “🔒” switch on the Smart Key remote is pressed after all doors are closed, the lights will turn off immediately.)
- Only the taillights are on: The taillights will turn off automatically if the vehicle is turned from ON to ACC or OFF and the driver’s door is opened.


Automatic High Beams system (AHB)*

Automatically switches between high and low beams as appropriate to enhance vision at night.

Refer to Toyota Safety Sense™ 2.5+ (TSS 2.5+) in this guide or the “Owner’s Manual” for more details on the Automatic High Beams feature.


* Operating conditions must be met. Refer to the “Owner’s Manual” for details.

TURN SIGNALS



* Move the lever partway and release. The signals will flash three times.

Steering wheel switches & telephone controls (Bluetooth®)




Bluetooth® technology allows dialing or receipt of calls without removing your hands from the steering wheel.

Refer to the Bluetooth® device pairing in this guide or the “Multimedia Owner’s Manual” for additional user instructions.

NOTE: Always use safe driving practices and follow all traffic rules.

Power outlet-12V DC




The vehicle must be in the “ACCESSORY” or “IGNITION ON” mode for use.

FEATURES & OPERATIONS


Power outlets-120V AC (if equipped)

OUTLET LOCATION (100W)

Rear of the console box (if equipped)




In the trunk




OUTLET LOCATION (1500W)


Rear of the console box (if equipped)



In the trunk



POWER OUTLET ON/OFF MASTER SWITCH




Check that the “Ready” indicator is illuminated, then press the AC 120V master switch. The power outlets can be used when the indicator on the AC 120V master switch is illuminated.

To turn off the 120V outlets, press the master switch and observe that the indicator is no longer illuminated.

Refer to the “Owner’s Manual” for more details.


Audio Multimedia



Refer to the “Multimedia Owner’s Manual” or visit www.toyota.com/audio-multimedia for additional resources.

NOTE: Always use safe driving practices and follow all traffic rules.


USB Type-A media port




Connecting a compatible device and cable into the USB media port will support charging and music playback through the audio multimedia system.

USB Type-C charge ports

In the console box





Rear of the console box




The vehicle must be in the “ACCESSORY” or “IGNITION ON” mode for use.

FEATURES & OPERATIONS

Qi Wireless charger



When the vehicle is turned off, the last state (ON/OFF) of the charger is retained.



Place device nearest in the center of the charging area for best results. If the charging coil is not in the center of the device, place the device so that its charging coil is centered in the charging area.

A mobile device can be charged wirelessly on the tray. **(1)** Press the power supply switch and the green operation indicator light turns on. **(2)** Place a compatible mobile device on the tray as shown in the illustration. An amber indicator illuminates while charging is in progress. When charging is complete, the indicator illuminates green. Some phones, cases or cover type wireless chargers may not cause the green indicator to illuminate even though it is fully charged.


The vehicle must be in the "ACCESSORY" or "IGNITION ON" mode for use.

Refer to the "Owner's Manual" for limitations and more details on this system before attempting to use it.


Heated steering wheel, Heated/ventilated seats (if equipped)

FRONT AIR CONDITIONER CONTROLS


Front



Rear



REAR CONTROL PANEL (IF EQUIPPED)



The vehicle must be on for use.

Refer to the "Owner's Manual" for more details.


FEATURES & OPERATIONS

Air conditioning/heating


FRONT AUTOMATIC AIR CONDITIONING - TYPE A

Automatic mode:

Adjusting the temperature setting will cause the airflow mode, air intake and fan speed to adjust automatically to the set temperature.




FRONT AUTOMATIC AIR CONDITIONING - TYPE B




Air conditioning control screen


- (1) Touch “” on the main manu on the multimedia display.
- (2) Select “Climate” on the sub menu.
- (3) Select the disired setting.



Rear air conditioning control screen




Option control screen



FEATURES & OPERATIONS


REAR AUTOMATIC AIR CONDITIONING (IF EQUIPPED)

Rear control panel



Refer to the "Owner's Manual" for more details.

Vehicle Stability Control (VSC)/ TRAC OFF switch




The VSC OFF switch can be used to help free a stuck vehicle in surroundings like mud, dirt or snow. While the vehicle is stopped, press the switch to disable the TRAC system.

To disable both VSC and TRAC systems, press and hold the switch for at least 3 seconds while the vehicle is stopped.

Refer to the "Owner's Manual" for limitations and more details.

Rear view monitor system



The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is located above the license plate.

To adjust the image on the rear view monitor screen, press "⚙️" on the main menu on the Multimedia display and select "Display". Select "Camera" to adjust the screen contrast and brightness.


Refer to the "Multimedia Owner's Manual" for limitations and more details on this system.

FEATURES & OPERATIONS

RCD (Rear Camera Detection)

The rear camera detection (RCD) is designed to detect pedestrians in the detection area behind the vehicle when the vehicle is backing up. If a pedestrian is detected, a buzzer will sound and an icon will be displayed on the Multimedia display to inform the driver of the pedestrian.

DISPLAY ON AUDIO SYSTEM SCREEN



Pedestrian detection icon:


The icon will be displayed automatically when a pedestrian is detected.

SYSTEM ON/OFF

- (1) Press “<>” switches and select “⚙️” from the Multi-Information Display (MID).
- (2) Press “⬆️” switches and select “🚶 RCD” and then press “OK” to turn the system On/Off.
- (3) Press “⬅️” to go back to the menu.

Refer to the “Owner’s Manual” for limitations and more details on this system before attempting to use it.

Blind Spot Monitor (BSM) and Rear Cross Traffic Alert (RCTA)



BLIND SPOT MONITOR (BSM)

The system is designed to use radar sensors to detect vehicles traveling in the Mirai's blind spot. If a vehicle is detected, the driver will be alerted via the outside rear view mirror indicator on the detected side.

REAR CROSS TRAFFIC ALERT (RCTA)


While in reverse, when a vehicle approaching from the right or left rear of the Mirai is detected, the outside rear view mirror indicators will flash. Also, the RCTA icon for the detected side will be displayed on the multimedia display, and the RCTA buzzer will sound.

SYSTEM ON/OFF


- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ BSM” or “ RCTA” and then press “” to turn BSM or RCTA On/Off.
- (3) Press “” to go back to the menu.

Refer to the “Owner’s Manual” for limitations and more details on this system before attempting to use it.


Panoramic View Monitor (PVM) (if equipped)



See-through view



Moving view




The Panoramic View Monitor (PVM) is designed to assist the driver in viewing the surroundings, when operating at low speeds or parking, by combining front, side and rear cameras and displaying an overhead image on the Audio Multimedia screen.

To view the moving view/see-through view screen, press the camera switch when the shift lever is in the "P" position and the Intuitive parking assist is enabled. Press the camera switch again to display the previous display screen, such as the navigation screen.

Refer to the "Multimedia Owner's Manual" for limitations and more details on this system.

Intuitive parking assist (if equipped)

SENSOR DETECTION ON MULTIMEDIA DISPLAY



The parking assist sonar system operates when the vehicle approaches an obstacle. The distance from your vehicle to nearby obstacles when parallel parking or maneuvering into a garage is measured by sensors and communicated via the Multi-Information Display (MID) and/or the multimedia display and a buzzer.

When the sensor detects an obstacle, the direction and the approximate distance to the obstacle are displayed on the MID and/or the multimedia display by illuminating continuously (far) or blinking (near), and beeping sounds will switch from intermittent to continuous as you approach and get closer to a detected obstacle. When the sensors detect two or more obstacles, the audible alerts will respond to the nearest zone.

Always check the surrounding area when using this system.

SYSTEM ON/OFF

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ Parking Assist” and then press “” to turn the system On/Off.
- (3) Press “” to go back to the menu.

Refer to the “Owner’s Manual” for limitations and more details.


FEATURES & OPERATIONS

Front and Rear Parking Assist with Automatic Braking (PA w/AB) (if equipped)


Front and Rear Parking Assist with Automatic Braking consists of the following functions that operate when driving at a low speed or backing up, such as when parking. When the system determines that the possibility of a collision with a detected object or pedestrian is high, a warning operates to urge the driver to take evasive action. If the system determines that the possibility of a collision with a detected object is extremely high, the brakes are automatically applied to help avoid the collision or help reduce the impact of the collision.

FUNCTIONALITY


For static objects front and rear



When traveling at a low speed and the brake pedal is not depressed, or is depressed late.




When the accelerator pedal is depressed excessively.




When the vehicle moves in the unintended direction due to the wrong shift position being selected.

For static objects around the vehicle (vehicles with the Advanced Park)



When moving forward and a collision with a stationary object on the inner side of a turn is likely.



When reversing and a collision with a stationary object on the outer side of a turn is likely.


FUNCTIONALITY (CONTINUED)

For rear-crossing vehicles



When reversing, a vehicle is approaching and the brake pedal is not depressed, or is depressed late.

For rear-crossing pedestrians



When a pedestrian is detected behind the vehicle while backing up, the brake pedal is not depressed or is depressed late.

SYSTEM ON/OFF

- (1) Press “< >” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ PKSB” and then press “” to turn the system On/Off.
- (3) Press “” to go back to the menu.

Refer to the sections “Parking Support Brake function” in the “Owner’s Manual” for limitations and more details.

FEATURES & OPERATIONS

Advanced Park (if equipped)

Advanced Park is designed to assist in safely and smoothly parking in a target parking space by displaying the blind spots around the vehicle and the parking spot through a bird's eye view, delivering operation guidance through displays and buzzer operation, and changing the shift position, operating the steering wheel, accelerator pedal, and brake pedal. Advanced Park does not operate the turn signal.

Additionally, the panoramic view monitor can display the area in front, behind, and from above the vehicle, helping confirm the condition of the area around the vehicle.


Depending on the condition of the road surface or the vehicle, the distance between the vehicle and a parking space, etc., it may not be possible to assist in parking in the target space.

FUNCTIONALITY


- Perpendicular parking (forward/reverse) function
- Perpendicular exiting (forward/reverse) function
- Parallel parking function
- Parallel exiting function
- Memory function

CAMERAS


Front camera




Side cameras



Rear camera



SYSTEM ON/OFF MAIN SWITCH



CONDITIONS WHERE ASSISTANCE WILL BEGIN

When all of the following conditions are met, the assistance will begin:


- The brake pedal is depressed
- The vehicle is stopped
- The driver's seat belt is fastened
- The steering wheel is not being operated
- The accelerator pedal is not depressed
- All of the doors and the trunk are closed
- The outside rear view mirrors are not folded
- The parking brake is not engaged
- The dynamic radar cruise control with full-speed range is not operating
- ABS, VSC, TRAC, PCS and PKSB are not operating
- The vehicle is not on a steep slope
- The VSC and TRAC are not turned off

Refer to the "Owner's Manual" for limitations and more details on this system before attempting to use it.

Quick overview-Toyota Safety Sense™ 2.5+

Toyota Safety Sense™ 2.5+ (TSS 2.5+) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS 2.5+ is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the “Owner’s Manual” for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to www.toyota.com/safety-sense.



Pre-Collision System with Pedestrian Detection (PCS w/PD)

PCS w/PD is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system determines there is potential for a collision with a detected object.

The advanced grille-mounted radar system is designed to work with the forward-facing camera to help recognize a preceding vehicle, pedestrian or bicyclist in certain conditions.



Lane Tracing Assist (LTA) System

While driving on a road with clear white (yellow) lane lines, the LTA system warns the driver if the vehicle may deviate from the current lane or course, and also can slightly operate the steering wheel to help avoid deviation from the lane or course. Also, while the dynamic radar cruise control with full-speed range is operating, this system will operate the steering wheel to help maintain the vehicle's lane position.

Functions included in the LTA system are Lane Departure Alert with Steering Assist, Vehicle Sway Warning and Lane Centering.



Full-Speed Range Dynamic Radar Cruise Control (DRCC)

Full-Speed Range DRCC is designed to help maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed. The minimum set speed is approximately 20 MPH.



Automatic High Beams (AHB)

AHB is designed to detect the headlights of oncoming vehicles and the taillights of preceding vehicles and switch between high beams and low beams as appropriate.




Road Sign Assist (RSA)


RSA is designed to recognize specific road signs using the forward-facing camera to provide information to the driver via the display.

Sensors

TSS 2.5+ combines a forward-facing camera mounted in front of the inside rear view mirror and a grille-mounted radar mounted in the front grille. These sensors support the driving assist systems.



Pre-Collision System with Pedestrian Detection (PCS w/PD)



The Pre-Collision System with Pedestrian Detection (PCS w/PD) is designed to help detect a vehicle, bicyclist or pedestrian in certain situations. Using both a camera and radar, PCS w/ PD can provide an audio/visual alert to warn you of a possible collision under certain circumstances. If you don't react, the system is designed to automatically brake.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the Pre-Collision System yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle, pedestrian or bicyclist may not be detected by the radar and camera sensors, preventing the system from operating or engaging properly.

Refer to the Toyota "Owner's Manual" for a list of additional situations in which the system operation may be limited.

TOYOTA SAFETY SENSE™

PRE-COLLISION SYSTEM (CONTINUED)

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist

If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.


Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.

See www.toyota.com/safety-sense for more information

PCS PEDESTRIAN DETECTION


Under certain conditions, the PCS system included with the TSS 2.5+ package may also help to detect a pedestrian or bicyclist in front of your vehicle using the forward-facing camera and front grille-mounted radar. The forward-facing camera of PCS detects a potential pedestrian or bicyclist based on size, profile, and motion of the detected pedestrian or bicyclist. However, a pedestrian or bicyclist may not be detected depending on the conditions, including the surrounding brightness and the motion, posture, size, and angle of the potential detected pedestrian or bicyclist, preventing the system from operating or engaging.



As part of the Pre-Collision System, this function is also designed to first provide an alert and then automatic braking if needed.

Refer to the Toyota "Owner's Manual" for additional limitations and information.

CHANGING PCS WARNING TIMING



- (1) Press “<>” switches and select “⚙️” from the Multi-Information Display (MID).
- (2) Press “⬆️” switches and select “🚗 PCS” and then press and hold “OK.”
The setting screen is displayed.
- (3) Press “⬆️” switches and select “Sensitivity” and then press “OK” to change the warning timing. Each time it is pressed, the PCS warning timing changes as shown above.
- (4) Press “↶” to go back to the menu.

Note: PCS is enabled each time the vehicle is turned on. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same.)

DISABLING PRE-COLLISION SYSTEM (PCS)




- (1) Press “<>” switches and select “⚙️” from the Multi-Information Display (MID).
- (2) Press “⬆️” switches and select “🚗 PCS” and then press and hold “OK.”
The setting screen is displayed.
- (3) Press “⬆️” switches and select “🚗 PCS” and then press “OK” to turn PSC On/Off.
- (4) Press “↶” to go back to the menu.

Note: The system is enabled each time the vehicle is turned on.

Refer to the Toyota “Owner’s Manual” for additional information on PCS w/PD operation, settings adjustments, limitations, and precautions before attempting to use it.

Lane Tracing Assist (LTA) System




While driving on a road with clear white (yellow) lane lines, the LTA system warns the driver if the vehicle may deviate from the current lane or course, and also can slightly operate the steering wheel to help avoid deviation from the lane or course. Also, while the dynamic radar cruise control with full-speed range is operating, this system will operate the steering wheel to help maintain the vehicle's lane position. The LTA system recognizes white (yellow) lane lines or a course using the front camera. Additionally, it detects preceding vehicles using the front camera and radar.

Functions included in the LTA system are Lane Departure Alert with Steering Assist, Vehicle Sway Warning and Lane Centering.

Refer to the Toyota "Owner's Manual" for additional information on the LTA system operation, settings, adjustments, limitations, and precautions before attempting to use it.


TURNING THE LTA SYSTEM ON/OFF

Press the LTA switch to turn the LTA system On/Off.



Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset. The LTA indicator is illuminated when the LTA system is on.


Press the LTA switch to turn the LTA system and Lane Departure Alert On/Off.



By detecting visible white/yellow lane markings or the road's edge at speeds above 32 mph, Lane Departure Alert with Steering Assist is designed to issue a visual alert and audio or steering vibration alert if an inadvertent lane departure is detected. If the driver does not take corrective action, the Steering Assist function is designed to provide gentle corrective steering.*

* See www.toyota.com/safety-sense for more information.

LTA system display




The LTA indicator is illuminated when Lane Departure Alert is active. The LTA indicator and lane indicators flash orange when operating.

LANE DEPARTURE ALERT WITH STEERING ASSIST (CONTINUED)



(1)



(2)

The LTA system  is displayed when the Multi-Information Display (MID) is switched to the driving support system information display.

- (1) The system displays solid white lines on the Lane Departure Alert indicator when visible lane markers or the road edge are detected. A lane indicator flashes orange to alert the driver when the vehicle deviates from its lane.
- (2) The system displays outlines on the Lane Departure Alert indicator when lane markers or the road edge are not detected or the function is temporarily canceled.

Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, Lane Departure Alert may not function on the side(s) where white/yellow lines are not detectable.

ADJUSTING LANE DEPARTURE ALERT SENSITIVITY

The driver can adjust the sensitivity of the Lane Departure Alert function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.


Standard - Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ LTA” and then press and hold “.
- The setting screen is displayed.
- (3) Press “” switches and select “Sensitivity” and then press “.
- (4) Press “” to go back to the menu.

SWAY WARNING SYSTEM



Continuous lane deviations from swaying.



Gentle swaying from driver's inattentiveness.



Acute steering wheel operation after the number of operations decrease due to driver's inattentiveness.

Sway warning is a function of the LTA system and is designed to detect swaying based on the vehicle location in the lane and the driver's steering wheel operation. To help prevent swaying, the system alerts the driver using a buzzer sound and a warning display on the MID.

DISABLING SWAY WARNING ALERT

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ LTA” and then press and hold “.
- The setting screen is displayed.
- (3) Press “” switches and select “Sway Warning” and then press “.
- change the desired setting.
- (4) Press “” to go back to the menu.

Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.

ADJUSTING SWAY ALERT SENSITIVITY

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ LTA” and then press and hold “.
- The setting screen is displayed.
- (3) Press “” switches and select “Sway Sensitivity” and then press “.
- change the desired setting.
- (4) Press “” to go back to the menu.


Refer to the Toyota “Owner’s Manual” for additional information on the LTA system operation, settings adjustments, limitations, and precautions before attempting to use it.

TOYOTA SAFETY SENSE™


LANE CENTERING

Lane Centering is a function of the LTA system. Turning the LTA system off will deactivate Lane Centering.

Press the LTA switch to deactivate the LTA system and Lane Centering.



LTA system display



The lane centering function is linked with Full-Speed Range Dynamic Radar Cruise Control (DRCC) and provides the required assistance by operating the steering wheel to help keep the vehicle in its current lane.

When Full-Speed Range Dynamic Radar Cruise Control (DRCC) is not operating, the lane centering function does not operate.

See www.toyota.com/safety-sense for more information.



DISABLING LANE CENTERING FUNCTION

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ LTA” and then press and hold “.

The setting screen is displayed.

- (3) Press “” switches and select “Lane Center” and then press “.

the desired setting.

- (4) Press “.

Note: Operation of the LTA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.


Refer to the Toyota “Owner’s Manual” for additional information on the LTA system operation, settings adjustments, limitations, and precautions before attempting to use it.

Full-Speed Range Dynamic Radar Cruise Control (DRCC)


Intended for highway use, Full-Speed Range Dynamic Radar Cruise Control (DRCC) lets you drive at a preset speed. The system is designed to function between 0-110 mph* and uses vehicle-to-vehicle distance control, helping maintain a preset distance from the vehicle ahead of you.*

* See www.toyota.com/safety-sense for more information.

Refer to the Toyota “Owner’s Manual” for a list of additional situations in which the system operation may be limited.




ACTIVATING DRCC



Refer to page 58 for switching to Constant Speed (Cruise) Control Mode.


ADJUSTING SET VEHICLE SPEED



The vehicle will cruise at a set speed, decelerate to maintain a selected distance from a slower preceding vehicle and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.


- (1) Press the “” to turn DRCC system ON. The “Radar Ready” and “” indicator will come on.
- (2) Use the steering wheel controls to increase speed by pressing “+RES” or decrease the speed by pressing “-SET”. Press and hold to make a large adjustment or press each time to make fine adjustments (1 mph [1.6 km/h] or 1 km/h [0.6 mph] increments).
- (3) Press “Cancel” to cancel the speed control.

* The speed control may also be canceled by depressing the brake pedal.



This mode employs a radar sensor to detect the presence of a preceding vehicle up to approximately 328 ft (100 m) ahead, determines the current vehicle-to-vehicle following distance and operates to maintain a preset following distance from the vehicle ahead. These distances vary based on the vehicle speed.

Note: Vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Constant speed cruising when there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control switch.

(2) Deceleration cruising and follow-up cruising when a preceding vehicle driving slower than the set speed appears

When a slower vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system may apply the brakes (the brake lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.


ADJUSTING DISTANCE (CONTINUED)

(3) Acceleration when there are no longer any preceding vehicles driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Note: When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.


SWITCHING TO CONSTANT SPEED (CRUISE) CONTROL MODE



Press and hold the cruise control main switch “” for at least 1.5 seconds to turn on constant speed cruise control. If you are already using DRCC, press the cruise control main switch “” to turn DRCC off before activating constant speed cruise control.

Note: When the vehicle is turned off, it will automatically default to DRCC.


SETTING CONSTANT SPEED (CRUISE) CONTROL



To adjust speed or cancel, see steps (2) and (3) of ADJUSTING SET VEHICLE SPEED on page 56.

Refer to the Toyota “Owner’s Manual” for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)



The Automatic High Beams (AHB) safety system is designed to help the driver see more clearly at night. At speeds above 21 mph, AHB can detect the headlights of oncoming vehicles and taillights of preceding vehicles, then automatically toggles between high and low beams accordingly.

See www.toyota.com/safety-sense for more information.

Refer to the Toyota “Owner’s Manual” for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

ACTIVATING THE AHB SYSTEM

- (1) Press the “” switch.
- (2) Turn the headlight switch to the “” or “AUTO” position.

The AHB indicator “” will come on when the headlights are on and the headlight switch lever is in the low beam position to indicate the system is active.

Note: Push the lever away from you to manually turn on high beams. Press the AHB switch to turn the AHB system off.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY


When all of the following conditions are met, the high beams will be automatically turned on (after approximately 1 second):

- Vehicle speed is approximately 21 mph (34 km/h) or more.
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or taillights turned on.
- There are few streetlights on the road ahead.

If any of the following conditions occur, the high beams will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or taillights turned on.
- There are many streetlights on the road ahead.

TEMPORARILY SWITCHING TO THE LOW BEAMS



Pull the lever toward you and then return it to its original position to switch to the low beams temporarily.

The high beams are on while the lever is pulled toward you, however, after the lever is returned to its original position, the low beams remain on for a certain amount of time. Afterwards, the Automatic High Beams will be activated again.

NOTE: It is recommended to switch to the low beams when the high beams may cause problems or distress to other drivers or pedestrians nearby.

Refer to the Toyota "Owner's Manual" for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.


Road Sign Assist (RSA)

Using the forward-facing camera and navigation system (if equipped), Road Sign Assist (RSA) is designed to detect certain road signs and display them on the instrument cluster.


All vehicle actions must be driver-initiated and are not automated.

Refer to the Toyota "Owner's Manual" for additional information and limitations.

RSA DISPLAY



When the driving support system information display is selected, a maximum of 3 signs can be displayed.



When a tab other than the driving support system information is selected, the following types of road signs will be displayed.

- Speed limit sign
- Do Not Enter sign (when notification is necessary)

SUPPORTED TYPES OF ROAD SIGNS



Speed limit



Stop



Do Not Enter



Yield

SYSTEM ON/OFF

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ RSA” and then press “” to turn RSA On/Off.
- (3) Press “” to go back to the menu.

Note: If the vehicle was last turned off while a speed limit sign was displayed on the Multi-Information Display (MID), the same sign displays again when the vehicle is turned back ON.


ADDITIONAL RSA SETTINGS

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “ RSA” and then press and hold “.
- The setting screen is displayed.
- (3) Press “” switches to select an RSA setting from the menu, and press “.
- to select or change a desired setting.
- (4) Press “” to go back to the menu.

Refer to the Toyota “Owner’s Manual” for additional information on RSA operation, settings adjustments, limitations, and precautions before attempting to use it.

SAFETY & EMERGENCY FEATURES

Safety Connect®



Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is staffed with live agents at the Toyota response center, which operates 24 hours per day, 7 days per week.


Services for subscribers include:

- Automatic collision notification
- Stolen vehicle locator
- Emergency assistance ("SOS" button)
- Enhanced roadside assistance

For limitations and additional information, refer to the "Owner's Manual" or visit www.toyota.com/connected-services.


Rear door child safety locks

Rear door



Moving the lever downward will allow the door to be opened only from the outside.


Seat belts




NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic locking retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the "Owner's Manual".

Seat belts-Shoulder belt anchor



Trunk-Internal release




SAFETY & EMERGENCY FEATURES

Emergency tire puncture repair kit


Your vehicle is not equipped with a spare tire, but instead is equipped with an emergency tire puncture repair kit (a bottle of sealant and compressor). After temporarily repairing the tire with the repair kit, have the tire repaired or replaced by your Toyota dealer.

TOOL LOCATION

Type A




Type B




TIRE REPAIR KIT COMPONENTS

Bottle




Compressor



Refer to the “Owner’s Manual” for tire changing procedures.

Tire Pressure Monitoring (warning) System (TPMS)



The tire pressure detected by the tire pressure warning system can be displayed on the Multi-Information Display (MID).

The tire pressure warning system can be selected on “” of the Multi-Information Display (MID).

System reset initialization

- (1) Press “<>” switches and select “” from the Multi-Information Display (MID).
- (2) Press “” switches and select “Vehicle Settings” then press and hold “.
- (3) Press “” switches and select “TPWS” and then press “.
- (4) Press “” switches and select “Set Pressure,” then press and hold “” until the tire pressure warning light starts blinking.

If the tire pressure indicator flashes for approximately 1 minute and then remains on, take the vehicle to your local Toyota dealer.

Refer to the load label on the door jamb or the “Owner’s Manual” for tire inflation specifications.

NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.

SAFETY & EMERGENCY FEATURES

Star Safety System™

Your vehicle comes standard with the Star Safety System™, which combines Anti-lock Braking System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Traction Control (TRAC) and Vehicle Stability Control (VSC).

Refer to the “Owner’s Manual” for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota’s Anti-lock Brake System detects which wheels are locking up and limits wheel lockup by “pulsing” each wheel’s brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or “panic” braking, and then add braking pressure to help decrease the vehicle’s stopping distance. When there’s only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota’s ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces motor power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn’t engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

ENHANCED VEHICLE STABILITY CONTROL (VSC)

Enhanced Vehicle Stability Control provides cooperative control of the ABS, TRAC, VSC and EPS.

Enhanced VSC helps to maintain directional stability when loss of traction occurs during a turn.

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing Motor power output, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).


Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits Motor power output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Floor mat installation



There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Only use one floor mat at a time, using the equipped fasteners to keep the mat in place.
- Install floor mats right side up.



Always align the Δ marks



GETTING STARTED WITH TOYOTA AUDIO MULTIMEDIA AND CONNECTED SERVICES

- Registering Your Vehicle
- Toyota app
- Bluetooth® Pairing
- Connected Services
- Apple CarPlay®
- Android Auto™
- SiriusXM®
- Online Support Tool
- Updating System Software

Scan QR Code to Download Toyota app

Apple




Android




Do not attempt the process while driving.

Registering Your Vehicle


With the Toyota app, you will be connected to your Toyota on the go. Use the app to personalize your profile and take the customized vehicle settings and preferences for the multimedia features you enjoy most with you too. Get real time vehicle health information, enjoy remote service, manage your Connected Services subscriptions and more.



STEP 1 Start the vehicle and select your language preference.




STEP 2 Select “Enter phone number”.




STEP 3 Enter your mobile phone number to receive a link to download the Toyota app.

STEP 4 Download and open the Toyota app on your device and follow instructions to add your vehicle by scanning the QR Code displayed on your vehicle’s screen. Complete the steps in your Toyota app to create your profile, activate included trial services and enable access in your vehicle.



STEP 5 Once complete, select “I’ve completed app setup”.



STEP 6 A welcome banner will be displayed on screen to confirm linking is complete.

GETTING STARTED WITH

Toyota app



TOYOTA

Toyota app allows access to valuable information about your vehicle and control of capable features equipped with your vehicle.

- Manuals & Warranties
- Schedule Maintenance
- Roadside Assistance
- Vehicle Health Report
- SiriusXM® Radio
- Safety Recalls
- Toyota Financial Services - Vehicle Payment

Remote Connect equipped vehicle functions:

- Lock/Unlock
- Start Vehicle
- Vehicle Finder
- Guest Driver settings
- Hazard Lights On
- Remote Climate
- Vehicle Status Alerts

Scan QR Code to Download Toyota app.

Apple



Android



Or

Search "Toyota" at your applicable app store.




If you have a Toyota Owner's account, use your credentials to "Sign In" and get started with Toyota app.

Or

If you do not have a Toyota Owner's account, "Register" now to get started with Toyota app.




Bluetooth® Pairing¹



Note:
Do not attempt the Bluetooth® Pairing process while driving.


STEP 1 Select [GEAR ICON] from the main menu, then “Bluetooth & Devices.”




iPhone Bluetooth Menu

Android Bluetooth Menu


STEP 2 Ensure Bluetooth is turned on for your phone.



STEP 3 Select “Manage devices”, then “Search for devices.”




STEP 4 Select “Device name” to register.




STEP 5 Check that the displayed PIN code matches the PIN code displayed on the Bluetooth® device, and then select [OK].

Bluetooth® Pairing¹ (continued)




STEP 6 If your device supports Apple CarPlay / Android Auto, select **“Yes”** to enable.



STEP 7 While pairing your device, a message may display asking to check your device to allow syncing contacts and allow messaging.


Note: You may also select **“Skip”** on display screen to skip enabling notifications. If skipped, proceed to **STEP 9**.



iPhone

Android

STEP 8 Turn on **“Show Notifications”** for iPhone® or **“ON”** for Android.



STEP 9 A confirmation will appear once your phone has been paired and connected.

Connected Services²

Your vehicle may come available with a trial period for the following Connected Services.

Learn more at www.toyota.com/connected-services/.

Safety Connect³

- (SOS) EMERGENCY ASSISTANCE BUTTON
- AUTOMATIC COLLISION NOTIFICATION
- ROADSIDE ASSISTANCE
- STOLEN VEHICLE LOCATOR
- COLLISION ASSISTANCE

Remote Connect⁴ (if equipped)

- START VEHICLE
- VEHICLE STATUS ALERTS
- HAZARD LIGHTS ON
- GUEST DRIVER SETTINGS
- LOCK/UNLOCK VEHICLE DOORS
- VEHICLE FINDER
- REMOTE CLIMATE

Completing the registration process is required to enable Remote Connect.

Service Connect⁵ (if equipped)

- VEHICLE HEALTH REPORT
- VEHICLE MAINTENANCE ALERT NOTIFICATION

Completing the registration process is required to enable Service Connect.

Drive Connect

- CLOUD NAVIGATION
- DESTINATION ASSIST
- INTELLIGENT ASSISTANT

GETTING STARTED WITH

Connected Services² (continued)


Wi-Fi Connect⁷

Multiple mobile devices

- Connect up to 5 Wi-Fi enabled devices
- Passengers can use smartphones, laptops and tablets

Infotainment

- Browse the internet
- Send and receive email
- Stay connected on social media
- Access favorite apps
- Stream movies




Several factors may affect smartphone and/or system performance including:

1. Smartphone operating system software version
2. Smartphone battery power level
3. Poor cellular reception to the smartphone
4. Multiple applications running on a smartphone at the same time
5. Charge/media cable quality
6. Smartphone operating system updates may also affect Toyota app functionality

For additional information, please visit: www.toyota.com/connected-services

Connected Services Online Support



Toyota's online support tool provides intuitive "How-To" instruction and videos.

To begin, please visit: <https://toyotaaudioandconnectedservicesupport.com/>

Apple CarPlay® (Compatible iPhone® required)

Setup of Apple CarPlay®



STEP 1 Ensure Siri® is enabled on your phone.




STEP 2 Plug a compatible iPhone® into the USB media port using an Apple® approved cable or have the smartphone and vehicle connected through Bluetooth®.



STEP 3 On the multimedia system, select “Yes” when asked if you would like to Enable Apple CarPlay®.



STEP 4 Select Allow to use CarPlay® while the phone is locked.



* Screen depiction accurate at time of posting.

STEP 5 To launch Apple CarPlay®, select the Apple CarPlay® icon on the top of the side menu bar.



* Screen depiction accurate at time of posting.

STEP 6 Apple CarPlay® is now ready to operate. You can go back to the Toyota multimedia system by using the Toyota icon in the Apple CarPlay® screen.

Requirements:

Bluetooth® functions will be inoperable while CarPlay® is in use. Wireless CarPlay® is supported. Features may vary by vehicle model and phone.


To learn more about how your iPhone® works with CarPlay® visit: <https://support.apple.com/en-us/HT205634>

To view a full list of CarPlay® supported apps visit: <https://www.apple.com/ios/carplay/>

GETTING STARTED WITH

Apple CarPlay® (Compatible iPhone® required) (continued)

Siri® through CarPlay®



Press and hold the voice command talk switch for 2-3 seconds to activate.



* Screen depiction accurate at time of posting.

Once Siri® is activated you can ask to: make calls, send and receive text messages, listen to music and more.

Android Auto™ (Compatible Android™ device required)

Setup of Android Auto™



STEP 1 With Android 9 or below, the Android Auto™ app download is required. With Android 10, Android Auto™ is built in and the app is NOT required.



STEP 2 Open Android Auto™ app and tap get started.




STEP 3 Ensure Android Auto™ is enabled on the phone.



STEP 4 Plug a compatible Android™ smartphone into the USB media port using an Android approved cable or have the smartphone and vehicle connected through Bluetooth®.

Setup of Android Auto™ (continued)

STEP 5 On the multimedia system, select “Yes” when asked if you would like to Enable Android Auto™.



STEP 6 To launch Android Auto™, select the Android Auto™ icon on the top of the side menu bar.



* Screen depiction accurate at time of posting.


STEP 7 Android Auto™ is now ready to operate. You can go back to the Toyota multimedia system by using the Toyota icon in the Android Auto™ screen.

Requirements:

Bluetooth® functions will be inoperable while Android Auto™ is in use. Wireless Android Auto™ is supported. Features may vary by vehicle model and phone.

To learn more about how to use Android Auto™ visit: <https://www.android.com/auto>

Google Assistant through Android Auto™



Press and hold the voice command talk switch for 2-3 seconds to activate.




* Screen depiction accurate at time of posting.

Once Google Assistant is activated, you can ask to: make calls, send and receive text messages, listen to music and more.

GETTING STARTED WITH

SiriusXM® 8 (If equipped)

SiriusXM® Audio




* Screen depiction accurate at time of posting.

Toyota vehicles equipped with SiriusXM® come with a 3-month Platinum Plan trial subscription. With the Platinum Plan, you get 350+ channels, including 165+ channels in your vehicle to enjoy ad-free music, plus sports, news, talk, comedy and more. Experience even more on the SXM App, featuring a collection of podcasts, Xtra channels of music, personalized Pandora® stations, SiriusXM video and more.



Audio Multimedia Online Support



Toyota's online support tool provides intuitive "How-To" instruction and videos.

To begin, please visit: <https://toyotaaudioandconnectedservicesupport.com/>

Updating System Software

The Toyota Audio Multimedia system is capable of over-the-air, over Wi-Fi®, and through USB flash drive updates. To use this function it is necessary to opt-in to the Connected Service Master Data Consent. When the Toyota Audio Multimedia system software is updated, the operating methods of functions may change. Each update will identify the proper updating method to one or all of the following methods:

- Update the software using the Data Communication Module (DCM)
- Update the software using Wi-Fi
- Update the software using a USB flash drive

See the Owner's Manual for complete details on the updating procedure.

After updating make sure to read the Digital Navigation Owner's Manual corresponding to the current software version available at <https://www.toyota.com/owners/resources/warranty-owners-manuals>.

Privacy & Protection

To learn about Toyota's Connected Services data collection, use, sharing and retention, visit: www.toyota.com/privacyvts.

- ¹ The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage and carrier.
- ² Visit Toyota.com/connected-services or see your local Toyota Dealer for additional details.
- ³ Safety Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, all of which can limit system functionality or availability, including access to response center and emergency support. Stolen vehicle police report required to use Stolen Vehicle Locator. Some features may require the Toyota app. Registration required. Subscription required after trial. Service subject to change at any time without notice. Terms of Use apply. Data charges may apply. Service may vary by vehicle and region. See usage precautions and service limitations in Owner's Manual and Toyota.com/connected-services/ for additional details.
To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁴ Toyota - Remote Connect
Use only if aware of circumstances surrounding vehicle and it is legal and safe to do so (e.g., do not remotely start engine if vehicle is in an enclosed space or vehicle is occupied by a child). Toyota Remote Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, which can limit system functionality and availability. Service may vary by vehicle and region. Registration and Toyota app download required. Subscription required after trial. Terms of Use apply. Data charges may apply. Remote start/stop not available on manual transmission-equipped vehicles. Services subject to change at any time without notice. See usage precautions and service limitations in Toyota Owner's Manual and <https://www.toyota.com/connected-services> for additional details.
To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁵ Service Connect information provided is based on the last time data was collected from the vehicle and is not real time data. Service Connect depends on an operative telematics device, a cellular connection, GPS signal strength and other factors outside of Toyota's control, which can limit functionality or availability. Service may vary by vehicle and region. Registration required. Subscription required after trial. Service subject to change at any time without notice. Terms of Use apply. Data charges may apply. See usage precautions and service limitations in Owner's Manual and Toyota.com/connected-services for additional details.
To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁶ Destination Assist depends on an operative telematics device, a cellular connection, navigation map data and GPS signal strength and other factors outside of Toyota's control, which can limit system ability functionality or availability. Use common sense when relying on this information. Service may vary by vehicle and region. Registration required. Subscription required after trial. Services subject to change at any time without notice. Terms of Use apply. Data charges may apply. See Owner's Manual and Toyota.com/connected-services for additional limitations and details.
To learn about Toyota's data collection, use, sharing and retention practices, please visit <https://www.toyota.com/privacyvts/>.
- ⁷ Wi-Fi Connect is available on select 2018 and newer Toyota vehicles.
Visit Toyota.com/connectedservices for vehicle availability.
- ⁸ SiriusXM® audio services require a subscription sold separately by Sirius XM Radio Inc. To cancel, you must call SiriusXM at 1-866-635-2349. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com.
All fees and programming subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM.
SiriusXM and all related marks and logos are trademarks of Sirius XM Radio Inc.

NOTES



MIRAI

Quick Reference Guide 2023



00505QRG23MIR



Printed in U.S.A. 11/22
21-MKG-16281

toyota.com