

Introduction

Thank you for your purchase of the Navigation System. Please read this manual carefully to ensure proper use. Keep this manual stored in your vehicle at all times.

The Lexus Navigation System is one of the most technologically advanced vehicle accessories ever developed. The system receives satellite signals from the Global Positioning System (GPS) operated by the U. S. Department of Defense. Using these signals and other vehicle sensors, the system can show you where you are and assist you in locating a desired destination.

The navigation system is designed to select efficient routes from your present starting location to your destination. The system is designed to direct you to a destination that is unfamiliar to you in efficient manners. The routes are generated from a large database that includes all roads contained in AAA state maps along with detailed street coverage for many major metropolitan areas. The calculated routes are neither the shortest routes nor routes without traffic congestion. Your own personal local knowledge or "short cut" may at times be faster than the calculated routes.

The navigation system's database includes 53 point of interest categories to allow you to easily select destinations such as restaurants and banks. If a destination is not in the database, you can enter the street address or a major intersection close to it and the system will route you there. The system will provide both a visual map and audio instructions. The audio instructions will announce the distance and direction to go when you are approaching a fork or intersection. These voice instructions will help you keep your eyes on the road and are timed to provide enough time to allow you to maneuver, change lanes or slow down.

Please be aware that all current vehicle navigation systems have certain limitations that may affect their ability to perform properly. The accuracy of the vehicle's position depends on the satellite condition, road configuration, vehicle condition or other circumstances. For more information on the limitations of the system, refer to pages 39 through 41.

TOYOTA MOTOR CORPORATION

Introduction

For safety reasons, this manual indicates items requiring particular attention with the following marks.

 CAUTION
This is a warning against something that may cause injury to people if the warning is ignored. You are informed what you must or must not do in order to avoid or reduce the risk to yourself and other people.

NOTICE
<i>This is a warning against something which may cause damage to the vehicle or its equipment if the warning is ignored. You are informed what you must or must not do in order to avoid or reduce the risk of damage to your Lexus and its equipment.</i>

INFORMATION
<i>This provides additional information.</i>


Initial screen



When you start the engine or turn the ignition key to "ACC", the initial "LEXUS" screen appears and the system begins operating.

 CAUTION
When the vehicle is stopped with the engine running, always apply the parking brake for safety.

After a few seconds, the "CAUTION" screen appears.



Please read it and follow the instructions.

If a screen other than for the navigation system is displayed (i.e., for the audio system or air conditioning), the current screen would change to the "CAUTION" screen by pushing the "MAP/VOICE", "DESTINATION" or "MENU" button on the bezel or by touching the "Maintenance" switch on the information menu screen.

When you touch the "I agree" switch on the screen, the "map" screen appears.

Safety Introduction



To use your system as safely as possible, follow all the safety tips shown below.

This system is intended to assist you in reaching your destination and, if used properly, can do so. You, as the driver, are solely responsible for the safe operation of your vehicle and the safety of your passengers.

Do not use any feature of this system to the extent it distracts you from safe driving. Your first priority while you are driving should always be the safe operation of your vehicle. While you are driving, be sure to observe all traffic regulations.

Before attempting to use this system while you are driving, learn how to use it and become thoroughly familiar with it. Read the entire Navigation System Manual to make sure you understand the system. Do not allow others to use this system until they have read and understood these and other instructions in this manual.

For your safety, some functions may become inoperable when you start driving. Unavailable switches are dimmed. You can input your destination and select your route only when the vehicle is not moving.

 **CAUTION**

- **For safety, the driver should not operate the navigation system while he/she is driving. Inattention to the road and traffic may cause an accident.**
- **While you are driving, be sure to follow the traffic regulations and keep the road condition in mind. If a traffic sign on the road has been changed, route guidance may provide wrong information such as the direction of a one way street.**

While you are driving, listen to the voice instructions as much as possible and glance at the screen briefly and only when it is safe. However, do not totally rely on voice guidance. Use it just for your information. If the system cannot determine your current position correctly, there is a possibility of incorrect, late or non-voice guidance.

The data in the system may occasionally be incomplete. Road conditions, including driving restrictions (no left turns, street closures, etc.) frequently change. Therefore, before you follow any instruction from the system, look to see whether you can comply with the instruction safely and legally.

This system cannot warn you about such things as the quality of a neighborhood, condition of streets, and availability of emergency services. If you are unsure about the safety of an area, don't drive into it. **Under no circumstances is this system a substitute for the driver's personal judgement.**

Safety Introduction

We recommend that you obtain updated map data, when it becomes available, in order to help use the system as effectively and safely as possible.

Use this system only in locations where it is legal to do so. Some states/provinces may have laws prohibiting video screens within sight of the driver.

Overview of Touch Screen and Switches

Switch operation

This system operates mainly by the switches on the screen. To protect the screen, lightly touch switches on the screen with your finger. When you touch a switch on the screen or push the button, a beep sounds.

INFORMATION

- *If the system does not respond to a touch of a switch, move your finger away from the screen and then touch it again.*
- *You cannot operate dimmed switches.*
- *Wipe off fingerprints on the surface of the display using a glass cleaning cloth.*



Speech command system



Some descriptions in this manual are marked with the above indicator. This means that this function can be activated using the speech command system.

For the operation of the speech command system and the command list, see page 71.

Symbols and Switches

Symbols and Switches

North-up symbol and scale of map

To indicate a map view with North up. Touching this symbol changes the map view to a heading-up respective. The figure also indicates the map scale. For details, see page 38.

GPS mark (Global Positioning System)


Whenever your vehicle is receiving signals from the GPS, this mark is displayed. For details, see page 39.

Map/Guide

Push this switch to change the screen mode. For details, see page 23.

Current vehicle position mark

To indicate the current position. For details, see page 25.



MAP/VOICE button

Push this button to repeat a Guidance voice, cancel the one touch scroll and start a Guidance. For details, see page 26.

DESTINATION button

Push this button to display the Destination screen. For details, see page 4.

MENU button

Push this button to display the menu screen. This screen allows you to make adjustments or correct settings of various options and functions.

OPTION button

Push this button to display the option screen. For details, see page 66.

zoom IN/zoom OUT

These switches magnify or reduce the map scale. For details, see page 37.

Symbols and Switches



Changing the route guidance

When you touch this switch, the Change Route screen will appear. For details, see page 24.



One – touch registration of marked point

To register the current vehicle position as a marked point. For details, see page 54.



Display of point of interest

Symbols such as restaurants and hotels, etc. can be displayed on the screen. For details, see page 33.



Deletion of point of interest

Symbols such as restaurants and hotels, etc. displayed on the screen can be deleted. For details, see page 33.



Heading-up symbol and scale of map

On the map, the vehicle travel direction is up. The red arrow indicates North. Touching this symbol directly on the screen changes the map to North-up. For details, see page 38.





SECTION I

BASIC FUNCTIONS

Descriptions of basic operations in frequent use

Inputting letters and numbers	2
How to move the cursor	3
Destination inputExplains 10 ways to input your destination	4
<i>Explains 10 ways to input your destination</i>	
Entering destination	22
Route guidance screen	23
Current position display	25
Voice guidance	26
Typical voice guidance prompts	27
Registration of your home	30
Detour setting	31
Displaying points of interest	33
Turn list	34
Guidance screen	36
Map scale	37
Screen scrolling	38
Orientation of the map	38
Limitations of the navigation system	39
Map database information and updates	42

Inputting Letters and Numbers

The navigation system operates by switches on the screen and on the bezel. When you touch a switch, a beep sounds. When using the switches on the touch screen, please use only light pressure with your finger to protect the screen from damage. Do not use objects other than your finger to touch the screen.



To type in an address etc., directly touch alphabet keys on the screen. If you touch a wrong letter, delete it using the  switch. Touching the  switch erases one letter.

Touching the "List" switch will change the screen to a display of the database items that match the name or address that you have entered on the screen. The number of matching items is shown to the right side of the screen. If the matching item is more than 9,999, the system displays "****" on the screen.

To input numerals, touch the "0-9" switch and the display will change the screen to number input display.



Touching the "A-Z" switch changes the screen back to the previous name input display.



When a list is displayed, you can scroll or page through the list by using the appropriate switch.


 To shift to the next or previous page.


 To scroll up or down one item at a time.



 This expresses a displayed screen position.

Inputting Letters and Numbers How to Move the Cursor

- ▶ If a ▶ or a ◀ appears to the right or left of the item name, the complete name is too long for the display. Touch the name, and the name will scroll to the end or beginning of the name.
- ◀



1. Touch the "Scroll" switch to move the cursor .



▶ *Position locating screen on the map*

2. When you touch an arrow facing your desired point, the map scrolls in that direction. When you release your finger, scrolling stops.

3. If you touch the "Enter" switch, the position of cursor  is set.

I

Destination Input

Push the **"DESTINATION"** button on the bezel and the "Destination" screen appears.



The destination screen allows you to select the region of the country to be searched for your destination.

Touch the "Change" switch on the destination screen to display a map of the United States divided into 10 regions.



Touch an area directly to select the search area and the destination screen returns.

Once you choose the region of the country to search, you can use one of 10 different methods to enter your destination.

Address: You can enter the house number, the street address and selected city of your destination. You can find your destination using various methods. See page 6 through 8 for the detailed steps.

1. By Address: You can input the house number and the street address by using the input keys. See page 6 for the detailed steps.

2. By Point of Interest: You can select one of the many points of interest that have been already stored in the system's database. There are 53 categories to choose from including restaurants, banks and automotive places. See page 9 for the detailed steps.

3. By Marked Point: You can register your own favorite destinations as a "Marked Point". The system allows you to store up 100 marked points. See page 15 for the detailed steps.

4. By Previous Destination: You can select a destination from any of the last 10 previously set destinations. See page 16 for the detailed steps.

Destination Input

5. By Home: You can select your own home without entering the address each time. In this case, it is necessary to register your home beforehand. See page 16 for the detailed steps.

6. By Emergency: You can select one of the three points of emergency service points that have been already stored in the system's database. See page 17 for the detailed steps.

7. By Intersection: You can enter the names of two intersecting streets. This is helpful if you do not know the specific street address of your destination but know the general vicinity. See page 18 for the detailed steps.

8. By Freeway Entrance/Exit: You can enter the name of the freeway (interstate) entrance or exit. See page 19 for the detailed steps.

9. By Previous Starting Point: You can enter a point where the system has started to guide last time. See page 21 for the detailed steps.

10. By Map Selection: You can select a destination simply by touching the location on the displayed map. See page 22 for the detailed steps.

INFORMATION


- *When inputting the destination, the response to the switch may be slow.*
- *"Point of Interest" are mainly registered in "Detailed map coverage areas". The registration is made based on the NavTech "Standard POI Inclusion List".*
- *If there is no point registered, switches such as "Marked Point", "Home", "Previous Destination" or "Previous Starting Point" are dimmed and not available.*
- *The route for returning may not be the same as that for going.*
- *The route guidance to the destination may not be the shortest route or a route without traffic congestion.*
- *Route guidance may not be available if there is no road data for the specified location.*

- *When setting the destination, you should use the map on a scale of one half mile or smaller.*
- *To select an "Address", "Point of Interest", "Freeway Entrance/Exit" or "Intersection" in a different region, a search area's change is necessary.*

CAUTION

While you are driving, be sure to follow traffic regulations and keep the road condition in mind. If a traffic sign on the road has been changed, the route guidance may provide wrong information.

Destination Input by ADDRESS




There are 2 ways to input a destination by address.

(a) Inputting a house number and a street name


Touch the "Address" switch on the destination screen. The "Address" screen appears, and then you can input a house number.

Touch letters directly on the screen to input a house number.



After inputting a house number, touch the "Enter" switch to display the screen which you can input a street name.

It is possible to input a street name first. Touch the "Street" switch to display the screen which you can input a street name.



After each letter is inputted, the system searches the database for street names that match. Alphabet keys are dimmed if the database does not have a match for the next letter in the remaining list of matching street names.

When you input numerals, touch the "0-9" switch to display the screen for numeral input.

Based on your input, the number of matching sites appears at the top right of the screen. After the number decreases to some extent, touch the "List" switch to display the street selection list. If the number of matches decreases to 4 or less, the screen changes automatically to the selection list.

Destination Input by ADDRESS



When you find your desired street name, touch of the item. The screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)

If the same address exists in more than one city, the current screen changes to the "City Select" screen. Select or enter your desired city.




If you input a street name first, the screen changes. You can then input the house number.



If the above screen appears, you can select an address range on that screen.

(b) Inputting a city name

The screen for inputting a city name appears if you touch the "City" switch on the "Address" screen on page 6.




Input a city name using alphabet keys.

After the number decreases to some extent, touch the "List" switch to display the city selection list. If the number of matches decreases to 4 or less, the screen changes automatically to the selection list.



Destination Input by ADDRESS



Touch the of the desired city name. The current screen changes to the screen which is for inputting a house number. Input a house number and a street name. The screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)

Map: If you touch this switch, the screen changes and displays the map location of the selected city and the route preference. (See "Entering Destination" on page 22.)

Destination Input by POINT OF INTEREST

There are 3 ways to select a point of interest location.

(a) Input the name of the point of interest directly.


(b) Inputting a city name first.

(c) Selecting from the points of interest categories.

It will not take a long time for you to find your destination if you use a combination of the searching ways of (a), (b) and (c).

(a) Input the name of the point of interest directly


Touch the "Point of Interest" switch on the destination screen.



The "Point of Interest" screen appears, and then you can input the name of the point of interest.

Touch letters directly on the screen to input a name. When you input numerals, touch the "0-9" switch to display the screen for numeral input.

If the number of sites becomes 4 or less, or if you touch the "List" switch at the bottom right of the screen, the screen changes and displays a list of sites.



Touch the of your desired destination. The screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)


If the same name exists in more than one city, you can search it more easily with the "City" and "Category" switch. (See (b) Inputting a city name and (c) Selection from the Points of Interest categories.)



Destination Input by POINT OF INTEREST

(b) Inputting a city name

Touch the "City" switch on the point of interest screen.




Touch alphabet keys directly on the screen to input a city name. When you input numerals, touch the "0-9" switch to display the screen for numeral input.

If the number of sites becomes 4 or less, or if you touch the "List" switch at the bottom right of the screen, the screen changes and displays the selection list. Touch the of the desired city name.

After entering the city name, input the name of the point of interest.

(c) Selection from the Points of Interest categories

Touch the "Category" switch on the point of interest screen.




The categories are shown on the screen. When you touch the of your desired category, more detailed categories are shown.




When you touch the of your desired category, the screen changes and displays the menu to input a name.

Destination Input by POINT OF INTEREST



Once you have selected a category, touch letters directly on the screen to input a name. When you input numerals, touch the "0-9" switch to display the screen for numeral input.

If the number of sites becomes 4 or less, or if you touch the "List" switch at the bottom right of the screen, the screen changes and displays a list of sites.




If you do not know the name of the specific point of interest, for example, when you are trying to find the nearest restaurant, touch the "Dist Sort" switch at the bottom of the screen. A listing of all the items in the category is displayed based on the distance from your current location.



When you touch the of your desired item, the screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)



Destination Input by POINT OF INTEREST



Touch the "Info" switch to display the selected destination name, address and telephone number.

INFORMATION

The desired point of interest can be displayed on the map screen. (For details, see page 33.)

LIST OF POINTS OF INTEREST



ALL AUTOMOTIVE



AUTOMOBILE CLUB



AUTO SERVICE & MAINTENANCE



GAS STATION



LEXUS DEALERSHIPS
(all search areas)



PARKING GARAGE/HOUSE



PARKING LOT



TOYOTA DEALERSHIPS
(all search areas)



ALL BANKING



ATM



BANK



ALL COMMUNITY



CITY HALL



CIVIC/COMMUNITY CENTER



CONVENTION/EXHIBITION CENTER



COURT HOUSE

Destination Input by POINT OF INTEREST

	HIGHER EDUCATION		GOLF COURSE		WINERY
	HOSPITAL		MARINA		RESTAURANT
	LIBRARY		MUSEUM		AMERICAN
	POLICE STATION		PARK/RECREATION (all search areas)		CHINESE
	SCHOOL		PERFORMING ARTS		CONTINENTAL
	ALL ENTERTAINMENT & ALL RECREATION		SKI RESORT		FRENCH
	AMUSEMENT PARK (all search areas)		SPORTS COMPLEX		ITALIAN
	CASINO		TOURIST ATTRACTION (all search areas)		JAPANESE


I

Destination Input by POINT OF INTEREST

	MEXICAN		BUS STATION		TOURIST INFORMATION
	SEAFOOD		COMMUTER RAIL STATION		TRAIN STATION
	OTHER		FERRY TERMINAL		ALL OTHER
	ALL SHOPPING		HISTORICAL MONUMENTS		BUSINESS FACILITY
	GROCERY STORE		HOTEL		CITY CENTER/NAMED PLACE
	SHOPPING		PARK AND RIDE		
	ALL TRAVEL		RENTAL CAR AGENCY		
	AIRPORT (all search areas)		REST AREA		

Destination Input by MARKED POINT

Touching the "Marked Point" switch on the destination screen displays your list of registered marked points. See page 50 on registering and editing marked points.



When you touch the of your desired item, the screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)

There are 4 ways to list the marked point by touching switches on bottom of the screen.

Sort by Mark: Touch this switch to list the marked points by the registered icon. There are 16 different normal purpose icons, 5 special purpose icons and 3 sound icons. (For details, see page 52.)

Sort by Date: Touch this switch to list the marked points in order of registered date.

Sort by Name: Touch this switch to list the marked points in alphabetical order.


Sort by Dist: Touch this switch to list the marked points in order of shorter distance from your current location.

While driving, only special purpose icons will be shown on the screen.

Destination Input by PREVIOUS DESTINATION



Touch the **"Previous Destination"** switch on the destination screen.



The screen lists to 10 previously set destinations. During driving, the screen lists 5 previously set destinations.

Select your desired destination. The screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)

You can delete the list of previous destinations while you stop your car, if you no longer need them. However, the system must delete the complete list and does not allow removing single entries.

When you touch the "Delete All" switch, a message appears to confirm your request to delete the list. If you are sure, touch the "YES" switch. If not, touch the "NO" switch.

Destination Input by HOME



Touch the **"Home"** switch on the destination input screen.

The screen changes and displays the map location of your home and route preference. (See "Entering Destination" on page 22.)

The system starts the guidance from your current position to your home immediately after you touch the **"Home"** switch during driving.

If your home is not registered yet, the **"Home"** switch is dimmed.


For the steps to register your home, see "Registration of your home" on page 30.

Destination Input by EMERGENCY

By touching the "Emergency" switch on the destination input screen, the display changes to a screen to select police stations, hospitals or dealers. During driving, only nearby police stations, hospitals or dealers are shown. The current position is shown with an address, the latitude and the longitude at the top of the screen.



When you touch your desired emergency category, the selected emergency category list is displayed.



The distance from your current position up to the destination is displayed on the right of the name.

You can see the names of the emergency destinations in alphabetical order by touching the "Name Sort" switch on the screen.

Touch the of your desired item. The screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)

Touch the "Info" switch on the screen to display the selected emergency destination name, address and telephone number.


INFORMATION

The navigation system does not guide in areas where route guidance is unavailable. (See page 42.)

I

Destination Input by INTERSECTION

Touch the "Intersection" switch on the destination screen.




Input the name of the two intersecting streets which are located near the destination to be set.

When you touch the "List" switch or the number of sites becomes 4 or less, the list of matching street names appears.



Touch the of your desired item. After inputting the two intersecting streets, the screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)



If the same two streets cross at more than one intersection, the screen changes and displays the menu to select the city name where the streets intersect. Select the city, and the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)

Destination Input by FREEWAY ENTRANCE or EXIT

To input a freeway entrance or exit, touch the "Fwy Entrance/Exit" switch on the destination input screen.



Be sure to use the complete name of the freeway or highway, including the hyphen, when entering the destination. Freeways and interstates use an "I" (I-405). US highways use the state designation before the number (CA-118).


As the number of matching freeways decreases, you can touch the "List" switch to display the list. When the number of sites becomes 4 or less, the list screen appears automatically.



Select the desired freeway by touching the .



You can then select either a freeway "Entrance" or "Exit".




Touch the of the desired entrance or exit name. The screen changes and displays the map location of the selected destination and the route preference. (See "Entering Destination" on page 22.)



Destination Input by FREEWAY ENTRANCE or EXIT

There are 2 ways to list the freeway entrance or exit.

Dist Sort: Touch this switch to list the entrances or exits in order of distance from your current location.



Name Sort: Touch this switch to list the entrances or exits in alphabetical order.

Destination Input by PREVIOUS STARTING POINT



Touch the **"Previous Starting Point"** switch on the destination screen.

The screen changes and displays the map location of the previous starting point and the route preference. (See **"Entering Destination"**.)

If you have not used the navigation yet, the **"Previous Starting Point"** switch is dimmed.

Destination Input by MAP

Touch the "Map" switch on the destination screen.



The screen changes and displays the map location of the current position and the route preference. (See "Entering Destination".)

Entering Destination

After you input the destination by one of the ten methods, the screen changes and displays the map location of the selected destination and the route preference.




You can move and set the cursor  at a desired point. (For the method of how to move the cursor, see page 3.)

When you touch the "Enter" switch, the system starts searching for a route to your destination using the conditions entered.

Route Preference

Touch the "Change" switch to change the conditions which are to determine the route to your destination.

You are given a number of choices on the conditions which the system uses to determine the route to your destination.



Touch the "On" switch of "Minimize Freeway Use" to search for a route other than freeways as much as possible. (In some cases, the route cannot avoid running on a freeway.)

Touch the "On" switch of "Minimize Toll Road Use" to search for a route other than toll roads as much as possible.


Touch the "On" switch of "Minimize Ferry Use" to search for a route without using a ferry as much as possible.

The switches you select are highlighted in green. After choosing conditions, touch the "Enter" switch.

Entering Destination



During the route search, "Route Searching" appears at the top of the screen and changes color from the left. When the search is completed, three types of routes are displayed on the screen.



Touch the "Next" switch to choose one from the three routes.

Route 1: A route on which you can reach the destination in the shortest time.

Route 2: A route on which you can reach the destination in the shortest distance.

Route 3: Other route.

After selecting one, you can start the route guidance by touching the "Start" switch or starting to move your vehicle.

If you want to set a way point between the starting point and the destination or change the search condition, touch the "Chg. Route" switch. The screen changes and displays the change route menu. (For details, see page 24.)

When you keep touching the "Start" switch until you hear a beep, Demo Mode will start.

Route Guidance Screen

The route guidance system displays two different screen modes.



Single screen: Only map is shown in a screen mode.



Route Guidance Screen



Split screen: Map and guidance screen are shown in a screen mode. (For detail about Guidance screen, see page 36.)

The two route guidance screens have a number of indicators and switches with which you should be familiar.



Map/Guide: To change two screen modes.

[GPS]: Upon reception of signals from the GPS (Global Positioning System), this mark appears. (For details, see page 39.)



zoom IN / zoom OUT: Magnifies or reduces the map scale. (For details, see page 37.)



POI: Touch this switch, and symbols of points of interest are shown on the screen. (For details, see page 33.)



Mark: Touch this switch for one-touch registration of the marked point. (For details, see page 54.)

INFORMATION

- *The distance up to your destination appears at the left of the screen.*
- *The time to your destination can also be displayed. (For the setting steps, see page 64.)*

Chg. Route: The "Change Route" screen appears and the following settings are available.



Reroute: To change the condition for Reroute.



Detour: To change the condition for Detour. (For details, see page 32.)

Way point: To set and delete a way point. (For details, see page 55.)

Route Preference: To change the conditions of the route preference. (For details, see page 22.)



Cancel Guidance: To stop the route guidance. When you touch this switch, the map screen appears.

Route Guidance Screen

INFORMATION

If the calculated route includes a trip by ferry, the route guidance shows a sea route. After you travel by ferry, the current vehicle position may be incorrect. Upon reception of GPS signals, it is automatically corrected.

Current Position Display



The current vehicle position mark appears in the center of the map screen. You can return to this map screen showing your current position at any time from any screen by pushing the "MAP/VOICE" button on the bezel.

During driving, the current vehicle position mark is fixed in the center of the screen and the map moves.

If you move the map with a "one-touch" scroll (see page 38 for details), the current vehicle position mark continues to track your current location.

INFORMATION

When you use the "one-touch" scroll feature, the current vehicle position mark may disappear from the screen. Move the map with a "one-touch" scroll again or push the "MAP/VOICE" button on the bezel to return to the current vehicle position map location display.

The current position is automatically set as your vehicle receives signals from the GPS (Global Positioning System). If your current position is not correct, it is automatically corrected after your vehicle receives signals from the GPS.

INFORMATION

After the battery disconnection, or on a new vehicle, the current position may not be correct. As soon as the system receives signals from the GPS, the correct current position is displayed.

If you must correct the current position manually, follow the steps on page 61.

Voice Guidance



Voice route guidance to the destination during route guidance. Use voice guidance just for your reference.

You can adjust the volume of the voice or turn off voice guidance.



Push the "MENU" button on the bezel to display the menu screen. Then touch any number at the bottom of the screen to select the desired volume. If you do not need voice guidance, touch the "OFF" switch.


The selected item is highlighted in green.

You can listen to "Voice route guidance" by pushing the **"MAP/VOICE"** button on the bezel, even if the volume is "OFF".

INFORMATION

During route guidance, the voice guidance continues even if the navigation screen is changed to other screens, such as the audio screen.

Typical Voice Guidance Prompts




The voice guidance provides various messages as you approach an intersection, or other point where you need to maneuver the vehicle.

- 1 "Proceed about 5 miles to the T-intersection."
- 2 "In a quarter of a mile, right turn at the T-intersection."
- 3 "At the T-intersection, right turn."
- 4 Beep sound only


INFORMATION

On freeways, interstates of other highways with higher speed limits, the voice guidance will be made at earlier points than on city streets in order to allow time to maneuver.




- 1 "Proceed about 4 miles to the traffic circle."
- 2 "In a quarter of a mile, traffic circle ahead, and then right turn 3rd exit ahead."
- 3 "Next exit right."
- 4 Beep sound only.

Typical Voice Guidance Prompts




*: The system indicates a U-turn if the distance between two one-way roads (of opposite directions) is less than 15 m (50 ft.) in residential areas or 50 m (164 ft.) in non-residential areas.

- 1 🎵 "In half of a mile, make a legal U-turn."
- 2 🎵 "Make a legal U-turn."
- 3 🎵🎵 Beep sound only.



The system announces your approach to the final destination.

- 1 🎵 "Your destination is ahead."
- 2 🎵 "You have arrived at your destination. Your route guidance is now finished."



When information is available in the database, the voice guidance provides lane information when entering or exiting a freeway or interstate.

- 1 🎵 "In 2 miles, 405 freeway on the right."
- 2 🎵 "405 freeway on the right and then keep right onto 405 freeway south."
- 3 🎵🎵 Beep sound only.

Typical Voice Guidance Prompts

INFORMATION

- *If the system cannot determine the current vehicle position correctly (in cases of poor GPS signal reception), the voice guidance may be made early or delayed.*
-  *If you did not hear the voice guidance command, push the "MAP/VOICE" button on the bezel to hear it again.*

I

Registration of Your Home

If you register your home address beforehand, you can easily set the route back to your home.



1. Push the "MENU" button on the bezel to display the menu screen and touch the "Marked Point" switch.



2. Touch the "Register" switch of Home for registering your home.

If home is already registered, the "Register" switch is dimmed.



You may register the location of your home by three different methods: current position, address or map location. Touch the screen to select your desired method from the menu.

(a) Registering by current position

When you select this method, the current vehicle position is immediately registered as your home. This is the fastest method to use if you are at your house.

(b) Registering by street address

If you are away from your home, you can input your home address.

Input the address of your home in the same way as any destination input. (See page 6.)

(c) Registering by map

If you are close to your home, you can register the location of your home directly on the map.

Input your home in the same way as the destination input. (See page 22.)

Registration of Your Home

(d) Deleting the registration of your home



1. Push the "MENU" button on the bezel to display the menu screen and touch the "Marked Point" switch.




2. Touch the "Delete" switch of Home.

The screen changes and displays the map location of the home and a message. If you are sure that you want to delete, touch the "YES" switch. If not, touch the "NO" switch.




Detour Setting

When you are driving while the route guidance is operating, you can change the route to detour around a section of the route where a delay is caused by road repairs, an accident, etc.



Touch the "Chg. Route" switch if you encounter a reason to divert from the selected route.

Detour Setting



This picture shows an example of how the system would route you around a delay caused by a traffic jam.

- 1 This part indicates the location where traffic jam is occurring due to road repairs or an accident.
- 2 Detour route suggested by the system.



When you touch the "Chg. Route" switch, the screen changes to a change route screen that allows you to select the distance you want to detour. Touch one of the numeral keys to start the detour process. After detouring, the system returns to the original guidance route.



Alternate: If you touch this switch, the system will calculate an entire new route to the destination.


INFORMATION

- *When your vehicle is on a freeway, the detour distance selections are 5, 15, and 25 miles.*
- *The system may not be able to calculate a detour route depending on the selected distance and surrounding road conditions.*

Displaying Points of Interest



Points of interest such as gas stations and restaurants can be displayed on the map screen. You can also set their location as a destination and use them for route guidance.



To display a particular type of point of interest on the screen, touch the "POI" switch on the map screen.



A window with a limited choice of points of interest will be displayed. When you touch your desired type of point of interest, symbols will appear on the map screen indicating where the POI addresses are located.



All List: If you cannot find your desired point of interest on the limited choice screen, touch this switch. The screen then displays the complete "Point of Interest" listing screen.



When you select a point of interest type from either the limited list or the complete list, the screen will display symbols at those locations on the map screen.

Local POI Search: If you want to search the nearest point of interest, touch this switch. Then choose one of the categories. The system will list the points within 20 miles.

Touch the of your desired point of interest. Points of interest which you chose are displayed on the map screen.


To turn off the symbols of the points of interest on the map screen, touch the "POI Off" switch.



Displaying Points of Interest

Setting a POI as a destination

You can select one of the points of interest symbols on the map screen as a destination and use it for a route guidance.



Directly touch the symbol of the point of interest that you want to set as a destination.

The map will shift so the symbol is centered in the screen and overlaps with the cursor .

The name of the point of interest and the "Info" switch are displayed at the top of the screen. When you touch the "Info" switch, the information such as the name and address, etc. are displayed. The distance from your current position can be displayed at the bottom left of the screen.

When your desired point of interest overlaps with the cursor, touch the "Ent Dest" switch. The screen changes and displays the map location of the selected destination and route preference. (See "Entering Destination" on page 22.)

If the symbols of two or more points of interest overlap as they are close to each other in location, touch the "Next" switch to bring your desired mark in front of the others.

Turn List



You can change from the map screen to a "Turn List" screen that displays the list of the roads up to your destination. This list can be used for a route guidance.




1. Push the "MENU" button on the bezel to display the menu screen and touch the "Route Information" switch.

Turn List



2. The screen will change to the Entire Route Map screen where you can touch the "Turn List" switch.



You can scroll through the list of roads by touching  . However, not all road names in the route may appear on the list. If a road changes its name without requiring a turn (such as on a street that runs through two or more cities), the name change will not appear on the list. The street name closest to the starting point will be displayed with a mileage to the next turn.



These marks indicate the direction which you should turn at an intersection.

INFORMATION

- *The current vehicle position mark appears at the bottom of the screen next to the name of the street you are driving on. The mark does not move.*
- *If you leave the guidance route, the name of the street you are on is not shown on the list next to the current vehicle position mark.*
- *If the road type you are on changes between a highway, a main street or a residential street (at an interchange or fork), it will appear on the turn list.*
- *If a long route has been selected, it may take a long time to display the turn list.*
- *Push the "MAP/VOICE" button on the bezel to return to the map display with a route guidance.*


Guidance Screen



You can change half of the screen to the Guidance Screen by touching the "Map/Guide" switch while the map screen is displayed. You can choose one out of two types of Guidance Screen.



1. Push the "MENU" button on the bezel to display the menu screen and touch the "Guidance Setup" switch.



2. The screen will change to the Guidance setup screen and you can select the "Guidance Screen Type".



To display Arrow Screen



To display Turn List Screen

Arrow Screen



This screen shows the current road name and the distance to the next corner.

Guidance Screen

Turn List Screen



The screen shows the Turn List. You cannot scroll through the list of roads.

Map Scale



Touch the **"zoom IN"** switch or the **"zoom OUT"** switch to change the scale of the map display. The scale bar and indicator at the bottom of the screen indicates the map scale menu. The scale runs from 1/16th of a mile to 64 miles. Touch the **"zoom IN"** switch or the **"zoom OUT"** switch until the scale bar changes normally. If you continue to hold your finger on the switch, the scale bar changes smoothly.

You can change the scale of the map display by touching the scale bar directly. It is not available during driving.

The map scale is displayed under the North-up symbol or Heading-up symbol at the top left of the screen.

INFORMATION

When the map scale is at the maximum range of 64 miles, the "zoom OUT" switch is dimmed. When the map scale is at the minimum range of 1/16th mile, the "zoom IN" switch is dimmed.

I

Screen Scrolling



If you wish to look at a different point on the map other than your current vehicle position, you can bring the desired point to the center of the screen by using the scroll feature.

Touch any point on the screen, and that point moves to the center of the screen and is shown by the cursor mark. You can then set this place as a destination. Touch the **"Ent Dest"** switch on the screen.

If a destination is already registered, you can enter a way point.

If you continue to hold your finger on the screen, the map will continue scrolling in that direction until you lift your finger.


If you touch switches like **"Mark"**, **"POI"**, etc., the screen does not scroll and the respective function operates.

After scrolling the screen, the map remains centered at the selected location until you activate another function. The current vehicle position mark will continue to move along your actual route and may move off the screen. When you push the **"MAP/VOICE"** button on the bezel, the current vehicle position mark returns to the center of the screen and the map moves as you proceed on your route.

INFORMATION

If you enter a destination using the screen scrolling function, the road nearest to the point you touched is set as the destination. At this time, if the nearest road is over 3 miles from destination point, the system may not be able to calculate a guidance route.

Orientation of the Map



Orientation of the Map

You can change the orientation of the map from North-up to Heading-up by touching the direction symbol at the top left of the screen.



North-up symbol

Regardless of the direction of vehicle travel, North is always up.



Heading-up symbol

The direction of the vehicle travel is always up. A red arrow indicates North.

Limitations of the Navigation System

This navigation system calculates the current vehicle position using satellite signals, various vehicle signals, map data, etc. However, an accurate position may not be shown depending on the satellite condition, road configuration, vehicle condition or other circumstances.


The Global Positioning System (GPS) developed and operated by the U.S. Department of Defense provides an accurate current vehicle position using 3 to 4 satellites. The GPS system has a certain level of inaccuracy built in for security reasons. While the navigation system will compensate for this most of the time, occasional positioning errors up to 300 feet can and should be expected. Generally, position errors will be corrected within a few seconds.



When your vehicle is receiving signals from the satellites, the "GPS" mark appears at the top left of the screen.

The GPS signal may be physically obstructed, leading to inaccurate vehicle position on the map display. Tunnels, tall buildings, trucks, or even the placement of objects on the instrument panel may obstruct the GPS signals.

The installation of window tinting may also obstruct the GPS signals. Most window tinting contains some metallic content that will interfere with the GPS signal reception. We recommend not to use the window tinting on vehicles equipped with navigation systems.



Limitations of the Navigation System

The GPS satellites may not send signals due to repairs or improvements being made to them.

Even when the navigation system is receiving good GPS signals, the vehicle position may not be shown accurately or inappropriate route guidance may occur in some cases.

(a) Accurate current vehicle position may not be shown in the following cases:

- When driving on a small angled Y-shaped road.
- When driving on a spiral road.
- When driving on a slippery road such as in sand, gravel, snow, etc.
- When driving on a long straight road.
- When freeway and surface streets run in parallel.
- After moving by ferry or vehicle carrier.
- When a long route is searched during high speed driving.
- When driving without setting the current position calibration correctly.
- After repeating a change of directions by going forward and backward, or turning on a turntable in the parking lot.
- When leaving a covered parking lot or parking garage.
- When a roof carrier is installed.
- When driving with the tire chains installed.
- When the tires are worn.
- After replacing a tire or tires.
- When using tires that are smaller or larger than the factory specifications.
- When the tire pressure in any of the four tires is not correct.

INFORMATION

If your vehicle cannot receive GPS signals, you can correct the current position manually. For the information on setting the current position calibration, see page 61.

Limitations of the Navigation System

(b) Inappropriate route guidance may occur in the following cases:

- When turning at a wrong intersection off the designated route guidance.
- If you are heading for a destination without passing through a set way point, automatic rerouting may display a route returning to the set way point.
- When turning at an intersection, there is no route guidance.
- When passing through the intersection, there is no route guidance.
- During automatic rerouting, the route guidance may not be available for the next turn to the right or left.
- It may take a long time to operate automatic rerouting during high speed driving. In automatic rerouting, a detour route may be shown.
- During automatic rerouting, the route may not be changed.
- The route in a U-turn may be shown or announced.
- A location may have multiple names and the system will announce one or more.
- Some routes may not be searched.
- If the route to your destination includes gravel, unpaved roads or alleys, the route guidance may not be shown.
- Your destination point might be shown on the opposite side of the street.
- When a portion of the route has regulations prohibiting the entry of the vehicle that vary by time or season or other reason.
- The road and map data stored in your navigation system may not be complete or may not be the latest release.

When replacing the tire(s), contact your dealer.

This navigation system uses the tire turning data and is designed to work with factory-specified tires for your Lexus. Installing tires that are larger or smaller than the originally equipped diameter may cause inaccurate display of the vehicle's position. The tire pressure also affects the diameter of the tires so please make sure the tire pressure of all four tires is correct.

Map Database Information and updates

Map database is made based on the maps, 1999 edition of DENSO, whose information source comes from NavTech maps and GDT maps.

© 1999 Navigation Technologies. All rights reserved.

© GDT, Geographic Data Technology, Inc.

This product contains proprietary and confidential property of Geographic Data Technology, Inc. Unauthorized use, including duplication of this product is expressly prohibited.

There are two types of areas available for route guidance. (See the following pages.) In one type of area, primarily around metropolitan centers, detailed route guidance is available for the entire area. In the other type of area, all roads are displayed on the map but route guidance is limited. The navigation route might lack precision because the data (no right turns, one-way traffic, etc.) is not completed. It is still possible to reach the destination by following the arrow direction and distance as shown on the bottom left of the screen. The arrow points in the direction of the destination. The distance shown is as measured in a straight line from the current vehicle position to the destination area.



In order to provide you with accurate map information as much as possible, we are always gathering information such as road repairs and doing site investigation. However, the names of roads, streets, facilities, and their locations are often changed. In some places, construction on roads may be in progress. For that reason, information on some areas in this system might be different from the actual location.

The map database is normally updated once a year. Contact your dealer for updating a map database.



System Option: To determine which version of the database is currently in your vehicle, touch the **"System Option"** switch on the "Menu" screen. The "System Option" screen appears and displays the map database version date. Contact your dealer to find out if there is a more recent update released.

Map Database Information and updates

Route guidance availability



1999 by NavTech
Route guidance available areas
Route guidance available for main roads only

Route guidance availability



1999 by NavTech
Route guidance available areas
Route guidance available for main roads only

I

Map Database Information and updates

Route guidance availability



1999 by NavTech
Route guidance available areas
Route guidance available for main roads only

Route guidance availability



1999 by NavTech
Route guidance available areas
Route guidance available for main roads only

Map Database Information and updates

Route guidance availability



1999 by NavTech
Route guidance available areas
Route guidance available for main roads only

Route guidance availability



1999 by NavTech
Route guidance available areas
Route guidance available for main roads only



Map Database Information and updates

Route guidance availability



1999 by NavTech
Route guidance available areas
Route guidance available for main roads only

Route guidance availability





1999 by NavTech
Route guidance available areas
Route guidance available for main roads only

Map Database Information and updates

Route guidance availability



1999 by NavTech
Route guidance available areas
Route guidance available for main roads only



INFORMATION

For the up-dated map DVD-ROM, contact your Lexus dealer.

Map Database Information and updates

SECTION *II*

ADVANCED FUNCTIONS

Descriptions of functions for more effective use

Marked points	50
Way points	55
Avoid point/area	58
Current position calibration	61



Marked Points

You can register and keep your own marked points of interest list (like restaurants, sports facilities, etc.) and use the marked points to input a destination.

(a) Registering marked points



1. Push the "MENU" button on the bezel to display the menu screen and touch the "Marked Point" switch.




2. Touch the "Register" switch of the Marked Point.



A screen similar to that for destination input appears. Input the address of the marked point in the same way as any destination input. See page 6 through 22.

Marked Points



When you finish registration of the marked point, the "Edit Marked Point" screen appears. The information shown depends on the method used to enter the marked point.

If you want to change the icon or name or enter a telephone number, touch the item to be edited (on the left side of the screen).

3. Touch the "OK" switch.

INFORMATION

Up to 100 marked points can be registered.


(b) Editing marked points

Once a marked point is registered, you can edit the icon, name or telephone number.

1. Push the "MENU" button on the bezel to display the menu screen and touch the "Marked Point" switch.



2. Touch the "Edit" switch.



The screen lists the marked points.

Sort by Mark: Touch this switch to list the marked points in order of the type of symbol.


Sort by Date: Touch this switch to list the marked points in order of the registered date.

Sort by Name: Touch this switch to list the marked points in alphabetical order.

Sort by Dist: Touch this switch to list the marked points in order of nearest place from your current location.

Touch of the desired marked point to display the edit marked point screen.

Marked Points



Touch the item to edit (on the left side of the screen).

- Editing an "Icon"



Touch your desired icon.

Special Purpose Icon: During driving, only special purpose icons can be selected in the marked point list. You can register up to 5.

Sound Icon: When you set on these icons, the buzzer sounds as your vehicle approaches them.

When you touch the desired symbol or "Back", the previous screen is displayed.

- Editing a "Name"



Touch alphabet or numeral keys directly to input the name.

After you finish your entry, touch the "Enter" switch at the bottom right of the screen.

The previous screen will be displayed.

- Editing a "Phone" (telephone number)




Touch numeral keys directly.

After you finish your entry, touch the "Enter" switch at the bottom of the screen.

The previous screen will be displayed.

Marked Points

- Editing a "Position" (position/map location).



Touch the arrows to scroll to your desired point on the map screen.

Touch the "Enter" switch when the cursor  moves to your desired point.

The previous screen will return.

After you finish any editing, touch the "OK" switch.

(c) Deleting marked points

1. Push the "MENU" button on the bezel to display the menu screen and touch the "Marked Point" switch.



2. Touch the "Delete" switch of the marked point.





3. Touch of the marked point to delete. If you want to delete all of the marked points, touch the "Delete All" switch.



Marked Points

To delete only specified marked points, use the **"Mark"**, **"Date"**, **"Name"** or **"Dist"** switch to display the screen, so that you can easily find the marked points.




Either of the above messages appears depending on the type of deletion. If you want to delete, touch the **"YES"** switch. To cancel the deletion, touch the **"NO"** switch.



(d) One-touch marked point registration



You can register your current position or any points (See **"Screen Scrolling"** on page 38.) from the map screen by touching the **"Mark"** switch.



When you touch the **"Mark"** switch, the above screen appears for a few seconds, and then the map screen returns.


Marked Points



The registered point is shown by ■ on the map.

To change the icon or name, etc., see "(b) Editing marked points".


You can register up to 100 marked points. If you attempt to register more than 100, a message appears for confirmation.



If you want to register a new point, touch the **"YES"** switch and delete several old points. See "Deleting marked points".

If you do not want to delete the points already registered, touch the **"NO"** switch.

Way Points



You can set way points during route guidance. Touch the **"Chg. Route"** switch to display the following screen.



Way Points

(a) Setting a way point

1. Touch the "Set" switch.



2. Enter your way point in the same way as you input any destination. (See page 6 through 22.)

The set way point is indicated by ① through ⑤.


INFORMATION

If some way points are already registered on the route, "Add" instead of "Set" is displayed.

After entering a way point, the screen changes and displays the map location of the way point and route preference. (See "Entering Destination" on page 22.)

(b) Adding a way point

1. Touch the "Add" switch to display the Add Way Point screen.



2. Select the section of your route where you want to add a way point and touch the "ADD" switch.

MAP: If you touch this switch, you can confirm the set way points already registered on the map screen.



3. Add a way point in the same way as you input the destination.

You can set up to 5 way points.

After adding a way point, the screen changes and displays the map location of the way point and route preference. (See "Entering Destination" on page 22.)

Way Points



(c) Deleting a way point

1. Touch the "Delete" switch to display the Delete Way Point screen.



2. Select the way point you want to delete and touch the "Delete" switch.



3. A selected point and above message appear. To delete the point, touch the "YES" switch. If you want to try again or cancel the deletion, touch the "NO" switch. The previous screen will return.

INFORMATION

When the vehicle is in motion, "Delete Next" instead of "Delete" is displayed.

(d) Deleting the next way point



When the vehicle is in motion, only the next way point can be deleted. Touch the "Delete Next" switch.

Avoid Point/Area

Any points you want to avoid due to traffic jams, construction work or other reasons can be registered as avoid points.

Push the "MENU" button on the bezel to display the menu screen and then touch the "Avoid Point/Area" switch to display the following screen.



INFORMATION

- *Some areas and freeways may not be able to be set as an avoid point.*
- *If a destination is input in the avoid area or the route calculation cannot be made without running through the avoid area, a route passing through the avoid area may be shown.*

(a) Registering avoid point/area

1. Touch the "Register Avoid Point/Area" switch.



2. Enter the avoid point location in the same way as you input any destination or display the map of the area you want to avoid. (See page 6 through 22.)

Avoid Point/Area



3. Depending on the contents to be edited, touch either the "Reduce" or "Enlarge" switch or one of the arrows.


When you touch the "Enter" switch, the following message appears.




After a few seconds, the avoid point/area screen returns.

(b) Editing avoid points

1. Touch the "Edit Avoid Point/Area" switch to display the Edit Avoid Point/Area screen.



2. Touch the point you want to edit from the list.



3. Depending on the contents to be edited, touch either the "Reduce" or "Enlarge" switch or one of the arrows.

When editing is completed, touch the "Enter" switch.


INFORMATION

- If you try to change the map to an inappropriate scale, a message appears.
- For enlargement or reduction of the map scale, see page 37.

Avoid Point/Area



(c) Deleting avoid point/area

1. Touch the "Delete Avoid Point/Area" switch to display the Delete Avoid Point/Area screen.



2. Select the point you want to delete from the list.

Delete All: All avoid points registered in the system are deleted.



3. Either of the above messages appears.

To delete the point(s), touch the "YES" switch.

If you touch the "YES" switch, the data cannot be recovered.


If you want to try again or cancel deletion, touch the "NO" switch. The previous screen will return.

Current Position Calibration

The current vehicle position mark will be automatically corrected during driving on reception of GPS signals. If your vehicle cannot receive GPS signals, you can correct the current position mark manually.



1. Push the "MENU" button on the bezel to display the "Menu" screen, and then touch the "System Option" switch.



2. Touch the "Position" switch.

INFORMATION

For additional information on current position accuracy, see "Limitations of the Navigation System" on page 39.

● Position



1. Touch the scroll arrows to move the cursor  to your desired location.

Touch the "Enter" switch.

Current Position Calibration




2. Touch either the left or right arrow to correct the direction of the current vehicle position mark on the road.

Touch the **"Enter"** switch on the screen and the map screen returns.

● Distance

The distance calibration function is to be used when the tires are replaced. This will adjust for any possible change in tire circumference from the old tires to the new ones. If this procedure is not performed when tires are replaced, the current vehicle position mark may become incorrect.

To execute the fast distance tire calibration procedure, touch the **"Distance"** switch on the System Option screen.



The above message appears and the fast distance calibration is automatically started. A few seconds later, the map screen returns.

SECTION *III*

MORE ADVANCED FUNCTIONS

Convenient features

Automatic rerouting	64
Time to destination	64
Maintenance information	66
Dealer setting	68
Speech command system	71



Automatic Rerouting

When the "Automatic Rerouting" feature is turned on, the system will automatically search for a new route to the destination if you leave the guidance route. This feature does not operate while you are driving on roads where the guidance is not available.

To turn the "Automatic Reroute" mode on:

1. Push the "MENU" button on the bezel.



2. Touch the "Guidance Setup" switch.



3. Touch the "On" switch on the right of "Automatic Reroute".

Selected switch is highlighted in green.

INFORMATION

If your vehicle leaves the guidance route, the system searches for a new route to the destination. The new route may or may not take you back to the previous route depending on how far you are off the original guidance route.

Time to Destination

When the "Time to Destination" feature is turned on, the time required to reach the destination is displayed on the route guidance screen.




To turn the "Time to Destination" mode on:

1. Push the "MENU" button on the bezel.

Time to Destination



2. Touch the "Guidance Setup" switch.



3. Touch the "Set Average Speed" switch on the "Guidance Setup" screen.



4. Touch ◀ or ▶ to set the average vehicle speeds for driving on a freeway, main street and residential area.

If you touch the "Default" switch, the default speed is set at each item.

5. After you finish setting the desired speeds, touch the "Enter" switch.

6. The guidance setup screen returns. Touch the "On" switch on the right of "Time to Destination".

Selected switch is highlighted in green.

INFORMATION

- The displayed time to the destination is the approximate driving time calculated based on the speeds you selected and your actual position along the guidance route.
- The time shown may vary greatly depending on your progress along the route (which may be affected by road conditions such as traffic jams, construction work, etc.)
- Up to 99 hours 59 minutes can be displayed.




Maintenance Information



This system has a function which informs you of the time to replace certain parts or components as well as other information shown on the screen. (See "Information Items" on page 67.) When the system begins operating after reaching either the Information Item's date or driving distance, the "Information" screen will be displayed.

The "Information" screen will not be displayed again by touching the "Don't display again" switch.

1. Push the "OPTION" button on the bezel to display the option screen, and then touch the "Information" switch.



2. Touch the "Maintenance" switch.



3. Touch your desired icon and input the conditions.



Date: Input the next maintenance date.

Distance: Input the driving distance until the next maintenance check. You can input a five-digit number for the driving distance.

After you input that information, touch the "OK" switch. The screen then returns to the "Maintenance" screen. The icon's color will change to green after the date and driving distance are input. The icon's color will change to orange when your Lexus needs to be serviced. The following switches appear on the screen.

Delete All: Cancel all conditions which have been inputted.

Reset Expired: Reset an item which has satisfied a condition.

Maintenance Information

Touch the "OFF" switch at the top of the screen, and the information screen will no longer be displayed.

INFORMATION

- *For scheduled maintenance information, please refer to the "Owner's Manual Supplement / Maintenance Schedule".*
- *Depending on your driving or the road conditions, the system may have a time-lag between the data which have been inputted and the actual date and driving distance.*

Information Items



Scheduled Maintenance



Oil Change



Replace Oil Filter



Rotate Tires



Replace Tires



Replace Battery



Replace Brake Pad



Replace Wiper Blades



Replace Engine Coolant



Replace Brake Fluid



Replace Automatic Transmission Fluid



Replace Air Conditioning Filter



Replace Air Cleaner Filter



Wedding Anniversary



Birthday

III

Dealer Setting



You can register your dealer's name and address. Touch the "Dealer" switch on the "Maintenance" screen.

(a) Registering dealer



1. Touch the "Register Dealer" switch.

2. Enter your dealer's location address in the same way as you input any destination. (See page 6 through 22.)



3. After you enter your dealer, the screen changes and displays the map location of the dealer. If it is OK, touch the "Enter" switch.

The current screen changes to the screen where you can edit the data of your dealer. (See (b) Editing dealer.)

By touching the "Go to Dealer" switch the system sets your dealer as a destination. (See (d) Going to dealer.)

Dealer Setting

(b) Editing dealer



1. Touch the "Edit Dealer" switch.



2. Touch the item to edit.


• Editing a "Dealer" or a "Staff"



Touch alphabet or numeral keys directly to input the name.

After you finish your entry, touch the "Enter" switch at the bottom right of the screen. The previous screen will be displayed.

• Editing a "Position"



Touch the arrows to scroll to your desired point on the map screen.

Touch the "Enter" switch when the cursor moves to your desired point.

The previous screen will be displayed.

Dealer Setting

- Editing a "Phone" (telephone number)



Touch numeral keys directly.

After you finish your entry, touch the "Enter" switch at the bottom of the screen.


The previous screen will be displayed.

After you finish any editing, touch the "OK" switch.

- (c) Deleting dealer



1. Touch the "Delete Dealer" switch.



2. A selected point will appear. Also, a message will appear at the bottom of the screen. To delete, touch the "YES" switch. To cancel the deletion, touch the "NO" switch.

- (d) Going to dealer

The registered dealer can be set as a destination.



Touch the "Go to Dealer" switch. The screen changes and displays the map location of the registered dealer and the route preference. (See "Entering Destination" on page 22.)

Speech Command System

The speech command system allows you to operate the navigation system without using your hands.



1. Push the speech command switch.

A beep sounds and an indicator is shown at the top left of the display.



2. Give a command while an indicator is shown in the display.

If the navigation system does not respond or the confirmation screen does not disappear, please push speech command switch and try again.

If no command is given, a beep sounds and the indicator disappears 6 seconds later.

If you give an unavailable command, the system will respond with an error message. Start the operation from the beginning.

If the system does not recognize your speech, the system will respond with this message ("System does not recognize this command, please rephrase your command."). Start the operation from the beginning.



► *Microphone*

It is unnecessary to speak directly into the microphone when making a command.

III

Speech Command System

Speech command example: Searching for a route to your home.

1. Push the speech command switch.
2. Say "Go home".

If your home is not registered, you will hear "Home is not registered".



3. If you hear "Are you sure that you want a route to home?" (also shown on the display), push the speech command and say "Yes".

If you say "No", the search will be canceled.

4. You will hear "Calculating route to home" and then the system starts searching for a route.

Speech Command System

Command list

NOTE: The commands with ★ are listed in the Quick Reference Guide.

Map Operation1

Command	Action
★Current Position Current Location Show Current Position Show Current Location Map	Shows current position map.
★Zoom IN	Zooms in.
★Zoom OUT	Zooms out.
★Maximum Scale Max Scale	Shows maximum Scale.
★Minimum Scale Min Scale	Shows minimum Scale.
★Change to North Up North Up	Changes map bearing to north up.
★Change to Heading Up Heading Up	Changes map bearing to heading up.

Map Operation 2—To register a point

Command	Action
★Mark	Registers this point as a marked point.

Map Operation 3—To change the guidance mode

Command	Action
★Change to Arrow Guidance Change to Arrow Guide Arrow Guidance Arrow Guide	Changes guidance screen to arrow mode.
★Change to Turn List Guidance Change to Turn List Guid Turn List Guidance Turn List Guide	Changes guidance screen to turn list mode.



Speech Command System

★Change to Single Screen Single Screen Close Guidance Close Guide	Shows entire map screen. (Map + Small Arrow)
★Change to Split Screen Split Screen Open Guidance Open Guide	Shows guidance screen. (Map + Arrow/Turn List Guidance)

Destination 1

Command	Action
★Go Home Home	Calculates route to home.
★Go to Starting Point Return to Starting Point Previous Starting Point	Calculates route to previous starting point.

Destination 2—To enter a destination from the list

Command	Action
★Go to Marked Point Marked Point	Shows special marked points list. (even if slowing down or even when stopping.)
★Go to Previous Destination Previous Destination	Shows previous destinations list.
★Number One One First	Calculates route to special marked point. or Calculates route to previous destination.
★Number Two Two Second	Calculates route to special marked point. or Calculates route to previous destination.
★Number Three Three Third	Calculates route to special marked point. or Calculates route to previous destination.
★Number four Four Fourth	Calculates route to special marked point. or Calculates route to previous destination.

Speech Command System

★Number Five Five Fifth	Calculates route to special marked point. or Calculates route to previous destination.
-------------------------------	--

Route Change

Command	Action
★Cancel Guidance Cancel Route End Guidance	Cancels guidance and deletes route.
★Reroute	Changes the route.
★Detour	Calculates 5 miles detour route.
★Alternate Route	Calculates alternate route.
★Delete Next Waypoint Cancel Next Waypoint	Deletes next waypoint and re-routes.
★Delete First Waypoint Cancel First Waypoint	Deletes first waypoint and re-routes.
★Delete Second Waypoint Cancel Second Waypoint	Deletes second waypoint and reroutes.
★Delete Third Waypoint Cancel Third Waypoint	Deletes third waypoint and re-routes.

★Delete Fourth Waypoint Cancel Fourth Waypoint	Deletes fourth waypoint and re-routes.
★Delete Fifth Waypoint Cancel Fifth Waypoint	Deletes fifth waypoint and re-routes.
★Delete Final Waypoint Cancel Final Waypoint	Deletes last waypoint and re-routes.
Delete All Waypoint Cancel All Waypoint	Deletes all waypoint and re-routes.

Talk Back Reply

Command	Talk Back
★Yes	_____
★No	



Speech Command System

Guidance Help

Command	Action
★Repeat Guidance Repeat Voice	Repeats voice guidance.
★Show Route Entire Route	Shows entire route.
★Show Destination Show End of Route	Shows map surrounding destination.
★Show Next Waypoint	Shows position of next waypoint.
★Show First Waypoint	Shows position of first waypoint.
★Show Second Waypoint	Shows position of second waypoint.
★Show Third Waypoint	Shows position of third waypoint.
★Show Fourth Waypoint	Shows position of fourth waypoint.
★Show Fifth Waypoint	Shows position of fifth waypoint.
★Show Final Waypoint	Shows position of last waypoint.

Volume—To change the Volume

Command	Action
★Louder	Turns volume up 1 level.
★Softer	Turns volume down 1 level.
★Voice Guidance OFF	Turns voice guidance off.
★Voice Guidance ON	Turns voice guidance on.

Speech Command System

POI display on the map

	★Automobile Club Triple A
	Auto Service & Maintenance Auto Service Maintenance
	★Gas Station Gas
	★Lexus Dealership Lexus Dealer
	★Parking Garage Parking House
	★Parking Lot
	Toyota Dealership Toyota Dealer

	★ATM
	★Bank
	City Hall
	Civic Center Community Center
	Convention Center Exhibition Center
	Court House
	Higher Education University College

	★Hospital
	Library
	★Police Station
	School
	Amusement Park
	Casino
	Golf Course



	Marina
	Museum
	Park&Recreation Parks&Recreation
	Performing Arts
	Ski Resort Skiing
	Sports Complex Stadium
	Tourist Attraction

	Winery
	★Restaurant I'm Hungry
	★American Restaurant American Food
	Chinese Restaurant Chinese Food
	★Continental Restaurant Continental Food
	★French Restaurant French Food
	Italian Restaurant Italian Food

	★Japanese Restaurant Japanese Food
	★Mexican Restaurant Mexican Food
	Seafood Restaurant Seafood
	Other Restaurant Other Food
	★Grocery Store
	Shopping Mall
	★Airport

Speech Command System

	Bus Station
	Commuter Rail Station
	Ferry Terminal
	Historical Monument
	Hotel
	Park & Ride
	Rental Car Agency

	★Rest Area Rest Stop
	Tourist Information
	Train Station
	Business Facility
	City Center
Delete	★POI Off



SECTION IV

OTHER FUNCTIONS

LEXUS park assist system	82
Clock adjustment	88
Screen transition	88
Screen adjustment	88



Lexus Park Assist System



► Sensors

The Lexus park assist system will help you to park easily by detecting any obstacle around your vehicle with ultrasonic sensors and informing you of the approximate distance from the vehicle to the obstacle with the indicators on the display and with beeping sounds.*

This system will operate at a vehicle speed of less than about 10 km/h (6 mph) with the selector lever in a position other than "P".

*NOTE: *The display of the Lexus park assist system screen can be activated or deactivated. The volume of the beeps can be changed. See page 84 for details.*



You can use this system in either of the following ways.

- Push the main switch of the Lexus park assist system with the ignition on. A beep sounds for a second. After the system self-check is performed, the Lexus park assist system screen appears for 2 seconds.
- Push the main switch of the Lexus park assist system and turn the ignition on. The Lexus park assist system screen appears for 2 seconds and the system self-check is performed. At this time, a beep does not sound.


Up to 4 indicator bars are shown on the front and rear sides of the vehicle mark and up to 3 indicator arcs are shown on each corner of the vehicle mark. The number of indicators shows the approximate range up to the obstacle. The indicator marks disappear one-by-one as your vehicle comes closer to the obstacle. Also, as you get closer to the obstacle, the beeping interval becomes shorter.

NOTICE

- ***If an accident should occur, the sensors will be affected resulting in a system failure.***
- ***If the indicators remain on the display but you do not hear a beeping sound, the system may be malfunctioning. Contact your Lexus dealer.***

Lexus Park Assist System

Indicators and beeps




► Front or rear obstacles

Depending on the distance between your vehicle and the obstacle, the display and beeps change as follows:

- 1 About 50 cm (1.5 ft.) to about 100 cm (3.0 ft.):** 4 bars (green, yellow, orange and red) appear on the front or rear side of the vehicle mark where the obstacle is detected. If the obstacle is detected on the rear side of the vehicle, the beeps remind you that your vehicle is getting closer to the obstacle by sounding intermittently.
- 2 About 37.5 cm (1.1 ft.) to about 50 cm (1.5 ft.):** The green bar is disappeared, and the beeps sound at shorter intervals than in step **1**.
- 3 About 25 cm (0.8 ft.) to about 37.5 cm (1.1 ft.):** The yellow bar is disappeared. The beeps sound at shorter intervals than in step **2**.
- 4 Less than about 25 cm (0.8 ft.):** The orange bar is disappeared and the beeps sound continuously.

*NOTE: *The display and beeps can be activated or deactivated. See page 84 for details.*



► Corner obstacles

Depending on the distance between your vehicle and the obstacle, the display and beeps change as follows:

- 1 About 37.5 cm (1.1 ft.) to about 50 cm (1.5 ft.):** 3 arcs (yellow, orange and red) appear on the corner of the vehicle mark where the obstacle is detected. At this time, the beeps remind you that your vehicle is getting closer to the obstacle by sounding intermittently.
- 2 About 25 cm (0.8 ft.) to about 37.5 cm (1.1 ft.):** The yellow arc is disappeared, and the beeps sound at shorter intervals than in step **1**.

Lexus Park Assist System

- 3 Less than about 25 cm (0.8 ft.): The orange arc is disappeared and the beeps sound continuously.

Malfunction warning



If a sensor malfunctions, a beep sounds for about 7 seconds and a message indicating sensor's malfunction appears.

If the above screen appears on the display, the following causes are suspected.

- The sensor is malfunctioning or the cables has broken.
- Icicles, snowflakes or mud get on the sensor.

The sensors operate individually. While one sensor is malfunctioning, sounding beeps and blinking indicators, if another sensor detects an obstacle, the approximate distance to the obstacle will be shown.


Lexus park assist menu

The system conditions can be changed.



1. Push the "OPTION" button on the bezel to display the option screen and touch the "Information" switch.

Lexus Park Assist System



2. Touch the "LEXUS Park Assist" switch.



Volume Control: The volume of the beeps can be selected in 5 steps.


Tone: The distance within which the front and rear sensor starts to sound is selected (either 1m (3.0 ft.) or 50cm (1.5 ft.)).

Display: The distance within which the front and rear sensor starts to display arcs is selected (either 1m (3.0 ft.) or 50cm (1.5 ft.)).

Display OFF: The display of the LEXUS park assist screen can be deactivated, even if the sensor detects an obstacle.

The multi-information display and a beep can be activated even if the display is off.

Lexus park assist system operating hints



► **Sensor detection range**

IV

Lexus Park Assist System

The sensor detection range is limited around the bumper. Be sure to confirm a safe distance around your vehicle and drive slowly.

If more than one obstacle is detected in the same direction, the indicators for the obstacle nearest to the vehicle will turn on.



CAUTION

Do not install an accessory or the likes within the sensor detection range. Doing so may cause the Lexus park assist system to malfunction resulting in an accident.

NOTICE

- *The sensors do not detect obstacles just under the bumper. A short object, thin stake or the likes will be detected once but might not be detected as your vehicle gets very close to them.*
- *If an obstacle is very close to your vehicle, it might not be detected.*
- *If a strong impact is applied to a sensor, it will not operate properly.*

The Lexus park assist system may not work properly in the following cases:

- When iced, snowflakes or mud gets on the sensors. If they are removed, the system will work properly.
- When the sensor is frozen. If they are defrosted, the system will work properly.
- When the sensor is covered with something. If they are removed, the system will work properly.

Especially in the cold, a malfunction warning screen may appear on the display due to frozen sensors. If the malfunction warning screen appears on the display, be sure to check the sensor. If the malfunction warning screen appears even with no mud, ice or snowflakes on the sensor, the sensor might have malfunctioned. Have your vehicle checked by your Lexus dealer.

In the following conditions, the detection range may be affected:

- When you stop your vehicle in scorching sun or in cold weather.
- A foreign matter such as snowflakes or mud gets on the sensor.

In the following conditions, the Lexus park assist system may not detect objects correctly.

- When driving on bumpy or gravelled roads, or on grass.
- When a device issuing ultrasonic waves such as the horn from another vehicle, motorcycle engine, air braking sound from heavy-duty vehicles etc. is operated around your vehicle.
- When rain or water splashes over the sensor.

Lexus Park Assist System

- When the vehicle is tilted.
- When a radio antenna or fender pole is mounted.
- When mud, ice or snowflakes get on the sensor.
- When you are heading for a tall curb stone or a curb stone at a right angle.

The Lexus park assist system may not detect the following:

- Thin objects such as wire or rope
- Sound wave absorbing objects such as cotton or snow
- Objects with a sharp edge
- Shorter objects
- Tall objects or objects that protrude outwards and above the sensor detection range.

Clock Adjustment

The clock in this system can be corrected manually or by using signals from the GPS. Daylight Saving Time setting or your desired time setting is available.

1. Push the "OPTION" switch.



2. Touch "Adjust Clock".



Auto Adjust ON: When you touch this switch, the time is set to the GPS clock, and this switch is highlighted in green.

Auto Adjust OFF: To reset the hour, touch the "H" switch. To reset the minute, touch the "M" switch. To adjust the time to the nearest hour, touch ":00" switch.

Daylight Saving Time: Daylight saving time can be set or canceled.

While daylight saving time is set, this switch is highlighted in green.

Time Zone: You can select the time zone. Touching this switch changes to the time zone selection screen.

Clock Adjustment



Touch the switch of your desired area. The time zone for the area is set and the previous screen returns.

Screen Transition

The function returning to the previous screen from the audio or air conditioner screen is selectable.

1. Push the "OPTION" button on the bezel to display the option screen and touch the "Screen Transition" switch.



2. Select the "ON" or "OFF" and then touch the "OK".

ON: The previous screen automatically returns from the audio or air conditioner screen 20 seconds after the end of audio or air conditioner screen operation.

OFF: The audio or air conditioner screen remains on.

Screen Adjustment

You can adjust the brightness or contrast of the screen depending on the brightness of your surroundings. You also can turn the display off.

Push the "OPTION" button on the bezel to display the option screen and touch the "Display" screen.

Screen Adjustment



Contrast and brightness adjustment

CONTRAST "+":

Strengthens the contrast of the screen.


CONTRAST "-":

Weakens the contrast of the screen.

BRIGHTNESS "+": Brightens the screen.

BRIGHTNESS "-": Darkens the screen.

The screen turns off when you push the "SCREEN OFF". To turn the display screen back on, push any bezel switch such as "OPTION", etc. The selected screen appears.



Depending on the position of the headlight switch, the screen changes to the day mode or night mode.

To display the screen in the day mode even with the head light switch on, touch "DAY MODE" on the adjustment screen for brightness and contrast control.

However, if the instrument panel light control switch is turned fully to the right, mode switching cannot be done. It remains in the day mode. In this case, "DAY MODE" is not shown on the screen.

If the screen is set in the day mode with the headlight switch turned to on, this condition is memorized in the system even with the engine turned off.



SECTION V

AIR CONDITIONING

Automatic air conditioning controls	92
Rear air conditioning controls	104
Air purifier	106




Automatic Air Conditioning Controls



	<i>Page</i>
1 Temperature selector (with the "DUAL" button on; for driver and rear passenger) (with the "DUAL" button off; for driver and all passenger)	95
2 Passenger side temperature control button	95
3 Front windshield button	98
4 Driver side temperature display	95
5 Outside temperature display	99
6 Passenger side temperature display	95
7 Air flow control switch	96
8 Air conditioning on-off switch ..	98
9 Fan speed control switch	96
10 Center vent vane swing button .	101
11 Air conditioning operation screen display button	94
12 Rear air conditioning, Air purifier (if equipped)	104/106
13 OFF button	94
14 Automatic control button	94
15 Air intake control button	97
16 Separate/dual control switch	95

21L003c

Automatic Air Conditioning Controls



► **Air flow selection**

⇒ See "Lower vent" on page 102. ➔ Automatic air flow mode only.

V

Automatic Air Conditioning Controls

- **The automatic air conditioning automatically maintains the set temperature.**

This air conditioning features automatic fan speed and air flow control which automatically selects the most suitable fan speed and air flow to control the temperature. The ignition switch must be in the "ON" position.

CLIMATE: Push this button to display switches for automatic air conditioning controls.

NOTICE

To prevent the battery from being discharged, do not leave the air conditioning on longer than necessary when the engine is not running.

(a) Climate control

SETTING OPERATION – automatic control



1. Push the "AUTO" button.

Air flow quantity, switching of the diffusers, on-off of the air conditioning, and switching of the air intake between RECIRCULATED AIR and OUTSIDE AIR are automatically adjusted. If you use the air purifier automatic mode at the same time, air purifying effect will be enhanced (if equipped). The operation status is shown by each indicator.

When one of the manual control buttons is depressed while operating in automatic mode, the mode relevant to the depressed button is set. Other conditions continue to be adjusted automatically.

It is recommended to close the lower vent. For details about it, see page 102.

Push the "OFF" button briefly to turn the air conditioning off. If you keep the "OFF" button pushed, the data for the air filter is reset.

Automatic Air Conditioning Controls



2. Use the "TEMP" or "PASSENGER TEMP" button to set the desired temperature.

The "TEMP" or "PASSENGER TEMP" button is used to set the desired temperature. The temperature will be controlled on the driver and front and rear passenger sides (if rear air conditioning is equipped) simultaneously or individually. The figures on the panel indicate degrees Fahrenheit or Centigrade.


"TEMP" button – Changes the temperature on the driver and front and rear passenger sides (if rear air conditioning is equipped) simultaneously or the driver side only.

"PASSENGER TEMP" button – Changes the temperature on the passenger side only.

"DUAL" button – Changes the mode of the temperature setting.

The indicator on the "DUAL" button has two modes:

- **When the indicator on** – For individual temperature setting
- **When the indicator off** – For simultaneous temperature setting



- ➔ Driver side setting
- ➔ Passenger side setting
- ⇨ Mixed setting



Automatic Air Conditioning Controls

SETTING OPERATION – manual control

When one of the manual control buttons is depressed while operating in automatic mode, the mode relevant to the depressed button is set. Other conditions continue to be adjusted automatically.

If manual air flow selection is desired –



The outlets from which air is delivered can be selected manually by touching the switch. The function of each mode is as follows:

- 1 **Panel** – Air flows mainly from the instrument panel vents.
- 2 **Bi-level** – Air flows from both the floor vents and the instrument panel vents.

- 3 **Floor** – Air flows mainly from the floor vents.

It is recommended to close the lower vent. For details about it, see page 102.

- 4 **Floor/Windshield** – Air flows mainly from the floor vents and windshield vents.

It is recommended to close the lower vent. For details about it, see page 102.

The selected mode is highlighted in green.

If quick heating or cooling is desired –

Push the "TEMP" or "PASSENGER TEMP" button on either side and hold it until the maximum figure or minimum figure appears.

If manual fan speed control is desired –



- 1 **Fan speed at low**
- 2 **Fan speed at high**

The fan speed can be set to your desired speed by touching the appropriate air flow control switch. The higher the fan speed is, the more air is delivered. Pushing the "OFF" button turns off the fan.

To remove exterior windshield frost, use the high speed setting.

The selected mode is highlighted in green.

Automatic Air Conditioning Controls

If manual switching of air intake is desired –



Each time you push the air intake control button, the mode changes in order from the RECIRCULATED AIR mode to AUTOMATIC mode to OUTSIDE AIR mode, then back to the RECIRCULATED AIR mode. Each indicator light shows which mode is now selected.

- 1 RECIRCULATED AIR mode** – If quick circulation of cooled air is desired, select this mode.
- 2 EXHAUST GAS AUTOMATIC mode** – If the outside air contains harmful substances like exhaust gas (i.e., when the vehicle running just in front of your vehicle accelerates rapidly), the system changes automatically from the OUTSIDE AIR mode (with indicators **2** and **3** on) to the RECIRCULATED mode (with indicators **1** and **2** on). If you use the air purifier automatic mode at the same time, air purifying effect will be enhanced (If equipped).
- 3 OUTSIDE AIR mode** – The system will take fresh outside air into the vehicle.

For normal use, it is best to keep the air intake control button set to OUTSIDE AIR mode. If recirculated air is used during heating, the windows will fog up more easily.

Turning off the air conditioning manually will cancel the EXHAUST GAS AUTOMATIC mode. If you select the "AUTO" mode during fan operating, the air conditioning turns on and the EXHAUST GAS AUTOMATIC mode will operate.

To change the sensitivity of the sensor switching between the RECIRCULATED and OUTSIDE AIR in the AUTOMATIC mode, push the air intake control button for a few seconds. The display changes as illustrated below.

The sensitivity of the sensor can be adjusted only while the vehicle has been stopped.



Touch the desired switch.

When you push any button except the air intake control button, the above screen disappears.



Automatic Air Conditioning Controls

If manual on-off of the air conditioning is desired –

Push the "A/C" button to turn the air conditioning on and push it again to turn the air conditioning off. If you turn off the air conditioning manually, the EXHAUST GAS AUTOMATIC mode will be cancelled.

If the outside temperature is lowered down to around 0°C (32°F), the air conditioning will turn off automatically. At this time, the indicator on the A/C button is off and the EXHAUST GAS AUTOMATIC indicator light remains on. However, the EXHAUST GAS AUTOMATIC mode does not operate. When the air conditioning turns on as with the raised temperature, the EXHAUST GAS AUTOMATIC mode resumes.

If the system is used for ventilation, heating in dry weather or removing frost or exterior fog on the windshield, turn the air conditioning off once it is no longer required. This will improve fuel economy. The air conditioning can be used for year-round automatic temperature control including cooling and dehumidifying operation.

If the air conditioning compressor does not operate, the indicator of the "A/C" button will blink. If the indicator of the "A/C" button blinks even when the "A/C" button is pushed again, have the compressor checked by your nearest Lexus dealer.

(b) Windshield defogging and defrosting



To remove interior fog on the windshield –

Push the "FRONT WINDSHIELD" button.

To remove frost or exterior fog on the windshield –

1. Push the upper side of the temperature control button until maximum figure appears on the temperature display.
2. Push the "FRONT WINDSHIELD" button.

Automatic Air Conditioning Controls

3. Push the "HI" of the air flow control switch to obtain a maximum air flow.

For further information for removing frost and fog, see "Lower vent" on page 102.

When the "FRONT WINDSHIELD" button is pushed while operating in automatic mode, the air conditioning is set to operate and the OUTSIDE AIR mode is set.

If you push the "FRONT WINDSHIELD" button once again while in the FRONT WINDSHIELD mode, the mode then returns to the last mode used.



CAUTION

Do not use the "FRONT WINDSHIELD" button during cooled air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield could cause the outer surface of the windshield to fog up blocking your vision.

When you turn the ignition switch on after the removal and installation of the battery terminal, the indicator light may flash and the operating sound of the motor may be heard. This does not indicate a malfunction.

You may hear the operating sound of the motor about 70 seconds after the ignition switch is turned off. This is not also a malfunction.

(c) Outside temperature display



Outside temperature is displayed on the screen.

The displayed temperature ranges from -30°C (-22°F) up to 50°C (122°F). If the temperature does not appear on the display or it shows "--", take your vehicle to your Lexus dealer.



Automatic Air Conditioning Controls

(d) Air filter

The air filter may clog after long use and reduce air flow.

When you replace the air filter, be sure to turn off the fan.



1. Open the glove box and remove the two covers.



2. Take out the air filter.

If the "CHANGE A/C FILTER" appears on the multi-information display, change the air filter as soon as possible because the air filter might have clogged.

Replace the air filter in the glove box. After the replacement, push and hold the "OFF" button for about more than 4 seconds to reset the air filter clogging data. The "A/C FILTER RESET" appears and the attention tone sounds to inform you that the data has been reset.

When you push the "OFF" button for about more than 4 seconds before the "CHANGE A/C FILTER" appears, the clogging data will be cleared. So do not reset the data before this message appears.

NOTICE

Do not drive with the air filter removed, or the efficiency of air conditioning may be lost.

Automatic Air Conditioning Controls

(e) Operating tips

- Make sure the air inlet grilles in front of the windshield are not blocked by leaves or other obstructions.
- If air flow control is not satisfactory, check the dashboard vents. (See "Center vents", "Side vents", "Lower vent" and "Rear vents".)
- To help cool down the interior after parking in the hot sun, drive for the first few minutes with the windows open. After the excess heat has blown away, close the windows.
- When driving on dusty roads, close all windows. If dust thrown up by the vehicle is still drawn into the vehicle after closing the windows, it is recommended that the air intake control button be left to the OUTSIDE AIR mode and the air flow control switch be selected to anywhere except the "OFF" button.
- If following another vehicle on a dusty road, or driving in windy and dusty conditions, it is recommended that the air intake control button be temporarily pressed in to the RECIRCULATED AIR mode, which will close off the outside passage and prevent outside air and dust from entering the vehicle interior.

Center vents



The center vents may be opened or closed as shown.



Push the "SWING" button to swing the vanes.

The vanes directly aimed at the driver and front passenger will swing wider as the room temperature nears the desired temperature. The swinging angle will also change from narrow to wide depending on the room temperature.



When you push the "SWING" button with no passenger on the front seat and "DUAL" button ON (with the indicator on):



Automatic Air Conditioning Controls

The vanes directly aimed at the driver and rear passenger will swing wider as the room temperature nears the desired temperature. The swinging angle will also change from narrow to wide depending on the room temperature.

When you push the "SWING" button with no passenger on the front seat and "DUAL" button ON (with the indicator off):


The vanes directly aimed at the driver will swing wider as the room temperature nears the desired temperature. The swinging angle will also change from narrow to wide depending on the room temperature.

Side vents



The side vents may be opened or closed as shown.

Lower vent



The lower vent may be opened or closed as shown.

For removing frost or fog, it is recommended to close the lower vent when you push the "FRONT WINDSHIELD" button, or use the "Floor" or the "Floor/Windshield" mode.

Automatic Air Conditioning Controls


Rear vents



The rear vents may be opened or closed as shown.



Rear Air Conditioning Controls



- ▶ **1** Rear air vent
- 2** AUTO button
- 3** OFF button
- 4** LO HI A/C or Manual

These are the controls added to the front air conditioning when your vehicle is equipped with a rear air conditioning. The controls for the rear passenger and for the front passengers both work the same, so operation can be made with the controls on either panel.

(a) Controls and functions

REAR AIR CONDITIONING ON-OFF-

Push the "AUTO" button to turn the air conditioning on, and push the "OFF" button to turn it off.

AIR FLOW CONTROL-

The mode changes every time the "LO HI A/C" or "Manual" button is pushed.

AUTO mode—Turns the fan operation to automatic.

LO speed mode—Turns the fan at low speed.

HI speed mode—Turns the fan at high speed.

Rear Air Conditioning Controls

(b) Rear cooling


1. Turn the front air conditioning on. The rear cooler will not turn on if the front air conditioning is off.
2. Turn the rear air conditioning on. The fan speed and rear cooler are adjusted automatically.
3. Use "**Manual**" or "**LO HI AC**" buttons to adjust the desired fan speed and the rear cooler. Each indicator light shows which mode is now selected.

(c) Air purification

The air purifier operates whenever the rear air conditioning or the air purifier ("**AUTO**", "**LO HI AC**" or "**Manual**" button) is on.



Air Purifier



To operate the air purifier, turn the rear fan on by pushing either of the rear fan on–off buttons of the rear cooler controls.

Switching on the rear fan turns on the air purifier at the same time. The front air conditioning may be on or off (See "Rear air conditioning controls" for details on rear fan operation.)

Replace the air filter when performance of air flow or deodorant function becomes low by the deterioration of filter.

SECTION VI

AUDIO SYSTEM

Audio system 108

Audio System

Quick reference for your audio system



20L242b

	<i>Page</i>
1 <i>Function switch display screen</i>	110
2 <i>Audio operation screen display button</i>	109
3 <i>Cassette tape slot</i>	119
4 <i>Traffic function button</i>	116
5 <i>Frequency turning knob</i>	114
6 <i>[Radio mode] Preset tuning</i>	114
<i>[Tape mode] Side change of cassette tape</i>	120
<i>[CD mode] Disc selection</i>	123
7 <i>Mode selectors</i>	109
8 <i>[Radio mode] Seek tuning</i>	115
<i>[Tape/CD mode] Direct access to a desired program</i>	121/124
9 <i>Turning the system on and adjusting volume</i>	109
10 <i>Stopping and ejecting a cassette tape</i>	119

► *On the Mark Levinson brand audio system, "Mark Levinson" logo is provided on the panel.*

Audio System

Using your audio system: some basics

This section describes some of the basic features of the Lexus audio system. Some information may not pertain to your system.

Your audio system works when the ignition switch is in the "ACC" or "ON" position.

NOTICE

To prevent the battery from being discharged, do not leave the car audio on longer than necessary when the engine is not running.

(a) Turning the system on and off



POWER-VOL: Push this knob to turn the audio system on and off. Turn this knob to adjust the volume. The system turns on in the last mode used.

AUDIO: Push this button to display switches for audio system.



Push the "AM", "FM", "TAPE" or "DISC" button to turn on that mode. The selected mode turns on directly.

Push these buttons if you want to switch from one mode to another.

If the tape or disc is not set, the cassette player or compact disc player does not turn on.

You can turn off the cassette player by ejecting the cassette tape. If the audio system was previously off, then the entire audio system will be turned off when you eject the cassette tape. If another function was previously playing, it will come on again.

Audio System



(b) Automatic sound levelizer

When the audio sound becomes difficult to be heard due to road noise, wind noise, etc. during driving, touch the "ASL" switch. The system adjusts to the optimum volume and tone quality according to the noise level.

The switches for radio, cassette tape and compact disc player operation are displayed on the liquid crystal display. Touch them lightly and directly on the screen.

The selected switch is highlighted in green.

Audio System

(c) Tone and balance

How good an audio program sounds to you is largely determined by the mix of the treble, mid-range, and bass levels. In fact, different kinds of music and vocal programs usually sound better with different mixes of treble, mid-range, and bass.

A good balance of the left and right stereo channels and of the front and rear sound levels is also important.

Keep in mind that if you are listening to a stereo recording or broadcast, changing the right/left balance will increase the volume of one group of sounds while decreasing the volume of another.



Touching the "SOUND" switch on the screen displays the sound adjustment screen.



BASS "+" or "-": Adjusts low-pitched tones.

MID "+" or "-": Adjusts mid-pitched tones.

TREB "+" or "-": Adjusts high-pitched tones.

"Front" or "Rear": Adjusts sound balance between the front and rear speakers.

"L" or "R": Adjusts sound balance between the left and right speakers.

"OK": The previous screen returns.

Audio System

(d) Your radio antenna

The wire antenna is mounted inside the rear window.

NOTICE

When cleaning the inside of the rear window, be careful not to scratch or damage the wire antenna.

Putting a window tint (especially, conductive or metallic type) on the rear window may affect the reception of radio. For the installation of the window tint, consult with your Lexus dealer.


(e) Your cassette player

When you insert a cassette, the exposed tape should be to the right.

NOTICE

Do not oil any part of the cassette player, and do not insert anything except a cassette tape into the slot.

(f) Your automatic changer



To use the automatic changer, push the panel.

Audio System



NOTICE

Do not put any object on the panel or push it hard. Doing this may damage the panel.



Your automatic changer can store up to 6 discs and play selected discs or continuously play all the discs set in the player.

When you set discs into the player, make sure their labels face up. If not, the player will display "CD CHECK".

NOTICE

Never try to disassemble or oil any part of the compact disc player. Do not insert anything except a compact disc into the slot.

Do not insert a disc upon another one.

CD-R(CD-Recordable), CD-RW(CD-Re-writable) and personal computer use CD-ROMs may not be playable on your compact disc player.

The player is intended for use with 12 cm (4.7 in.) discs only.

Audio System

Radio operation

(a) Listening to the radio



Push these buttons to choose either an AM or FM station.

"AM", "FM1", "FM2" or "FM TYPE" appears on the display.



Turn this knob to step up the station band or to step down.

Your radio automatically changes to stereo reception when a stereo broadcast is received. "ST" appears on the display. If the signal becomes weak, the radio reduces the amount of channel separation to prevent the weak signal from creating noise. If the signal becomes extremely weak, the radio switches from stereo to mono reception. In this case, "ST" disappears from the display.

(b) Presetting a station



1. Tune in the desired station.

2. Touch one of the station selector switches (1–6) and hold it until a beep is heard. This sets the station to the switch and the frequency appears on the switch.

Each switch can store FM1, FM2 and AM. To change the preset station to a different one, follow the same procedure.

The preset station memory is cancelled when the power source is interrupted by battery disconnection or a blown fuse.

Audio System

(c) Selecting a station

Your Lexus has an electronic tuning radio (ETR). Tune in the desired station using one of the following methods.

Preset tuning: Touch the switch (1–6) or push the “^” or “v” button of the “CH” button for the station you want. The switch (1–6) is highlighted in green and station frequency appears on the display.

Manual tuning: Turn the “TUNE” knob briefly. Each time you turn the knob, the radio will step up or down to another frequency.

Seek tuning: Push the “^” or “v” button of the “SEEK” button and hold it until you hear a beep. The radio will begin seeking up or down for a station of the nearest frequency and will stop on reception. Each time you push the button, the stations will be searched out one after another.



Scan tuning: Touch the “SCAN” switch briefly. “SCAN” appears on the display. The radio will find the next station up or down the band, stay there for a few seconds, and then scan again. To select a station, touch the “SCAN” switch a second time.

Preset scan tuning: Touch the “SCAN” switch and hold it until you hear a beep. “P. SCAN” appears on the display. The radio will tune in the next preset station up or down the band, stay there for a few seconds, and then move to the next preset station. To select a station, touch the “SCAN” switch a second time.

Audio System

(d) RDS (Radio Data System)



AF (Alternative Frequency) function: A station providing good reception is automatically selected if current reception worsens.

This function switches over to the broadcasting station providing good reception within the same RDS network and is convenient for following the appropriate stations.



TRAF (Traffic) function: A station that regularly broadcasts traffic information is automatically sought and broadcasts when the program starts.

When you push the "TRAF" button, "TRAF SEEK" appears on the display and the radio will start seeking any traffic program station.

If any traffic program station is not found, "NOTHING" appears and the previous mode returns.

If the traffic program station is found, the name for traffic program station is displayed and "TRAF" is lit for a while until traffic announcement is received. When traffic announcement program starts broadcasting, "Traffic" will appear on the screen.

After the traffic announcement program is over, the previous mode returns.

Audio System

(e) TYPE (Program type)



When you touch the "RDS SRCH" switch during FM reception, "RDS SEARCH" appears and the radio starts to search RDS station.

If any RDS station cannot be found, "NO RDS Stations Found" appears and the previous mode returns.

If RDS stations are found, the stations are read and preset by program type. The FM TYPE mode screen displays the "*** RDS Stations Found" (** indicates the number of stations which are found) and then RDS stations appear in the order of frequency.

If in one program type, more than 6 stations are found, the 6 stations are preset in the order of the lower frequency.

Each time you push the "◀" or "▶", the program type changes as in the following:

- ROCK
- EASY LIS (Easy listening)
- CLS/JAZZ (Classical music and Jazz)
- R&B (Rhythm and Blues)
- INFORM (Information)
- RELIGION
- MISC.
- ALERT (Emergency message)

(f) Emergency broadcast



If an emergency broadcast is received during reception of other than AM broadcasting, "Alert" appears and an emergency broadcast will start.

Audio System

(g) Radio text message



If "MSG" appears during FM reception, touching the "MSG" switch displays the message display screen which indicates the text message from the RDS station.



If a new message is received with the first text message on the display, "MSG" appears on the corner of the screen again. When you touch the "**LATEST MESSAGE**" switch, the new message appears.

The RDS audio system has memory to store three messages consisting of 64 characters. To store a message in memory, touch the "**STORE**" switch until you hear a beep.

If 3 messages are already stored in memory, the oldest message will be overwritten by the new message.

To recall a radio text message, touch the "**RECALL**" switch. Each time you touch the switch, the message will be displayed from the new one.

When you touch the "**OK**" switch, the previous screen returns.

Audio System

Cassette tape player operation (a) Playing a cassette tape



When you insert a cassette tape, the exposed tape should be to the right.

The player will automatically start when you insert a cassette tape. At this time, "TAPE" appears on the display.

If a metal or chrome equivalent cassette tape is put in the cassette player, the player will automatically adapt to it and "MTL" appears on the display.

To stop or eject the cassette tape, push the "▲" button.



If a cassette is already in the slot, push the "TAPE" button.

Dolby® Noise Reduction* feature: If you are listening to a tape that was recorded with Dolby® B Noise Reduction, touch the switch marked with the double-D symbol. The double-D symbol is highlighted. Touch the switch again to turn off Dolby® B NR.

The Dolby NR mode reduces tape noise by about 10 dB. For best sound reproduction, play your tapes with this switch on or off according to the mode used for recording the tape.

* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.

Audio System

(b) Manual program selection



Reverse switch: You can reverse the tape by touching the "◀▶" switch or "PROG" button at the same time. The display will show the opposite direction after reversing the tape. Also if the tape reaches the end of one side, it is automatically reversed to the other side.

Fast forward and Rewind switches: You can fast forward or fast rewind by touching the "◀◀" or "▶▶" switch.

To stop the tape while it is fast forwarding, touch "▶▶", to stop the tape while it is rewinding, touch "◀◀".

If a tape rewinds completely, the cassette player will stop and then play the that same side. If a tape fast forwards completely, the cassette player will play the other side of the tape using the auto-reverse feature.

Auto-reverse feature: After the cassette player reaches the end of a tape, it automatically reverses and begins to play the other side, regardless of whether the cassette was playing or fast forwarding.

(c) Automatic program selection



"RPT" switch: The repeat feature automatically replays the current program.

Touch the "RPT" switch while the program is playing. When the program ends, it will automatically be rewound and replayed. Touch the switch again to turn off the repeat feature.

There must be at least 3 seconds of blank space between programs for the repeat feature to work correctly.

"SKIP" switch: The skip feature allows you to fast forward past long stretches of blank tape. This is especially useful at the end of cassettes.

Audio System

Touch the **"SKIP"** switch. The player will automatically skip any blank portions of 15 seconds or more and play the next program. To cancel it, touch the switch once again.



"Automatic program selection" button: The automatic program selection feature allows you to program your cassette player to skip forward or backward to locate the song you want to hear. You can skip up to 9 programs at a time.

Push this button on the upper side to skip forward. "FF" and the number will appear on the display. Push the button until the number you want to skip appears on the display. After that, the player will automatically skip forward.

When the end of the tape is reached, the player automatically reverses sides and resumes normal play.

Push this button on the lower side to skip backward. Push the button until "REW" and the number you want to skip appear on the display.

If you set "REW 1", the player will rewind to the beginning of the current program.

When counting the number of programs you want to rewind, remember to count the current program as well. For example, if you want to rewind to a song that is two before the song you are listening to, push this button until "REW 3" appears on the display.

When the beginning of the tape is reached, the player automatically resumes normal play.

There must be at least 5 seconds of blank space between programs for this feature to work correctly.

"RPT", "SKIP" or "Automatic program selection" features: These features may not work well with some spoken word, live or classical recordings.

Compact disc player operation

(a) Inserting or ejecting compact discs

The ignition switch must be in the "ACC" or "ON" position.

Your automatic changer can store up to 6 discs.



Audio System

Setting one compact disc alone:

1. Push the "LOAD" button briefly.

You can set a disc at the lowest empty disc number.

2. The green indicators of the slot start blinking. After the blinking indicators stay on, the CD door opens. While the CD door is open, insert only one disc. If you need to insert the next disc, repeat the same procedure to insert another disc.

After insertion, the set disc is automatically loaded.

If the label faces down, the disc cannot be played. In this case, "CD CHECK" appears on the display.


Setting all the discs:

1. Push the "LOAD" button until you hear a beep.
2. The green indicators of the slot start blinking. After the blinking indicators stay on, the CD door opens. While the CD door is opened, insert only one disc. The CD door closes and the green indicators of the slot start blinking. After the blinking indicators stay on, the CD door opens and you can insert the next disc. Repeat this procedure until you insert all the disc.

If you do not insert the discs within 15 seconds after pushing the "LOAD" button and CD door opens, the operation will be canceled automatically.

NOTICE

Do not insert a disc upon another one or put them continuously to prevent them from being stuck.



Ejecting one disc alone:

1. Push the "∨" or "∧" button to highlight the disc number you want to eject.
2. Push the "EJECT" button for the compact disc briefly.

At this time, the green indicators of the slot start blinking.

Ejecting all the discs:

Push the "EJECT" button for the compact disc until you hear a beep.

Audio System



The numbers of the trays where the compact disc is not set are dimmed.

(b) Playing a compact disc



Push the "DISC" button if the disc are already loaded in the player.

"CD" appears on the display.

The discs set in the player are played continuously, starting with the last disc you inserted. The disc number of the disc currently being played, the track number and the time from the beginning of the program are shown on the display.

When play of one disc ends, the first track of the following disc starts. When play of the final disc ends, play of the first disc starts again.

The player will skip any empty disc trays.

(c) Selecting a desired disc



On the screen: Touch the desired disc number.

The selected disc number is highlighted in green.

The player will start playing the selected disc from the first track.

On the audio panel: Push the "∧" or "∨" button of the "DISC" button.

When you release the button, the player will start playing the selected disc from the first track.

Audio System

(d) Searching for a desired disc



Touch the "DISC SCAN" switch.

With "DISC SCAN" highlighted in green, the program at the beginning of each disc will be played for 10 seconds. To continue listening to the program of your choice, touch the "DISC SCAN" switch a second time.

After all the tracks are scanned in one pass, normal play resumes.

(e) Selecting a desired track



"TRACK" button: Use for direct access to a desired track.

Push either side of the "TRACK" button and hold it until the desired track number appears on the display. As you release the button, the player will start playing the selected track from the beginning.

Fast forward: Touch the "▲" switch and hold it to fast forward the disc. When you release the switch, the compact disc player will resume playing from that position.

Reverse: Touch the "▼" switch and hold it to reverse the disc. When you release the switch, the compact disc player will resume playing.

Audio System

(f) Searching for a desired track



Touch the "SCAN" switch.

"Scan" will be highlighted in green. The compact disc player will play the next track for 10 seconds, then scan again. To select a track, touch the "SCAN" switch a second time. If the player reaches the end of the disc, it will continue scanning at track 1.

After all the tracks are scanned in one pass, normal play resumes.

(g) Other compact disc player functions



"RPT" switch: Use it for automatic repeat of the track you are currently listening to.

Touch the switch while the track is playing. When the track is finished, the player will automatically go back to the beginning of the track and play the track again. To cancel it, touch the switch once again.

"DISC RPT" switch: Use it for automatic repeat of the disc you are currently listening to.

Touch the switch while the disc is playing. When the disc is finished, the player will automatically go back to the beginning of the disc and play the disc again. To cancel it, touch the button once again.

"DISC RAND" switch: Use it for automatic track selection for all the discs and play by the system.

When the switch is touched, the system selects a track in the discs of all the trays which are set and plays it. To cancel it, touch the switch once again.

When a track is skipped or the system is inoperative, touch the switch to reset.

"RAND" switch: Use it for automatic and random selection of the disc which you are currently listening to.

When the switch is touched, the system selects a track in the disc you are currently listening to. To cancel it, touch the switch once again.

Audio System

(h) If the player malfunctions

If the player or another unit equipped with the player malfunctions, our audio system will display one of the following error messages.

If "CD CHECK" appears on the display: It indicates that the disc is dirty, damaged or it was inserted up-side down. Clean the disc or insert it correctly.

If "CD ERROR" appears on the display: The following causes are possible.

There is a trouble inside the system. Eject the disc.

The inside of the player unit may be too hot due to the very high ambient temperature. Eject the disc and allow the player to cool down.

If the malfunction is not rectified: Take your vehicle to your Lexus dealer.

Car audio system operating hints

NOTICE

To ensure the correct audio system operation:

Be careful not to spill beverages over the audio system.

Do not put anything other than a cassette tape or compact disc into the cassette tape slot or compact disc slot.

The use of cellular phone inside or near the vehicle may cause a noise from the speakers of the audio system which you are listening to. However, this does not indicate a malfunction.

Radio reception

Usually, the problem with radio reception does not mean there is a problem with your radio – it is just the normal result of conditions outside the vehicle.

For example, nearby buildings and terrain can interfere with FM reception. Power lines or telephone wires can interfere with AM signals. And of course, radio signals have a limited range, and the farther you are from a station, the weaker its signal will be. In addition, reception conditions change constantly as your vehicle moves.

Here are some common reception problems that probably do not indicate a problem with your radio:

FM

Fading and drifting stations – Generally, the effective range of FM is about 40 km (25 miles). Once outside this range, you may notice fading and drifting, which increase with the distance from the radio transmitter. They are often accompanied by distortion.

Multi-path – FM signals are reflective, making it possible for two signals to reach your antenna at the same time. If this happens, the signals will cancel each other out, causing a momentary flutter or loss of reception.

Static and fluttering – These occur when signals are blocked by buildings, trees, or other large objects. Increasing the bass level may reduce static and fluttering.

Audio System

Station swapping – If the FM signal you are listening to is interrupted or weakened, and there is another strong station nearby on the FM band, your radio may tune in the second station until the original signal can be picked up again.

AM

Fading – AM broadcasts are reflected by the upper atmosphere – especially at night. These reflected signals can interfere with those received directly from the radio station, causing the radio station to sound alternately strong and weak.

Station interference – When a reflected signal and a signal received directly from a radio station are very nearly the same frequency, they can interfere with each other, making it difficult to hear the broadcast.

Static – AM is easily affected by external sources of electrical noise, such as high tension power lines, lightening, or electrical motors. This results in static.

Caring for your cassette player and tapes

For high performance from your cassette player and tapes:

Clean the tape head and other parts regularly.

A dirty tape head or tape path can decrease sound quality and tangle your cassette tapes. The easiest way to clean them is by using a cleaning tape. (A wet type is recommended.)

Use high-quality cassettes:

Low-quality cassette tapes can cause many problems, including poor sound, inconsistent playing speed, and constant auto-reversing. They can also get stuck or tangled in the cassette player.

Do not use a cassette if it has been damaged or tangled or if its label is peeling off.

Do not leave a cassette in the player if you are not listening to it, especially if it is hot outside.

Store cassettes in their cases and out of direct sunlight.

Avoid using cassettes with a total playing time longer than 100 minutes (50 minutes per side). The tape used in these cassette is thin and could get stuck or tangled in the cassette player.

Caring for your compact disc player and discs



Use only compact discs labeled as shown. CD-R (CD-Recordable), CD-RW (CD-Re-writable) and personal computer use CD-ROMs may not be playable on your compact disc player.


Your compact disc player is intended for use with 12 cm (4.7 in.) discs only.

Extremely high temperature can keep your compact disc player from working. On hot days, use air conditioning to cool the vehicle interior before you listen to a disc.


Bumpy roads or other vibrations may make your compact disc player skip.

Audio System

If moisture gets into your compact disc player, you may not hear any sound even though your compact disc player appears to be working. Eject all discs from the player and wait until it dries.



Your automatic changer cannot play special shaped or low-quality compact discs as those shown here. Do not use them as the changer could be damaged.




► **Correct**

► **Wrong**

Handle compact discs carefully, especially when you set them into the player. Hold them on the edge and do not bend them. Avoid getting fingerprints on them, particularly on the shiny side.

Dirt, scrapes, warping, pin holes, or other disc damage could cause the player to skip or to repeat a section of a track. (To see a pin hole, hold the disc up to the light.)

Audio System



To clean a compact disc: Wipe it with a soft, lint-free cloth that has been dampened with water. Wipe in a straight line from the center to the edge of the disc (not in a circle). Do not use a conventional record cleaner or anti-static device.



CAUTION

Compact disc players use an invisible laser beam which could cause hazardous radiation exposure if directed outside the unit. Be sure to operate the player correctly.

VI