

# WARRANTY & MAINTENANCE GUIDE



2026

## SAFETY PRECAUTIONS

Your bZ has both high-voltage DC and AC systems as well as a 12-volt system. Both DC and AC high voltage are very dangerous and can cause personal injury, severe burns, electric shock and even fatal injury.

To avoid personal injury, please follow all caution labels attached to high-voltage parts. Do not touch or attempt to remove or replace any high-voltage (orange-colored) wiring and connectors. Do not touch the service plug located inside the center console.

If an accident occurs, do not touch any high-voltage wiring, connectors or parts such as the inverter unit or hybrid vehicle battery assembly.

Do not touch the traction battery if liquid is leaking from or adhered to it. If electrolyte (Organic Carbonate-based electrolyte) from the traction battery comes into contact with the eyes or skin, it could cause blindness or skin wounds. In the unlikely event that it comes into contact with the eyes or skin, wash it off immediately with a large amount of water, and seek immediate medical attention.

If a vehicle fire occurs, extinguish it with a Class D powder-type fire extinguisher.

Toyota recommends having maintenance and repairs for your bZ performed by an authorized Toyota dealership. To locate your nearest authorized Toyota dealership, contact the Toyota Brand Engagement Center at (800) 331-4331 or log on to [www.toyota.com](http://www.toyota.com).

# WELCOME TO THE TOYOTA FAMILY

---

**T**hank you for purchasing a Toyota vehicle. We know you have many options when considering which vehicle to buy, and we appreciate your decision to select Toyota.

We want you to enjoy owning your Toyota as much as you enjoy driving it. This booklet is designed to help. Here you'll find information on Toyota's warranty coverage, maintenance recommendations for your vehicle and your owner's rights. There are two easy-to-follow sections: one for warranty and one for maintenance. The tab on the side of each page identifies the section you are in.

For more information about our vehicles, our company or the products and services available for your vehicle, please visit Toyota's official website, [www.toyota.com](http://www.toyota.com).

We wish you many miles of safe and pleasurable driving, and we look forward to serving you in the years ahead. Welcome to the Toyota family!



**TOYOTA**

# TABLE OF CONTENTS

---

## INTRODUCTION

Satisfaction Down the Road	4
If You Need Assistance	5
The Immobilizer Key	7
Transportation Assistance	9

## WARRANTY INFORMATION

### YOUR WARRANTIES IN DETAIL

General Warranty Provisions	10
New Vehicle Limited Warranty	13
California Zero-Emission Warranty	17
Tire Limited Warranty	21

### YOUR RESPONSIBILITIES

Operation and Maintenance	22
Obtaining Warranty Service	24

## MAINTENANCE INFORMATION

### INTRODUCTION

The Importance of Scheduled Maintenance _____	26
Maintaining Your Warranty _____	27

### MAINTENANCE CHARTS

Using the Maintenance Charts _____	28
Maintenance Charts _____	30
Explanation of Maintenance Items _____	33
Vehicle Identification _____	36

### FIND IT ONLINE

To update your contact information and vehicle ownership status, please visit [www.toyota.com/recall/update-info-toyota](http://www.toyota.com/recall/update-info-toyota). Your vehicle's VIN will be required to start the update process.

You may also enroll to receive the following useful information and benefits at [toyota.com/owners](http://toyota.com/owners):

- Access to Owner's Manuals and Maintenance Guides
- View Your Vehicle's Service History
- Explore How-to videos and more



**Owners**

## SATISFACTION DOWN THE ROAD

---

**A**t Toyota, our top priority is always our customers. We know your Toyota is an important part of your life and something you depend on every day. That's why we're dedicated to building products of the highest quality and reliability.

Our excellent warranty coverage is evidence that we stand behind the quality of our vehicles. We're confident — as you should be — that your Toyota will provide you with many years of enjoyable driving.

To further demonstrate our commitment to our customers' satisfaction, occasionally we may establish a special policy adjustment to pay for specific repairs that are no longer covered by warranty. When we establish such a policy adjustment, we mail details to all applicable owners we have on record.

To provide you with added protection against unexpected service costs, we offer Toyota Financial Services vehicle service agreements and Toyota Auto Care and Toyota Care Plus prepaid maintenance programs. Each offers plans to meet a wide variety of needs. Your dealership can help you select the plan that's best for you.

Our goal is for every Toyota customer to enjoy outstanding quality, dependability and peace of mind throughout their ownership experience. We want you to be a satisfied member of the Toyota family for many miles to come.

This booklet describes the terms of Toyota warranty coverage as well as general owner responsibilities. The scheduled maintenance section describes your vehicle's maintenance requirements. Be sure to review this information carefully, since proper maintenance is required to ensure that warranty coverage remains intact.

All information in this booklet is the latest available at the time of publication and is subject to change without notice.

**B**oth Toyota and your Toyota dealer are dedicated to serving your automotive needs. Your complete satisfaction is our first priority. Should you have a problem or concern — either during or after the warranty period — please take the following steps to ensure the quickest possible response:

### Step 1

Discuss the situation with a dealership manager, such as the service manager or customer relations manager. In most cases, a satisfactory solution can be reached at this step.

### Step 2

If the dealership does not address your concern to your satisfaction, call the Toyota Brand Engagement Center at **(800) 331-4331**.

Please have the following information ready when you call:

- Your Toyota's vehicle identification number (located on the driver's side corner of the dashboard, under the windshield)
- Current mileage on your vehicle
- Name of your Toyota dealership

A Toyota customer relations representative will assist you in working with the dealership to find a satisfactory solution.

### Step 3

If your concern has still not been resolved to your satisfaction, Toyota offers additional assistance through the Dispute Settlement Program, a dispute resolution program administered by the National Center for Dispute Settlement. The purpose of the Dispute Settlement Program is to resolve disputes through arbitration — a process by which two parties authorize an independent third party to hear and resolve a dispute. The program is informal and free of charge. To request that your case be reviewed through the program, complete the customer claim form in the *Owner's Warranty Rights Notification* booklet and mail it to:

National Center for Dispute Settlement  
P.O. Box 515284  
Dallas, TX 75251-5284

To initiate arbitration, you must complete an NCDS customer claim form and mail it to NCDS. To request a form, call NCDS at (800) 777-8119 or obtain a copy at [www.ncdsusa.org](http://www.ncdsusa.org). When you call, please have your vehicle identification number, the current mileage on your Toyota and the names of your selling and servicing dealerships.

## IF YOU NEED ASSISTANCE

---

**California residents:** Toyota offers assistance through an informal dispute settlement program called the California Dispute Settlement Program (CDSP). A brochure about the program is found in your glove box. For additional information, call the Toyota Customer Experience Center at (800) 331-4331. You may also contact the CDSP directly at (888) 300-6237. Failure to use the CDSP may affect your rights and remedies under California's "Lemon Laws."

This information about the Dispute Settlement Programs is correct as of the date of printing. However, the programs may be changed without notice. For the most current information about the programs, call the Toyota Brand Engagement Center at (800) 331-4331.

### THE NEW WORLD OF ANTI-THEFT TECHNOLOGY

This Toyota vehicle may be equipped with an electronic “immobilizer” anti-theft system. When the key is inserted into the ignition switch, it transmits an electronic code to an immobilizer computer. The vehicle will only power on if the code in the key matches the code in the immobilizer.

If the code does not match, the immobilizer disables the ignition. While an exact physical copy of the key will open the door and allow retrieval of items locked in the vehicle, it won't start the vehicle unless the key has the same code as the immobilizer.

### SECURITY

For security purposes, access to key codes and service procedures for electronically registering replacement keys is restricted. Only a Toyota dealer or certain bonded/registered independent locksmiths can generate replacement keys.

# THE IMMOBILIZER KEY

---

## REPLACING THE KEY

Upon purchase, each vehicle should have two master keys and an aluminum tag with a key code imprinted on it.

To generate a fully functional replacement key (one that will both open the doors and power the vehicle on), one of the master keys is required. To make a key that will open the door for retrieval of items locked inside the vehicle, the aluminum key-code tag can be used. If a master key or the aluminum key-code tag is not available, a Toyota dealer or certain registered locksmiths can obtain the key code from a restricted-access database. These businesses can also access a service utility to reprogram the immobilizer if all registered master keys have been lost. If a Toyota dealer is not available, please refer to [www.aloa.org](http://www.aloa.org) to find a bonded/registered locksmith who performs high-security key service.

## KEEPING THE KEY SAFE

Replacing an immobilizer key may be costly. It is advisable to keep a spare master key and the aluminum key-code tag in a safe place. If you record the key code in more than one place, do not record it in a way that can be easily identified and associated with the vehicle. It is wise to keep a copy of the key code outside of the vehicle.

If the vehicle was delivered with less than two keys and the aluminum key-code tag, consider having the Toyota dealer or a qualified independent automotive locksmith make a duplicate key before you need it.

**W**e realize that your confidence in the quality and reliability of our products was a key factor in your decision to buy a Toyota. We also know how disruptive the loss of transportation can be to your daily routine. That's why we're pleased to offer you the benefits of our Transportation Assistance Policy.

Under this policy, you are eligible for transportation assistance if your Toyota must be kept overnight for warranty-covered repairs. The policy applies when your vehicle must be kept overnight for any of the following reasons:

- The warranty repairs will take longer than one day to complete.
- The warrantable condition requires extensive diagnosis.
- The parts needed for the warranty repairs are not readily available and your vehicle is inoperative or unsafe to drive.

The policy does not apply when warranty repairs can be completed in one day but the vehicle must be kept overnight due to dealer or owner scheduling conflicts.

The Transportation Assistance Policy applies for the duration of the New Vehicle Limited Warranty. The policy applies to all 2026 model-year Toyotas sold and serviced by authorized Toyota dealerships in the mainland United States and Alaska.

For further details, please consult your Toyota dealer.

# GENERAL WARRANTY PROVISIONS

**Important:** You must use the Dispute Settlement Program (or, in California, the CDSP) before seeking remedies through a court action pursuant to the Magnuson-Moss Warranty Act (the “Act”). However, if you choose to pursue rights and remedies not created by the Act, you are not required to use the Dispute Settlement Program (CDSP). You may also be required to use the Dispute Settlement Program or CDSP before seeking remedies under the “Lemon Laws” of your state. Please check this booklet and the appropriate page of the *Owner’s Warranty Rights Notification* booklet (found in your glove box) for additional information and the requirements applicable to your state.

## Who Is the Warrantor

The warrantor for these limited warranties is Toyota Motor Sales, U.S.A., Inc. (“Toyota”), a California corporation, P.O. Box 259001, Plano, Texas 75025-9001.

## Which Vehicles Are Covered

These warranties apply to all 2026 model-year bZ vehicles distributed by Toyota that are originally sold by an authorized dealer in the United States and normally operated or touring in the United States, U.S. territories or Canada. Warranty coverage is automatically transferred at no cost to subsequent vehicle owners.

## Multiple Warranty Conditions

This booklet contains warranty terms and conditions that may vary depending on the part covered. A warranty for specific parts or systems, such as Powertrain Warranty or Electric Vehicle Drive Components, is governed by the coverage set forth in that warranty as well as the General Warranty Provisions.

## When Warranty Begins

The warranty period begins on the vehicle’s in-service date, which is the first date the vehicle is either delivered to an ultimate purchaser, leased or used as a company car or demonstrator.

## Repairs Made at No Charge

Repairs and adjustments covered by these warranties are made at no charge for parts and labor.

## Parts Replacement

Any needed parts replacement will be made using new or remanufactured parts. The decision whether a part should be repaired or replaced will be made by the servicing Toyota dealership and/or Toyota. Parts scheduled to be replaced as required maintenance are warranted until their first replacement only.

## Informal Dispute Settlement Program

Toyota offers assistance through an informal dispute settlement program called the **Dispute Settlement Program**. This program is administered by an independent third party:

National Center for Dispute Settlement  
P.O. Box 515284  
Dallas, TX 75251-5284

Further information about this program can be found in this booklet and the *Owner's Warranty Rights Notification* booklet.

**California residents:** Toyota offers assistance through an informal dispute settlement program called the California Dispute Settlement Program (CDSP). A brochure about the program is found in your glove box. For additional information, call the Toyota Brand Engagement Center at (800) 331-4331. You may also contact the CDSP directly at (888) 300-6237. Failure to use the CDSP may affect your rights and remedies under California's "Lemon Laws."

## Limitations

The performance of necessary repairs and adjustments is the exclusive remedy under these warranties or any implied warranties. Toyota does not authorize any person to create for it any other obligation or liability in connection with this vehicle.

**Any implied warranty of merchantability or fitness for a particular purpose is limited to the duration of these written warranties.** Some states do not allow restrictions on how long an implied warranty lasts, so this limitation may not apply to you.


## Your Rights Under State Law

These warranties give you specific legal rights. You may also have other rights that vary from state to state.


# GENERAL WARRANTY PROVISIONS

## WARRANTY COVERAGE AT A GLANCE

### New Vehicle Limited Warranty



### California Zero-Emission Warranty



California<sup>2</sup>

<sup>1</sup> Specific components may have longer coverage under terms of the Powertrain Warranty.

<sup>2</sup> Also applies to Connecticut, Delaware, Maine, Maryland, Massachusetts, Minnesota, Nevada, New Jersey, New York, Oregon, Pennsylvania, Vermont, Virginia and Washington vehicles equipped with a California Certified Emission Control System.

## WHAT IS COVERED AND HOW LONG

### Basic Warranty

This warranty covers repairs and adjustments needed to correct defects in materials or workmanship of any part supplied by Toyota, subject to the exceptions indicated under “What Is Not Covered” on pages 14–16.

Coverage is for 3 years or 36,000 miles from the vehicle's in service date, whichever occurs first, with the exception of air conditioning recharge, wheel alignment and wheel balancing, which are covered for 12 months or 12,000 miles, whichever occurs first.

### Electric Vehicle Drive Components Warranty

This warranty covers repairs needed to correct defects in materials or workmanship of the components listed here and supplied by Toyota, subject to the exceptions indicated under “What is not covered” on pages 14–16.

- Traction Battery
  - Below 70% of original capacity
- Transaxle
- Inverter with Converter

The Electrical Drive Component Warranty is in effect for 8 years or 100,000 miles from the vehicle's in service date, whichever occurs first.

### Powertrain Warranty

This warranty covers repairs needed to correct defects in materials or workmanship of any component listed below and supplied by Toyota, subject to the exceptions indicated under “What Is Not Covered” on pages 14–16.

The Powertrain Warranty is in effect for 5 years or 60,000 miles from the vehicle's in service date, whichever occurs first.

#### EV Control ECU

#### Front-Wheel-Drive System

Final drive housing and all internal parts, axle shafts, drive shafts, constant velocity joints, front hub and bearings, seals and gaskets.

#### Rear-Wheel-Drive System

Axle housing and all internal parts, propeller shafts, U-joints, axle shafts, drive shafts, bearings, supports, seals and gaskets.

### Restraint Systems Warranty

This warranty covers repairs needed to correct defects in materials or workmanship of any seatbelt or airbag system supplied by Toyota, subject to the exceptions indicated under “What Is Not Covered” on pages 14–16.

Coverage is for 60 months or 60,000 miles, whichever occurs first.

For vehicles sold and registered in the state of Kansas, the warranty for seatbelts and related components is 10 years, regardless of mileage.

# NEW VEHICLE LIMITED WARRANTY

## Corrosion Perforation Warranty

This warranty covers repair or replacement of any original body panel that develops perforation from corrosion (rust-through), subject to the exceptions indicated under “What Is Not Covered” on pages 14–16.

Coverage is for 60 months, regardless of mileage.

For information on how to protect your vehicle from corrosion, refer to sections related to maintenance and care in the *Owner’s Manual*.

## Towing

When your vehicle is inoperable due to failure of a warranted part, towing service to the nearest authorized Toyota dealership is covered.

## WHAT IS NOT COVERED

This warranty does not cover damage or failures resulting directly from any of the following:

- Neglecting to follow appropriate vehicle usage, incorrect charging procedure or use of an incompatible charging device that results in a battery capacity reduction
- Fire, accidents or theft
- Abuse or negligence
- Misuse — for example, racing or overloading
- Improper repairs
- Alteration or tampering, including installation of non-Genuine Toyota Accessories

- Lack of or improper maintenance, including use of fluids other than those specified in the *Owner’s Manual*
- Installation of parts that are not Toyota Genuine Parts
- Airborne chemicals, tree sap, road debris (including stone chips), rail dust, salt, hail, floods, wind storms, lightning and other environmental conditions
- Water contamination
- Participation in High Performance Driving Events (HPDE), including events sponsored by Toyota or affiliates, or recreational track/off-highway use does not specifically limit/exclude warranty coverage under the New Vehicle Limited Warranty. However, damage to the vehicle or components that occurs as a result of abuse or misuse of the vehicle while participating in an HPDE/track event, or off-road use is NOT covered.
- Participating in competitive motorsports events may involve conditions that could exceed the expected and reasonable operation range or durability of some vehicle components. Wear or damage from such use is NOT covered as part of the New Vehicle Limited Warranty.

**This warranty also does not cover the following:**

## Tires

Tires are covered by a separate warranty provided by the tire manufacturer. See page 21.

## Normal Wear and Tear

Noise, vibration, cosmetic conditions and other deterioration caused by normal wear and tear.

## Gradual Capacity Reduction of Traction Battery (Lithium-ion Battery)

Lithium-ion battery capacity (the ability to hold a charge) gradually reduces with time and use. This is a natural characteristic of lithium-ion batteries. The extent at which capacity is reduced changes drastically depending on the environment (ambient temperature, etc.) and usage conditions such as how the vehicle is driven and how the lithium-ion battery is charged. Reduction of the lithium-ion battery capacity by 30 percent or less is considered normal and not covered under warranty. In order to lessen the possibility of capacity reduction, follow the directions listed in the *Owner's Manual*.

The driving range estimates are not a measure of battery capacity. Additional factors such as environmental conditions will influence the driving range on your display monitor. As a result, your display monitor is not an indicator of battery capacity.

The traction battery warranty replacement may not restore the vehicle to an “as new” condition. Taking into consideration other factors, including the age and mileage of the vehicle, Toyota will ensure that the energy

capacity of the replacement battery is at least equal to that of the original battery before the failure occurred.

The measurement method used to determine battery capacity, and the decision of whether to repair, replace, or provide reconditioned/re-manufactured parts, and the condition of any such replaced, recondition/re-manufactured parts, are at the sole discretion of Toyota.

## Maintenance Expense

Normal maintenance services such as:

- Replacement of fluids and filters
- Lubrication
- Cleaning and polishing
- Replacement of worn wiper blade, and brake pads/linings

## Vehicles with Altered Odometer

Failure of a vehicle on which the odometer has been altered so that actual vehicle mileage cannot be readily determined.

## Salvage or Total-Loss Vehicles

Any vehicle that has ever been branded as salvage, total loss, true mileage unknown or similar title under any state's law or has ever been declared a “total loss” or equivalent by a financial institution or insurer, such as by payment for a claim in lieu of repairs because the cost of repairs exceeded the cash value of the vehicle. This exclusion does not apply to any open Safety Recalls/SSCs/LSCs.

# NEW VEHICLE LIMITED WARRANTY

---

## Software Updates

Software updates made available for download by owners directly, either on a complimentary basis or for a fee, as determined by Toyota in its sole discretion.

## Incidental Damages

Incidental or consequential damages associated with a vehicle failure. Such damages include but are not limited to inconvenience; the cost of transportation, telephone calls and lodging; the loss of personal or commercial property; and the loss of pay or revenue.

### **Disclaimer of Extra Expenses and Damages**

The performance of necessary repairs and adjustments is the exclusive remedy under this warranty or any implied warranty. Toyota does not authorize any person to create for it any other obligation or liability in connection with this vehicle. Toyota shall not be liable for incidental or consequential damages resulting from breach of this written warranty or any implied warranty. Any implied warranty of merchantability or fitness for a particular purpose is limited to the duration of this written warranty, except in states where this limitation is not allowed.

## DISPUTE RESOLUTION

If a dispute arises regarding your warranty coverage, please follow the steps described under “If You Need Assistance” on page 5. Please note that you must use the Dispute Settlement Program (or, in California, the CDSP) before seeking remedies through a court action pursuant to the Magnuson-Moss Warranty Act. You may also be required to use the Dispute Settlement Program or CDSP before seeking remedies under the “Lemon Laws” of your state. Please check the appropriate page of the *Owner's Warranty Rights Notification* booklet (located in your glove box) for the requirements applicable to your state.

## YOUR WARRANTY RIGHTS AND OBLIGATIONS

Vehicles that are registered and operated in California or any state that adopts California emission warranty provisions are covered by this warranty. Currently, Connecticut, Delaware, Maine, Maryland, Massachusetts, Minnesota, Nevada, New Jersey, New York, Oregon, Pennsylvania, Vermont, Virginia and Washington are the other states to which this warranty applies.

The California Air Resources Board (CARB) and Toyota are pleased to explain the zero-emission vehicle warranty on your 2026 vehicle. In California, new zero-emission vehicles must be designed, and built in accordance with State regulations. CARB regulations require that Toyota must warranty the propulsion related parts on our vehicle for the time periods indicated on the next page, provided there has been no abuse, neglect or improper maintenance of your vehicle.

Where a warrantable condition exists, Toyota will repair your vehicle at no cost to you, including diagnosis, parts and labor.

# CALIFORNIA ZERO-EMISSION WARRANTY

---

## MANUFACTURER'S WARRANTY COVERAGE

- 1) For three years or 50,000 miles, whichever occurs first:
  - If any propulsion-related part on your vehicle is defective, the part will be repaired or replaced by Toyota. This is your SHORT-TERM Propulsion related parts DEFECT WARRANTY. Specific components may have longer coverage under the terms of the Powertrain Warranty.
- 2) For seven years or 70,000 miles, whichever occurs first:
  - If any propulsion-related part listed on pages 19–20 is defective, the part will be repaired or replaced by Toyota. This is your LONG-TERM propulsion related parts DEFECT WARRANTY.

## OWNER'S WARRANTY RESPONSIBILITIES

You are responsible for performance of the required maintenance indicated in the *Owner's Manual* and this booklet. Toyota recommends that you retain all receipts covering maintenance on your vehicle, but Toyota cannot deny warranty coverage solely for the lack of receipts or your failure to ensure the performance of all scheduled maintenance.

You are responsible for presenting your vehicle to a Toyota dealership as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

You should also be aware that Toyota may deny you warranty coverage if your vehicle or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact the Toyota Brand Engagement Center at (800) 331-4331 or the California Air Resources Board, 4001 Iowa Avenue, Riverside, CA 92507. Email: [helpline@arb.ca.gov](mailto:helpline@arb.ca.gov)

# CALIFORNIA ZERO-EMISSION WARRANTY

## CALIFORNIA LONG-TERM PROPULSION RELATED PARTS

The parts listed here are covered for seven years or 70,000 miles\* from the vehicle's in-service date, whichever occurs first.

- Acceleration sensor (airbag sensor)
- Air conditioner tube & accessory assembly
- Air duct subassembly
- Back window glass spacer
- Back window outside lower moulding
- Battery
- BEV supply battery assembly
- Bolt for transaxle assembly with motor & inverter
- Bolt with washer for transaxle assembly with motor & inverter
- Brake actuator
- Brake master cylinder for HV
- Breather plug for transaxle assembly with motor & inverter
- Charge inlet box assembly
- Clip for heater to foot duct
- Clip for heater to register duct
- Combination meter assembly
- Compressor assembly with motor
- Compressor mounting bracket
- Cooler thermistor
- Cooling unit parts
- DC BEV charger cable subassembly
- Defroster lower nozzle assembly
- Defroster nozzle assembly
- Digital key computer assembly
- Discharge hose
- Drive shaft snap ring
- Driver monitor computer assembly
- Electric heater subassembly
- Electric vehicle charger cable assembly
- Electric vehicle control computer
- Electric vehicle control computer assembly
- Electric vehicle emergency connector assembly
- Fan assembly with motor
- Flange bolt for transaxle assembly with motor & inverter
- Flange nut for traction battery busbar block No.2
- Front axle inboard joint boot
- Front drive shaft assembly
- Front drive shaft inboard joint boot kit
- Headlamp computer subassembly No. 1
- Headlamp LED unit subassembly
- Headlamp main computer subassembly
- Heat exchanger assembly
- Heat exchanger unit subassembly
- Heat management computer assembly

WARRANTY

\*Certain components on the above parts list may have longer coverage under the New Vehicle Limited Warranty. Additionally, propulsion related parts not included in the above list have a coverage of 3 years or 50,000 miles whichever occurs first from the vehicle's in-service date.

# CALIFORNIA ZERO-EMISSION WARRANTY

---

## WARRANTY

- Heater & accessory assembly
- Heater cover
- Heater grommet
- Heater to foot duct
- Heater to register duct
- Immobiliser code computer
- Inverter cooling tube assembly No.1
- Light control LED computer
- Millimeter wave radar sensor assembly
- Motor compartment main wire
- Motor cooling cooler
- Multiplex network door computer
- Multiplex network master switch assembly
- O-ring for transaxle assembly with motor & inverter
- Parking assist computer
- Plugin & wireless charging computer assembly
- Position control computer assembly
- Quick heater & accessory assembly
- Radiator assembly
- Radiator with air duct shutter assembly
- Rear axle hub & brg with ABS sensor
- Rear drive shaft assembly right hand
- Rear drive shaft boot clamp
- Shift control actuator assembly
- Side defroster nozzle duct
- Sliding roof control computer
- Smart key supply computer assembly
- Straight screw plug with head for transaxle assembly with motor & inverter
- Traction bat voltage detctr wire
- Traction battery busbar lock
- Traction battery cable No.3
- Traction battery conn housing No.2
- Traction battery wire cover
- Traction battery wire
- Transaxle assembly with motor & inverter
- Type T-oil seal for transaxle assembly with motor & inverter
- Water control valve
- Water pump assembly with motor
- Wiring harness clamp

## OBTAINING WARRANTY SERVICE

All tires supplied as original equipment on new Toyota vehicles are warranted by the individual tire manufacturer only, and not Toyota. Coverages by individual tire manufacturers may vary.

The terms of the tire manufacturers' warranty can be obtained from the tire manufacturers' websites. If you wish to obtain a hard copy of the tire warranty terms, please contact the tire manufacturer directly.

## ORIGINAL EQUIPMENT TIRE MANUFACTURERS

**BF Goodrich/Michelin North America**  
P.O. Box 19001  
Greenville, SC 29062  
BF Goodrich: (877) 788-8899  
Michelin: (800) 847-3435  
[www.bfgoodrichtires.com](http://www.bfgoodrichtires.com)  
[www.michelinman.com](http://www.michelinman.com)

**Bridgestone/Firestone**  
200 4th Avenue South  
Nashville, TN 37201  
Bridgestone: (800) 847-3272  
Firestone: (800) 356-4644  
[www.bridgestone.com](http://www.bridgestone.com)  
[www.firestonetire.com](http://www.firestonetire.com)

**Continental Tire of North America**  
1800 Continental Boulevard  
Charlotte, NC 28273  
(800) 847-3349  
[www.continentaltire.com](http://www.continentaltire.com)

**Dunlop Tires/Goodyear Tire and Rubber Co.**  
1144 East Market Street  
Akron, OH 44316  
(800) 321-2136  
[www.dunloptires.com](http://www.dunloptires.com)  
[www.goodyear.com](http://www.goodyear.com)

**Falken Tire Corporation**  
8656 Haven Avenue  
Rancho Cucamonga, CA 91730  
(800) 723-2553  
[www.falkentire.com](http://www.falkentire.com)

**Hankook Tire America Corporation**  
1450 Valley Road  
Wayne, NJ 07470  
(800) 426-5665  
[www.hankooktire.com](http://www.hankooktire.com)

**Kenda Tire**  
7095 Americana Parkway  
Reynoldsburg, OH 43068  
(866) 536-3287  
[www.kendatire.com](http://www.kendatire.com)

**Maxxis International – USA**  
545 Old Peachtree Road  
Suwanee, GA 30024  
(800) 462-9947  
[www.maxxis.com](http://www.maxxis.com)

**Nitto Tire U.S.A. Inc.**  
P.O. Box 6064  
Cypress, CA 90630  
(888) 529-8200  
[www.nittotire.com](http://www.nittotire.com)

**Pirelli Tire LLC**  
100 Pirelli Drive  
Rome, GA 30161  
(800) 747-3554  
[www.pirelli.com](http://www.pirelli.com)

**Toyo Tire U.S.A Corporation**  
P.O. Box 6052  
Cypress, CA 90630  
(800) 442-8696  
[www.toyotires.com](http://www.toyotires.com)

**Yokohama Tire Corporation**  
1 MacArthur Place, Suite 800  
Santa Ana, CA 92707  
(800) 722-9888  
[www.yokohamatire.com](http://www.yokohamatire.com)

## GENERAL INFORMATION

You are responsible for ensuring that your Toyota is operated and maintained according to the instructions in the *Owner's Manual* and this booklet.

You should keep detailed records of vehicle maintenance, since under some circumstances they may be required for warranty coverage. These records should include date of service, mileage at time of service and a description of service performed and/or parts installed. For your convenience, a maintenance chart is included in this booklet. If you sell your vehicle, you should give your maintenance records to the new owner.

Toyota will not deny a warranty claim solely because you do not have records to show that you maintained your vehicle. However, damage or failure caused by lack of proper maintenance is not covered under warranty.

## WHERE TO GO FOR MAINTENANCE

You may have maintenance performed on your vehicle by any qualified person or facility. However, Toyota recommends having maintenance performed by an authorized Toyota dealership.

Toyota dealership technicians are specially trained to maintain and repair Toyota vehicles. They stay current on the latest service information through Toyota technical bulletins, service publications and training courses. Many are also certified through the Toyota Certification Program, which involves a series of rigorous written examinations. Feel free to ask any Toyota dealership to show you their technicians' credentials.

You can be confident you're getting the best possible service for your vehicle when you take it to a Toyota dealership.

## REPLACEMENT PARTS

Warranty coverage is not dependent upon the use of any particular brand of replacement parts. However, Toyota recommends using only Toyota Genuine Parts when you need to replace a part on your vehicle. Like all Toyota products, Toyota Genuine Parts are built to the highest standards of quality, durability and performance. They are also designed to fit your vehicle's exact specifications.

Your Toyota dealership maintains an extensive inventory of Toyota Genuine Parts to meet your vehicle service needs. And because it is linked electronically to Toyota's Parts Distribution Centers, the dealership has quick access to any parts it may not have in stock.

Toyota Genuine Parts are covered by their own warranty (see your dealer for details) or the remainder of any applicable New Vehicle Limited Warranty, whichever is longer. **Parts that are not Toyota Genuine Parts, or any damage or failures resulting from their use, are not covered by any Toyota warranty.**

## BY GEOGRAPHIC REGION

### In the United States, U.S. Territories, Canada and Mexico

To obtain warranty service in the United States, U.S. territories, Canada or Mexico, take your vehicle to an authorized Toyota dealership. If your vehicle cannot be driven, contact your nearest Toyota dealership for towing assistance. You do not have to pay for towing to the nearest Toyota dealership if your vehicle is inoperable due to failure of a warranted part.

### Outside the United States, U.S. Territories, Canada and Mexico

If you are using your vehicle outside the United States, U.S. territories, Canada and Mexico and need warranty service, contact a local Toyota dealership. Please note, however, that your vehicle may not be repaired free of charge because the local Toyota distributor may have no obligation to provide warranty service for your vehicle, and/or your vehicle may not comply with local regulatory or environmental requirements.

## EMERGENCY REPAIRS

If your vehicle is inoperable or unsafe to drive and there is no Toyota dealership reasonably available to make repairs, you may perform the repairs yourself or have them performed by another automotive service provider. Toyota will reimburse you for any of the repairs that are covered by warranty. To receive reimbursement, present to an authorized Toyota dealership your paid repair invoices and any parts that were removed from the vehicle. You will be reimbursed for warranted parts at the manufacturer's suggested retail price and warranted labor at a geographically appropriate hourly rate multiplied by Toyota's recommended time allowance for the repair.

If your vehicle requires emergency repair, Toyota assumes no liability for subsequent failures caused by improper repairs or the use of parts that are not Toyota Genuine Parts unless you have the vehicle properly repaired in a timely manner. To ensure that warranty coverage remains intact, have your vehicle inspected by an authorized Toyota dealership as soon as possible after an emergency repair.



# THE IMPORTANCE OF SCHEDULED MAINTENANCE

---

**R**egular maintenance is essential to obtaining the highest level of performance, safety and reliability from your Toyota. It can also increase your vehicle's resale value. The following pages are designed to help you make sure your vehicle receives proper and timely maintenance. Along with other important information related to vehicle service, you'll find factory-recommended maintenance guidelines.

In addition to scheduled maintenance, your vehicle requires ongoing general maintenance such as fluid checks and visual inspections. These procedures are explained in the "Maintenance and Care" section of the *Owner's Manual*. Be sure to perform these procedures regularly to ensure the most trouble-free operation of your vehicle.

With proper maintenance and care, your vehicle will last longer and deliver more dependable, economical performance. Follow this booklet's recommendations and you'll enjoy maximum reliability and peace of mind from your Toyota for many years to come.



**TOYOTA**

## IMPORTANT MAINTENANCE INFORMATION

### Maintenance Records

Maintaining your vehicle according to the recommendations in this booklet is required to ensure that your warranty coverage remains intact. You should keep detailed records of vehicle maintenance, including date of service, mileage at time of service and a description of service and/or parts installation performed. The scheduled maintenance chart in this booklet can help you document this information. If you sell your vehicle, be sure to give your maintenance records to the new owner.

Toyota will not deny a warranty claim solely because you do not have records to show that you maintained your vehicle. However, damage or failure caused by lack of proper maintenance is not covered under warranty.

### Maintenance Providers

Maintenance and repair services may be performed by you or by any automotive service provider you choose. Toyota will not deny a warranty claim solely because you used a service provider other than a Toyota dealership for maintenance and repairs. However, damage or failure caused by improper maintenance or repairs is not covered under warranty.

### Dealer-Recommended Maintenance

Your dealer may recommend more frequent maintenance intervals or more maintenance services than those listed in the scheduled maintenance chart. These additional services are not required to maintain your warranty coverage. Ask your dealer to explain any recommended maintenance not included in the scheduled maintenance chart.

For a complete description of Toyota warranty coverages, see the Warranty Information portion of this booklet.

# USING THE MAINTENANCE CHARTS

---

**R**egular maintenance is essential to obtaining the highest level of performance, safety and reliability from your Toyota. It can also increase your vehicle's resale value. This booklet presents Toyota's maintenance recommendations in convenient checklists, so you can easily see what type of maintenance your vehicle needs and document that the work was performed.

To ensure that your vehicle receives first-quality service and parts, Toyota recommends having maintenance performed by an authorized Toyota dealership. Toyota dealership technicians are experts on Toyota vehicles, and they use Toyota Genuine Parts designed to your vehicle's exact specifications. When you go to a Toyota dealership, you can be confident that they will use Toyota Genuine Parts and have Toyota-trained technicians.

## Miles or Months?

Toyota recommends obtaining scheduled maintenance for your vehicle every 5,000 miles or six months, whichever comes first.

For example:

- If you drive 5,000 miles in less than six months, you should obtain maintenance at **5,000 miles** — don't wait until six months.
- If at six months you have driven less than 5,000 miles, you should obtain maintenance at **six months** — don't wait until 5,000 miles.

Be sure to keep an eye on your mileage so that you obtain maintenance when recommended. If you are a low-mileage driver, mark your calendar to remind yourself to obtain maintenance every six months.

## Special Operating Conditions

In addition to standard maintenance items, the maintenance chart indicates services that should be performed on vehicles that are driven under especially demanding conditions. These “special operating conditions” and their required maintenance items are clearly indicated in each chart.

### NOTE:

You should perform these additional maintenance services only if the **majority** of your driving is done under the special operating conditions indicated. If you only **occasionally** drive under these circumstances, it is not necessary to perform the additional services.

## Additional Maintenance

In addition to scheduled maintenance, your Toyota requires ongoing general maintenance, such as fluid checks and visual inspections. These procedures are explained in the “Maintenance and Care” section of the *Owner's Manual*. Be sure to perform these procedures regularly to ensure the most trouble-free operation of your vehicle.

## SuperChrome and Alloy Wheel Care

If you purchased Genuine Toyota Accessory SuperChrome or Aluminum Alloy Wheels, follow these cleaning guidelines to maintain the appearance of your wheels:

- If wheels are hot, wait for them to cool before washing.
- Use a soft sponge or cotton cloth to apply the same mild car-wash soap as used for the vehicle body. Quickly rinse off with water. Use a soft cloth to apply the same car wax as used for the vehicle body.
- DO NOT USE: Any kind of chemical-based cleaners, alcohol, solvents, gasoline, steam cleaners, scouring pads, wire brushes or coarse abrasives to clean your wheels.

# MAINTENANCE CHART

thousand mile interval

Recommended Service	5	10	15	20	25	30	35	40	45	50
All Fluid Levels <sup>(1)</sup>	I	I	I	I	I	I	I	I	I	I
Ball Joints and Dust Covers			I			I			I	
Brake Lines and Hoses			I			I			I	
Brake Linings/Drums and Brake Pads/Discs <sup>(2)</sup>	I	I	I	I	I	I	I	I	I	I
Cabin Air Filter <sup>(3)</sup>						R				
Drive Shaft Boots			I			I			I	
Driver's Floor Mat for Proper Installation	I	I	I	I	I	I	I	I	I	I
e-Transaxle Fluid						I				
Heater Coolant			I			I			I	
Radiator/Condenser/Intercooler (if applicable)			I			I			I	
Rotate Tires	P	P	P	P	P	P	P	P	P	P
Steering Gear			I			I			I	
Steering Linkage and Boots			I			I			I	
Traction Battery Coolant			I			I			I	
Wiper Blades	I	I	I	I	I	I	I	I	I	I

thousand mile interval

Special Operating Conditions	5	10	15	20	25	30	35	40	45	50
Ball Joints and Dust Covers <sup>(4)</sup>	I	I		I	I		I	I		I
Drive Shaft Boots <sup>(4)</sup>	I	I		I	I		I	I		I
Nuts and Bolts on Chassis and Body <sup>(4,5)</sup>	T	T	T	T	T	T	T	T	T	T
Steering Linkage and Boots <sup>(4)</sup>	I	I		I	I		I	I		I

I: Inspect, P: Perform, R: Replace, T: Torque

<sup>1</sup> Inspect sealed transmissions, transfer cases, and differentials for signs of leakage. If any leakage from a sealed component is suspected, it is recommended that you have the sealed component inspected by a Toyota dealer. Inspect power steering fluid (if equipped) and brake fluid level/condition. Inspect engine and inverter (if equipped) coolant level/condition/freezing point. Your dealer may recommend services (Dealer-Recommended Maintenance) based on inspection results.

<sup>2</sup> Visually inspect every 5,000 miles, and inspect thickness and disc runout every 30,000 miles.

<sup>3</sup> Driving in conditions such as heavy traffic areas or urban areas or dusty areas or desert areas or dirt roads may shorten air conditioning filter's life. Therefore, it may need to be replaced earlier.

<sup>4</sup> Perform this service if you drive on dirt or dusty roads.

<sup>5</sup> Perform this service if you drive while towing, using a car-top carrier, or heavy vehicle loading. Not all vehicles are designed for towing. Refer to your *Owner's Manual* for details.

# MAINTENANCE CHART

thousand mile interval

Recommended Service	55	60	65	70	75	80	85	90	95	100
All Fluid Levels <sup>(1)</sup>	I	I	I	I	I	I	I	I	I	I
Ball Joints and Dust Covers		I			I			I		
Brake Lines and Hoses		I			I			I		
Brake Linings/Drums and Brake Pads/Disks <sup>(2)</sup>	I	I	I	I	I	I	I	I	I	I
Cabin Air Filter <sup>(3)</sup>		R						R		
Drive Shaft Boots		I			I			I		
Driver's Floor Mat for Proper Installation	I	I	I	I	I	I	I	I	I	I
e-Transaxle Fluid		I						I		
Fill Air Conditioner Refrigerant <sup>(4)</sup>						P				
Heater Coolant		I			I			I		
Radiator/Condenser/Intercooler (if applicable)		I			I			I		
Rotate Tires	P	P	P	P	P	P	P	P	P	P
Steering Gear		I			I			I		
Steering Linkage and Boots		I			I			I		
Traction Battery Coolant		I			I			I		
Wiper Blades	I	I	I	I	I	I	I	I	I	I

thousand mile interval

Special Operating Conditions	55	60	65	70	75	80	85	90	95	100
Perform these service items only if you drive primarily under the conditions indicated.										
Ball Joints and Dust Covers <sup>(5)</sup>	I		I	I		I	I		I	I
Drive Shaft Boots <sup>(5)</sup>	I		I	I		I	I		I	I
e-Transaxle Fluid <sup>(6)</sup>		R								
Nuts and Bolts on Chassis and Body <sup>(5,6)</sup>	T	T	T	T	T	T	T	T	T	T
Steering Linkage and Boots <sup>(5)</sup>	I		I	I		I	I		I	I

I: Inspect, P: Perform, R: Replace, T: Torque

<sup>1</sup> Inspect sealed transmissions, transfer cases, and differentials for signs of leakage. If any leakage from a sealed component is suspected, it is recommended that you have the sealed component inspected by a Toyota dealer. Inspect power steering fluid (if equipped) and brake fluid level/condition. Inspect engine and inverter (if equipped) coolant level/condition/freezing point. Your dealer may recommend services (Dealer-Recommended Maintenance) based on inspection results.

<sup>2</sup> Visually inspect every 5,000 miles, and inspect thickness and disc runout every 30,000 miles.

<sup>3</sup> Driving in conditions such as heavy traffic areas or urban areas or dusty areas or desert areas or dirt roads may shorten air conditioning filter's life. Therefore, it may need to be replaced earlier.

<sup>4</sup> Fill every 80,000 miles/96 months thereafter within the states that have adopted the ZEV regulation.

<sup>5</sup> Perform this service if you drive on dirt or dusty roads.

<sup>6</sup> Perform this service if you drive while towing, using a car-top carrier, or heavy vehicle loading. Not all vehicles are designed for towing. Refer to your *Owner's Manual* for details.

# MAINTENANCE CHART

thousand mile interval

Recommended Service	105	110	115	120	125	130	135	140	145	150
All Fluid Levels <sup>(1)</sup>	I	I	I	I	I	I	I	I	I	I
Ball Joints and Dust Covers	I			I			I			I
Brake Lines and Hoses	I			I			I			I
Brake Linings/Drums and Brake Pads/Discs <sup>(2)</sup>	I	I	I	I	I	I	I	I	I	I
Cabin Air Filter <sup>(3)</sup>				R						R
Drive Shaft Boots	I			I			I			I
Driver's Floor Mat for Proper Installation	I	I	I	I	I	I	I	I	I	I
e-Transaxle Fluid				I						I
Heater Coolant <sup>(4)</sup>	I			R			I			I
Radiator/Condenser/Intercooler (if applicable)	I			I			I			I
Rotate Tires	P	P	P	P	P	P	P	P	P	P
Steering Gear	I			I			I			I
Steering Linkage and Boots	I			I			I			I
Traction Battery Coolant <sup>(4)</sup>	I			R			I			I
Wiper Blades	I	I	I	I	I	I	I	I	I	I

thousand mile interval

Special Operating Conditions	105	110	115	120	125	130	135	140	145	150
------------------------------	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Perform these service items only if you drive primarily under the conditions indicated.

Ball Joints and Dust Covers <sup>(5)</sup>		I	I		I	I		I	I	
Drive Shaft Boots <sup>(5)</sup>		I	I		I	I		I	I	
e-Transaxle Fluid <sup>(6)</sup>				R						
Nuts and Bolts on Chassis and Body <sup>(5,6)</sup>	T	T	T	T	T	T	T	T	T	T
Steering Linkage and Boots <sup>(5)</sup>		I	I		I	I		I	I	

I: Inspect, P: Perform, R: Replace, T: Torque

<sup>1</sup> Inspect sealed transmissions, transfer cases, and differentials for signs of leakage. If any leakage from a sealed component is suspected, it is recommended that you have the sealed component inspected by a Toyota dealer. Inspect power steering fluid (if equipped) and brake fluid level/condition. Inspect engine and inverter (if equipped) coolant level/condition/freezing point. Your dealer may recommend services (Dealer-Recommended Maintenance) based on inspection results.

<sup>2</sup> Visually inspect every 5,000 miles, and inspect thickness and disc runout every 30,000 miles.

<sup>3</sup> Driving in conditions such as heavy traffic areas or urban areas or dusty areas or desert areas or dirt roads may shorten air conditioning filter's life. Therefore, it may need to be replaced earlier.

<sup>4</sup> Initial coolant replacement at 120,000 miles. Replace every 50,000 miles thereafter.

<sup>5</sup> Perform this service if you drive on dirt or dusty roads.

<sup>6</sup> Perform this service if you drive while towing, using a car-top carrier, or heavy vehicle loading. Not all vehicles are designed for towing. Refer to your *Owner's Manual* for details.

**T**he following descriptions are provided to give you a better understanding of the maintenance items that should be performed on your vehicle. The scheduled maintenance chart indicates at which mileage/time intervals each item should be performed. Please note that many maintenance items should be performed only by a qualified technician.

For further information on maintenance items you can perform yourself, see the “Maintenance and Care” section of the *Owner’s Manual*.

## Air Conditioning Refrigerant

Inspect and adjust refrigerant level at specified intervals. A qualified technician should perform these services.

## Ball Joints and Dust Covers

Check the suspension and steering linkage ball joints for looseness and damage. Check all dust covers for deterioration and damage. Replace any deteriorated or damaged parts. A qualified technician should perform these services.

## Brake Lines and Hoses

Visually inspect for proper installation. Check for chafing, cracks, deterioration and signs of leakage. Replace any deteriorated or damaged parts. A qualified technician should perform these services.

## Brake Linings/Drums and Brake Pads/Discs

Check the brake linings (shoes) and drums for scoring, burning, fluid leakage, broken parts and excessive wear. Check the pads for excessive wear and the discs for runout, excessive wear and fluid leakage. Replace any deteriorated or damaged parts. A qualified technician should perform these services.

## Cabin Air Filter

Replace at specified intervals. Driving in heavy traffic, on dirt roads, or in urban, desert, or dusty areas may reduce the filter’s lifespan, requiring more frequent replacement.

# EXPLANATION OF MAINTENANCE ITEMS

---

## Drive Shaft

Replace any deteriorated or damaged parts and, if necessary, repack the grease. Only a qualified technician should perform these services.

- Boots: Check the drive shaft boots and clamps for cracks, deterioration and damage.

## Driver's Floor Mat

- Only use the driver's floor mat designed specifically for the model and model year of your vehicle.
- Always properly secure the driver's floor mat using the equipped retainers.
- Never install another floor mat on top of the existing driver's floor mat.
- Never install the driver's floor mat upside down.

## e-Transaxle Fluid

Inspect or replace at specified intervals. When performing inspections, check each component for signs of leakage. If you discover any leakage, have it repaired by a qualified technician immediately.

## Heater Coolant

Drain the cooling system and refill with an ethylene-glycol type coolant. Inspect hoses and connections for corrosion and leaks. Tighten connections and replace parts when necessary. A qualified technician should perform these services. (For more details, contact your local Toyota Dealer.)

Your Toyota is equipped with Genuine Toyota Super Long-Life Coolant. The replacement intervals for heater coolant recommended in this booklet are based on replacement with Toyota Genuine Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids). If another type of ethylene-glycol coolant is used, replacement intervals may be different.

## Nuts and Bolts on Chassis and Body

Retighten the seat-mounting bolts and front/rear suspension member retaining bolts to specified torque.

## Radiator/Condenser/Intercooler (if applicable)

Check for any signs of damage or blockage by leaves, dirt or insects. Also check the hoses for leaks, corrosion and condition of installation. Clean if necessary. Have any problems repaired immediately by a qualified technician.

## Steering Gear

Inspect for signs of leakage. If you discover any leakage, have it repaired immediately by a qualified technician.

## Steering Linkage and Boots

With the vehicle stopped, check for excessive freeplay in the steering wheel. Inspect the linkage for bending and damage and the dust boots for deterioration, cracks and damage. Replace any damaged parts. A qualified technician should perform these services.

## Tires

Check tire pressure and check tires for damage and uneven wear. If the vehicle is equipped with a spare tire, check the condition and pressure of the spare. See your *Owner's Manual* for more information.

## Traction Battery Coolant

Inspect hoses and connections for corrosion and leaks. Tighten connections and replace parts when necessary. A qualified technician should perform these services.

In order to ensure maximum performance of the traction battery cooling system and limit risks of battery short-circuit and other damage to using "Toyota Genuine Traction Battery Coolant" or similar high-quality ethylene glycol-based, low electric conductivity coolant, non-amine and non-borate coolant with azole additives. Toyota cannot guarantee that the use of a product other than "Toyota Genuine Traction Battery Coolant" will prevent risks of battery short-circuit or other damage.

## Wiper Blades

The wiper blades should not show any signs of cracking, splitting, wear, contamination or deformation. The wiper blades should clear the windshield without streaking or skipping.

## VEHICLE IDENTIFICATION

---

Model \_\_\_\_\_

In-service date \_\_\_\_\_

Selling dealership \_\_\_\_\_

Key number \_\_\_\_\_

Body style \_\_\_\_\_

Mileage at delivery \_\_\_\_\_

Selling dealership phone number \_\_\_\_\_

Vehicle Identification Number \_\_\_\_\_





**bZ**

**Warranty & Maintenance Guide 2026**



0050526WMBZ