

TOYOTA Owners

toyota.com/owners

CUSTOMER EXPERIENCE CENTER

1-800-331-4331

DISPLAY NAVIGATION WITH ENTUNE

QUICK REFERENCE GUIDE

Display Navigation with Entune Quick Reference Guide

TABLE OF CONTENTS

OVERVIEW	2
<i>Limitations of the Quick Reference Guide</i>	2
<i>Basic Operation</i>	2
ENTUNE™ - INTRODUCTION	3
<i>What is Entune?</i>	3
<i>Entune</i>	3
<i>Phone Compatibility</i>	4
ENTUNE - HOW TO GET STARTED	5
<i>Basic Overview</i>	5
ENTUNE - NEW CUSTOMER REGISTRATION	6
<i>Account Creation</i>	6
<i>Downloading Entune App to Your Phone</i>	6
<i>Launch App</i>	6
<i>Connect Phone</i>	6
<i>Accessing Entune Apps</i>	6
HOW TO CONNECT YOUR BLUETOOTH PHONE	7
HOW TO CALL BY VOICE RECOGNITION	8
<i>Dial by Number</i>	8
<i>Dial by Name</i>	9
HOW TO INPUT A DESTINATION	10
<i>By Address</i>	10
<i>Note on Voice Recognition</i>	12
<i>Tips for Using Voice Recognition</i>	12
<i>By Address - Voice Recognition</i>	12
HOW TO INPUT A DESTINATION - POINT OF INTEREST	14
<i>Point of Interest by Name</i>	14
<i>Point of Interest by Category</i>	15
<i>Point of Interest by Category - Voice Recognition</i>	16
HOW TO SET HOME	17
<i>By Address</i>	17
ADDITIONAL NAVIGATION FEATURES	19
<i>Operation of Emergency Screen</i>	19
<i>Search Area</i>	19
<i>Route Preferences</i>	19
<i>3 Routes</i>	19
<i>Screen Configurations</i>	19
<i>Beep Setting</i>	20
<i>Voice Volume</i>	20
<i>Language</i>	20
<i>System Time</i>	20
<i>Auto Screen Change</i>	20
<i>Estimated Distance and Time</i>	20

LIMITATIONS OF THE QUICK REFERENCE GUIDE

The Quick Reference Guide is designed to provide information on the basic operation and key features of the navigation system and Entune™ (apps and data services). The Quick Reference Guide is not intended as a substitute for the Navigation Owner's Manual. We strongly encourage you to review the Navigation Owner's Manual, the Quick Reference Guide and visit www.toyota.com/entune so you will have a better understanding of all your vehicles features and controls.

BASIC OPERATION



1 NORTH-UP OR COMPASS MODE Icon
Touch to change the map display between North-up or Head-up perspectives.

2 MENU Button
Access radio, destination, phone, setup, media, apps, traffic incidents and map data.

3 MAP Button
Repeat the last voice guidance prompt, cancel the map scrolling feature, start guidance, or display the current position.

4 ZOOM IN/ZOOM OUT Icons
Touch to magnify or reduce the map scale.

5 CURRENT VEHICLE POSITION Mark
Indicates the current position of the vehicle and its directional heading.



PLEASE READ

WHAT IS ENTUNE?

The available Entune™ system is a collection of popular mobile applications and data services integrated with select Toyota vehicles. Entune™ includes three years of complimentary access to apps and services delivered via most smartphones and some feature phones (after three years, access charges will apply; excluding Pandora®).

Once the phone is connected to the vehicle using Bluetooth® wireless technology or a USB cable, Entune™'s features are operated using the vehicle's controls or, for some services, by voice recognition. Entune™ contains mobile apps for Bing™, iHeartRadio, MovieTickets.com, OpenTable® and Pandora®. Entune™'s data services include fuel guide, sports scores, stocks, traffic and weather. See www.toyota.com/entune for availability of apps and services.

ENTUNE*

In order to access Entune applications from your vehicle's touch screen, you must register using the Entune app on a capable smartphone or from www.toyota.com/entune. Visit www.toyota.com/entune to learn all about Entune features and use the link to register. After you register, use your cell phone to download the Entune app from the appropriate app store.

For additional information on Entune and to check phone compatibility, visit www.toyota.com/connect or call the Toyota Customer Experience Center at 1-800-331-4331.

PHONE COMPATIBILITY

An Entune capable phone is required to use apps and data services. Check phone compatibility by any one of the following methods:

- Visit: www.toyota.com/connect
- Call the Toyota Customer Experience Center at 1-800-331-4331

Note: You do not need an Entune capable phone to use Bluetooth® hands-free, Bluetooth audio or the navigation system. For Bluetooth phone pairing, refer to page 7.

*Be sure to obey traffic regulations and maintain awareness of road and traffic conditions. Select Entune™ apps use a large amount of data and you are responsible for all data charges. Apps and services vary by phone and carrier. Not all apps and data services are available initially. Apps identified by "™" or "®" are trademarks or registered trademarks of their respective companies and cannot be used without permission. See toyota.com/entune for the latest information regarding apps and services.

entune™ - HOW TO GET STARTED

BASIC OVERVIEW

	Step		Reference	
Phone Compatibility	1	Confirm that your phone is able to run the Entune app.	Go to "PHONE COMPATIBILITY" on page 4.	
Account Creation	2	Register at www.toyota.com/entune or via the Entune App on your phone.	Go to "ACCOUNT CREATION" on page 6.	
Download App	3	Download the Entune app to your phone.	Using your cell phone, find the Entune app in the Apple App Store or Android Market.	
Launch App and Login	4	Launch the Entune app on your phone and sign in.	The Entune app must be running on the mobile device in order to use the internet services.	User Name: <input type="text"/> Password: <input type="password"/>
Connect	5	Connect the phone to your vehicle, and experience Entune.	Go to "HOW TO CONNECT YOUR BLUETOOTH PHONE" on page 7.	

entune™ - NEW CUSTOMER REGISTRATION

ACCOUNT CREATION

step 1 From a computer, access www.toyota.com/entune

OR

step 2 Click on the "Quick Start Guide" tab located on the top of the page.

step 1 Click on "How Do I Use Entune?"

step 2 Follow the directions to create your account.

step 3 Determine your audio system and select "Click Here."

DOWNLOADING ENTUNE APP TO YOUR PHONE

Using your cell phone, connect to your app store (Apple App store, Android Market), search for Entune and download.



LAUNCH APP

In order to view the Entune apps on your vehicle display, some phones may require an additional step after they have been connected. After signing in, select Options on your phone to ensure the phone is connected and listening.

CONNECT PHONE

See page 7 for instructions.


ACCESSING ENTUNE APPS



step 1 Press **MENU** on the faceplate followed by .

step 2 Touch the desired application.

Quick Tip - The Entune app must be running on the mobile device in order to use the internet services.




The Entune app contains the only individual apps that will work with your vehicle. Other apps downloaded on your phone are not available through Entune.

HOW TO CONNECT YOUR BLUETOOTH PHONE



step 1 Press **MENU** on the faceplate followed by 



step 2 Touch . Verify that Bluetooth feature on the phone is ON and is in discoverable mode.



step 3 If necessary, input the passkey listed on the screen into the approved Bluetooth cell phone. Please refer to the cell phone manufacturer's user guide for pairing procedures.




step 4 Upon connection, the system will indicate that the pairing process was successful.

Quick Tip - Up to five Bluetooth cell phones can be paired. However, only one Bluetooth cell phone can be used at a time.


If you are able to successfully transfer your phone book, you can dial by name using voice recognition. Please say the name exactly as it is entered in your phone when in the telephone screen. If you have difficulty pairing your phone, or are unable to transfer your cell phone book, please refer to your cell phone manufacturer's user guide.

HOW TO CALL BY VOICE RECOGNITION

DIAL BY NUMBER



step 1 Press  on the steering wheel. After the beep say, "Dial <number>." Say the phone number digits individually, without pausing (e.g. "Dial Three, one, zero, four...").



step 2 After the beep, say "Dial" or press  on the steering wheel.

Quick Tip - If you know your next command, you can press  at any time to interrupt the prompt. Speak your command after the beep.



step 3 Call is active when **Talking** is indicated. To end call, press  on the screen or  on the steering wheel.


Quick Tip - It is recommended that you reduce background noise prior to using the Voice Recognition system. Conversation, high fan speed, wind noise (open windows), etc., may prevent the voice recognition system from understanding your commands.

 Some Bluetooth® equipped cell phones may or may not show battery or signal strength on the display.

HOW TO CALL BY VOICE RECOGNITION

DIAL BY NAME

If you are able to successfully transfer your phone book, you can dial by name using voice recognition. Please say the name exactly as it is entered in your phone when in the telephone screen. If you have difficulty pairing your phone, or are unable to transfer your cell phone book, please refer to your cell phone manufacturer's user guide.



step 1 Press  on the steering wheel. After the beep say, "Call <name>." Please say the name exactly as it is entered in your phone.



step 2 After the beep, say "Dial" or press  on the steering wheel.

Quick Tip - If you know your next command, you can press  at any time to interrupt the prompt. Speak your command after the beep.



step 3 Call is active when **Talking** is indicated. To end call, press  on the screen or  on the steering wheel.

HOW TO INPUT A DESTINATION


BY ADDRESS




step 1 Press **MENU** on the faceplate followed by 



step 2 Touch 



step 3 If state is correct, touch  and move to step 5. To change State/Province, touch  and move to step 4.



step 4 Select the desired State/Province.



step 5 Input the city name. Select the desired city name from the displayed list.




step 6 Input the street name and touch . Select the desired street name from the displayed list.


Quick Tip - Enter the street name without prefixes such as North or the letter N. The system will display the base street name without prefixes or suffixes on the next screen.


HOW TO INPUT A DESTINATION

BY ADDRESS



step 7 Input the house number and touch .



step 8 Touch .



step 9 Touch  followed by .



step 10 Select the desired Route Preferences and touch  to confirm selection. See page 15 for route selection.



step 11 Touch  to start route guidance.

HOW TO INPUT A DESTINATION

NOTE ON VOICE RECOGNITION

The navigation system's voice recognition feature will compare your spoken words with computer-generated word patterns preprogrammed in the database. If the system does not provide your intended match, please try a different pronunciation. Voice-activation names are not available for every street and city.

TIPS FOR USING VOICE RECOGNITION

tip 1 A large TALK icon  will illuminate on the NAV screen to signal when to speak your command.

tip 2 Have the full and correct address in mind. The system will ask for the state, city, and street name followed by the house number as separate inputs.

tip 3 Before using voice recognition, roll up all windows and set the climate control fan on low or off to reduce background noise in the cabin.

tip 4 Speak at a normal volume and pace, and pronounce words clearly.

tip 5 Streets should be spoken without prefixes or suffixes. Street names should be spoken as in these examples:
1st Street, say: "First"
E 15th Street, say "Fifteenth"
190th Street, say "One hundred ninetieth"
Point Court, say "Point"

tip 6 Say a street address number as single digits. Examples:
125, say: "One two five"
2000, say: "Two zero zero zero"
32307, say: "Three two three zero seven"

BY ADDRESS-VOICE RECOGNITION



step 1 Press  on the steering wheel. After the beep say, "Enter an Address."



step 2 After the beep say the city name or, "Change state" to search in another state.

Quick Tip - If you know your next command, you can press  at any time to interrupt the prompt. Speak your command after the beep.

HOW TO INPUT A DESTINATION


BY ADDRESS-VOICE RECOGNITION



step 3 After the beep say the street name.



step 4 After the beep say the house number as single digits.



step 5 If necessary, after the beep say, "Yes" to confirm address.




step 6 After the beep say, "Start Guidance."



step 7 Touch **OK** to start route guidance.

HOW TO INPUT A DESTINATION - POINT OF INTEREST

POINT OF INTEREST BY NAME



step 1 Press **MENU** on the faceplate followed by .



step 2 Touch .



step 3 Touch .



step 4 Input the POI name and if necessary touch .



step 5 Use  or  to scroll up or down. Touch the desired destination followed by .



step 6 Touch  to start route guidance.

Quick Tip - If the POI isn't listed in the database verify the spelling and Search Area for accuracy.

HOW TO INPUT A DESTINATION - POINT OF INTEREST


POINT OF INTEREST BY CATEGORY



step 1 Press **MENU** on the faceplate followed by 



step 2 Touch 



step 3 Touch 



step 4 Touch the desired category location.



step 5 Touch the desired category icon followed by the desired sub-category.




step 6 Use  or  to scroll up or down. Touch the desired point of interest. Touch  followed by  to start route guidance.

HOW TO INPUT A DESTINATION - POINT OF INTEREST

POINT OF INTEREST BY CATEGORY - VOICE RECOGNITION

Quick Tip - You can search for many dining, hotel and fuel chains by name, e.g., "Find Nearby Starbucks."



step 1 Press  on the steering wheel. After the beep say, "Find Nearby <POI category>" (e.g., "Find Nearby Hotel.")



step 2 After the beep say, the number that corresponds to the desired destination.

Quick Tip - If you know your next command, you can press  at any time to interrupt the prompt. Speak your command after the beep.



step 3 After the beep say, "Start Guidance."



step 4 Touch  to start route guidance.

HOW TO SET HOME

BY ADDRESS




step 1 Press **MENU** on the faceplate followed by 



step 2 Touch 



step 3 Touch 



step 4 Touch 

Tip - For security reasons, use a point close to your home instead of your actual home address.



step 5 Touch 



step 6 Touch 

HOW TO SET HOME

BY ADDRESS



step 7 Input the city name. Select the desired city name from the displayed list.



step 8 Input the street name and touch **OK**. Select the desired street name from the displayed list.


Quick Tip - Enter the street name without prefixes such as North or the letter N. The system will display the base street name without prefixes or suffixes on the next screen.



step 9 Input the house number and touch **OK**.




step 10 Confirm location and touch **Enter**.



step 11 Touch **Edit** followed by the desired icon for your home. Touch **OK**.

ADDITIONAL NAVIGATION FEATURES

OPERATION OF EMERGENCY SCREEN



Touch the desired emergency category. If the vehicle is in motion, only nearby police stations, dealers, hospitals or fire stations are shown.

SEARCH AREA




Prior to inputting the desired address select the State/Province by pressing **Change State/Province**. The system is only capable of searching for an address within one state or province at a time.

ROUTE PREFERENCES





Once the address has been inputted, select the desired route preference(s) for the trip. When the yellow bar appears, the preference has been selected. For example, if Toll Roads is not selected, the system will route over non-toll roads which may take longer to reach the destination.

3 ROUTES



One of three routes may be chosen for the trip:
Preferred- is the easiest route, usually the fastest
Alternate- is the second fastest route
Short- is the most direct based upon driven mileage

SCREEN CONFIGURATIONS



Select what information to display with the map. Some selections are available during route guidance mode only.


ADDITIONAL NAVIGATION FEATURES

BEEP SETTING




PRESS **MENU** > **Setup** > **General**
Turn the Beep sound On or Off. Touch **Beep**.

VOICE VOLUME



PRESS **MENU** > **Setup** > **Voice**
Adjust the Voice Guidance volume level. Touch **Volume**.

LANGUAGE




PRESS **MENU** > **Setup** > **General**
Select Language Preference: English, French or Spanish. Touch **Language**.

SYSTEM TIME



PRESS **MENU** > **Setup** > **General**
Adjust the Time Zone and Daylight Saving Time option. Touch **System Time**.

AUTO SCREEN CHANGE



PRESS **MENU** > **Setup** > **General** > **Auto Screen Change**
Once the screen transition is switched off, the audio screen will remain without reverting to the map display. Touch **Auto Screen Change**.

ESTIMATED DISTANCE AND TIME



PRESS **MENU** > **Setup** > **Navigation** > **Detailed Nav. Settings** > **Driving Speeds**
The system can be customized to match your driving habits. Adjust the speed settings. Touch **Speed**. Please refer to the Navigation Owner's manual for a complete description of this feature.

NOTES
